

Room Controller Installation Instructions



Load:Logic®
Room Controller

Precautions

- **READ AND FOLLOW ALL SAFETY INSTRUCTIONS.**
- **CAUTION: USE COPPER CONDUCTOR ONLY.**
- **CAUTION - RISK OF ELECTRICAL SHOCK.** To prevent electrical shock, turn OFF power at the circuit breaker before installing or servicing unit. Never wire energized electrical components.
- **NOTICE:** For installation by a licensed electrician in accordance with National and/or local Electrical Codes and the following instructions.
- **NOTICE:** Do not install if product appears to be damaged.
- Be sure to read and understand all instructions before installing or servicing unit
- For Indoor use only. Do not use outdoors.
- Disconnect switch or a circuit breaker must be provided and marked as the disconnecting device.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- Confirm device ratings are suitable for application prior to installation. Use of device in applications beyond its specified ratings or in applications other than its intended use may cause an unsafe condition and will void manufacturer's warranty.
- All servicing shall be performed by qualified service personnel.
- If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- No user serviceable parts contained inside unit. Refer all service related questions to the factory.

SAVE THESE INSTRUCTIONS!



Room Controller Setup App

Operation Guide



IMPORTANT: This App is designed to assist in the configuration of control parameters for the Hubbell Wiring Device-Kellems Load:Logic® Room Controller. Once the App has been used to change any setting in a room, manual configuration using the push buttons and LEDs on the Room Controller will be disabled. All further settings will need to be made using the App. (See Room Controller Installation Instructions)

START THE APP BY TOUCHING THE NX SCREEN ICON.

When the App starts, you will be prompted to enter a security pin. The default pin is **96@01**. Once started, the App will automatically do a discovery to find all active RCBTM's (NXBTR) Bluetooth® interface modules that are in range. After discovery is complete, a list of discovered RBTM's will be displayed. Use the signal strength indicators to determine the closest module for the current room. Modules can also be uniquely identified by the MAC address label on the module's housing.

Touch the appropriate module indicator to start a discovery of devices in the room where this module is installed. Wait for the discovery to complete before making further selections.

When discovery is complete, a listing of the devices found will be displayed. These will include:

1. **Room Controllers:** Touch to display a list of room controllers found in the room. Touch one of the room controllers to see a display showing controls for the relay(s) and dimmer(s), if present, in that room controller. If the room has only one room controller, it will automatically open when **Room Controllers** is selected.

The current state of the relays and dimmers will be displayed on the screen. The displays are in real time.

Use the relay control(s) to change the state of the relay. Use the dimmer control bar to change the state of the dimmer(s)

Reboot (Top of Screen): Restarts the room controller.




Factory Reset: Sets the room controller and all connected devices back to factory default settings.

2. **Relays:** Touch to display a list of relays found in the room. Touch the relay to see a display of the available relay settings. The current settings will be shown on the display.

Name: Allows the relay to be given a meaningful name. Use the keyboard to enter a name if desired.

Pri/Sec: Indicates whether this relay is logically a Primary relay or a Secondary relay. This logic is used with the daylight sensor option to determine the sequence in which the relay(s) will switch OFF in response to increasing daylight. The Primary relay will switch first, followed by the Secondary.

Power Up: Select the state this relay will default to upon restoration of power to the room controller after an outage. The default setting is **Last State**.



Mode: Indicates how the relay will respond to the occupancy sensor. Occupancy mode is automatic ON. Vacancy mode is manual ON. This will automatically be set to Vacancy mode for all relays if at least one switch is connected to the room controller(s).

Occupied: Sets the state of the relay when the room is occupied. Default is ON.

Unoccupied: Sets the state of the relay when the room is unoccupied. Default is OFF.

Groups: A blue background fill in one of the 16 available groups indicates that this relay is selected to be a member of this group number. A gray background fill indicates that the relay is NOT a member of the group. The relay may be a member of any or all groups if required.

Relay: Allows manual ON/OFF actuation of the relay in real time.

Make changes as needed. Touch the **<Accept>** button to save the changes or touch the **<Back>** button to exit WITHOUT saving the changes.

3. **Dimmers:** Touch to display a list of dimmers found in the room. Touch one of the dimmers to see a display of the dimmer settings:

Name: Allows the dimmer to be given a meaningful name. Use the keyboard to enter a name if desired.

Power Up: Select the state this dimmer will default to upon restoration after an outage. **<Last State>** is the default setting. Touch **<Set Level>** to enter a specific dim level for power up. Use the **<Level>** slider to set the desired level or, touch the box to use the keyboard to enter the level.

High Trim: Sets the maximum dimming level for this dimmer. The default setting is 100%.

Low Trim: Sets the minimum dimming level for this dimmer. The default setting is 0%

Dim to OFF: If set to **<Enabled>**, a relay(s) in the same group as the dimmer, will turn OFF when the dimming level reaches 0%. If set to **<Disabled>**, a relay(s) in the same group as the dimmer, will NOT turn OFF when the dimming level reaches 0%.

Mode: Indicates how the dimmer will respond to the occupancy sensor. Vacancy Mode is Manual ON. Occupancy Mode is Automatic ON.




Occupied Level: Sets the Level of the dimmer when the room is occupied. Default is **Last Level**.

Unoccupied Level: Sets the level of the dimmer when the room is unoccupied. Default is **Last Level**.

Groups: A blue background fill in one of the 16 available groups indicates that this dimmer is selected to be a member of this group number. A gray background fill indicates that the dimmer is NOT a member of the group. The dimmer may be a member of any or all groups if required.

Dimmer: Allows manual actuation of the dimmer in real time.

Make changes as needed. Touch the **<Accept>** button to save the changes or touch the **<Back>** button to exit WITHOUT saving the changes.



4. **Switches:** Touch to display a list of switches found in the room. Note that each switch display indicates the port number and switch's address wheel setting (See RC Switch installation instructions for more details). This is useful for distinguishing between switches of the same type in the room.

There are a number of different switch types that might be discovered. The setup screens for the various types will differ based on the function of the switch being selected.

Touch a switch to see the current settings for that switch:

A. **Multifunction Switch** - # series smart switch:

Name: Allows the switch station to be given a meaningful name. Use the keyboard to enter a name as desired.

Button: Blue background fill indicates the currently selected button.

Type: Indicates the current button type. The default button type is Toggle. Use the pull down to display a list of the available button types and select the desired Type from the list for this button:

Toggle: Touch ON/Touch OFF (default)
ON: Touch for ON only
OFF: Touch for OFF only
Raise: Ramp dimmer up
Lower: Ramp dimmer down
Timed ON: Touch for ON for set time period
Disabled: Button disabled

Groups: A blue background fill in one of the 16 available groups indicates that this switch is selected to be a member of this group number. A gray background fill indicates that the switch is NOT a member of the group. The switch may be a member of any or all groups if required.

Make changes as needed. Touch the **<Accept>** button to save the changes or touch the **<Back>** button to exit WITHOUT saving the changes.



B. **ON/RAISE/LOWER/OFF (ORLO) and RAISE/LOWER (RL) Switches:**

Name: Allows the switch station to be given a meaningful name. Use the keyboard to enter a name as desired.

Raise/Lower Setup: Allows adjustment to the speed at which the dimming level will change as a Raise or Lower button held down.

Rate: Sets the rate at which level change messages are sent from the switch to the dimmer. Recommended setting is 300.

% Change: Sets the amount of change that occurs with each message. A setting of 10 will provide about a 5 second transition time from 0% to 100%.

Groups: A blue background fill in one of the 16 available groups indicates that this switch is selected to be a member of this group number. A gray background fill indicates that the switch is NOT a member of the group. The switch may be a member of any or all groups if required.

Make changes as needed. Touch the **<Accept>** button to save the changes or touch the **<Back>** button to exit WITHOUT saving the changes.



C. Scene Switch:

Name: Allows the switch to be given a meaningful name. Use the keyboard to enter a name as desired.

Preset Setup: The buttons are factory configured to control Preset 1 - Preset 4 from top to bottom respectively. Use the drop down arrow adjacent to a button to choose one of the 16 available presets to be recalled by this button.

Preset Status: Indicates the currently activated preset.

Raise/Lower Setup: Allows adjustment to the speed at which the dimming level will change as a Raise or Lower button held down.

Rate: Sets the rate at which level change messages are sent from the switch to the dimmer. Recommended setting is 300.

% Change: Sets the amount of change that occurs with each message. A setting of 10 will provide about a 5 second transition time from 0% to 100% while holding down a Raise or Lower button.

Make changes as needed. Touch the **<Accept>** button to save the changes or touch the **<Back>** button to exit WITHOUT saving the changes.

5. **Occupancy Sensors:** Note that regardless of the quantity of sensors installed, the App will only indicate a single sensor with a composite occupancy state for the room.

Name: Allows the sensor to be given a meaningful name. Use the keyboard to enter a name as desired.

Groups: A blue background fill in one of the 16 available groups indicates that this sensor is selected to be a member of this group number. A gray background fill indicates that the sensor is NOT a member of the group. By default, the occupancy sensor is set to be a member of all groups.

State: Indicates the Occupied or Unoccupied state of the room as reported by the occupancy sensor at the time the App screen was accessed. This is read only. Touch the **<Refresh>** button to re-read the occupancy state of the room.

Make changes as needed. Touch the **<Accept>** button to save the changes or touch the **<Back>** button to exit WITHOUT saving the changes.

6. **Daylight Sensor:** Touch to display the **Photocell** set up page. This page allows for the setup of up to 6 zones of daylight harvesting using a single compatible photocell like the RCDP.

Name: Allows the sensor to be given a meaningful name. Use the keyboard to enter a name as desired.

Daylight Level: Indicates the current amount of daylight visible to the daylight sensor. Touch **<Refresh>** at any time to re-read the daylight level.

Sensor Range: Use the pull down to select the range appropriate to the daylight sensor model installed. The standard RCDP daylight sensor is factory set to 3 to 300. This is the nominal default for typical indoor side lighted applications.

Zone #: Use the pull down to select the type of daylight harvesting control to be used for this zone. The available choices are:

- A. **None:** Daylight harvesting not enabled. This is the default setting for Zones 2-6.



- B. **ON/OFF Mode:** All controlled lighting will turn OFF based on the settings. The controlled lighting will be OFF as long as there is sufficient daylight to maintain the desired minimum task light level.

Design Level: The target minimum foot candle level at the task work surface.

At Sensor: Indicates the current amount of daylight visible to the daylight sensor. Touch **<Get Level>** at any time to refresh the daylight level.

At Task: The amount of light in foot candles as read by a light meter placed at the task surface. Take this reading with the indoor lighting turned OFF.

Dead Band (%): Provides a band between ON and OFF to prevent unwanted cycling of the load. Typically a setting of 5% works well.

Make changes as needed. Touch the **<Accept>** button to save the changes or touch the **<Back>** button to exit WITHOUT saving the changes.

- C. **Step Relay Mode:** High, low, OFF switching control based on the Primary/Secondary setting for the controlled relay(s)
- D. **Full Dimming Mode:** Full range dimming in response to daylight.

Design Level: The target minimum foot candle level to be maintained at the work surface. Enter the specified foot candle level.

At Sensor: Indicates the current amount of daylight visible to the daylight sensor. Touch **<Get Level>** at any time to re read the daylight level.

At Task: The amount of light in foot candles as read by a light meter placed at the task surface. Take this reading with the electric lighting turned OFF.

NOTE: Make adjustments to the Design Level until the desired foot candle reading is achieved on the light meter at the task surface.

- E. **Test Mode:** This is the factory default setting for Zone 1. Test mode causes the controlled lighting to react quickly to bright and dim light such as passing the beam of a flashlight across the daylight sensor.

7. **Preset Settings:** Touch to display the preset setup page. Use the Preset Select pull down to choose which preset (1 - 16) this button will affect. **Note:** the factory default programming, sets Preset 1 to 100%, Preset 2 to 75%, Preset 3 to 50%, and Preset 4 to 25% for all dimmers. **NOTE:** The "Include" setting determines if this preset will affect the associated dimmer or relay. If the box is not checked, this preset will NOT change this dimmer or relay when activated.

Fade Time: The fade time for transitions between presets can be set between 1 second and 18 hours. The factory default fade time is 5 seconds. Use the sliders or type in the box to change the fade time for this preset.

Dimmers: Use the slider or type in the box to set the desired dimmer level for each dimmer.

Relays: Use the controls to set if the relay will be turned ON or OFF when this preset is activated.

After all settings have been selected, touch the **<Save>** button at the top of the screen. A **<Test>** button is also provided at the top of the screen. This button will activate the current preset exactly as if the preset button on the actual switch is touched.

NOTE: Touching the **<Test>** button immediately after saving a preset will have no affect since the lighting will already be set to the levels defined for the current preset.

Zone 1 Daylight Levels

Design Level: 100

At Sensor: 100

Get Level

At Task: 100

Zone 1 Dimmer Rates

Ramp Up Rate (sec): 0


Ramp Down Rate (min): 0

Zone 1 Group Settings

01	02	03	04
05	06	07	08
09	10	11	12
13	14	15	16

Description

Hubbell Wiring Device-Kellems Load:Logic[®] Room Controller is a smart device designed to control and manage lighting loads in a space based on a set of configured parameters. It contains two independently controlled outputs. Optional 0-10VDC outputs are available for controlling dimmable ballasts and LED drivers. The Load:Logic[®] Room Controller also features four RJ45 ports that provide plug and play support for occupancy, daylight sensors and switches for local control. The Load:Logic[®] Room Controller can operate in a stand-alone mode or connected with other room controllers.



Installation

- DO NOT DISCARD THE MAC ADDRESS LABELS INCLUDED WITH THE PRODUCT. SEE STEP (5) BELOW.
- The room controller has a MAC address label affixed to the outside of the unit. Place the enclosed MAC address label(s) in a log book and record the location of the room controller and the circuit(s) it controls. The MAC address will be needed later during the system setup process.
- Turn power OFF at the service panel.
- Mount the room controller's enclosure to a 1/2" knockout opening of an electrical junction box. Secure it to box tightening the included locknut. (See Figure 1)
- Connect the control devices (e.g. occupancy sensors, daylight sensor and switches) to any of the RJ45 ports available using a UTP patch cord. Similar devices (e.g. switches or occupancy sensors) may be connected together from the same RJ45 port. (See Figure 2)
- Make the appropriate electrical connections from the room controller to the corresponding devices as shown in Figure 3.
- Turn ON the power at the service panel.
- Test the installation as follows:
 - Momentarily press Button A to toggle Load A (red wire) ON and OFF.
 - Momentarily press Button B to toggle Load B (blue wire) ON and OFF.
 - Turn ON Load A.
 - Press and hold Button A down to decrease the light level on Load A.
 - Release Button A and press again to increase the light level on Load A.
 - Turn OFF Load A.
 - Turn ON Load B
 - Press and hold Button B down to decrease the light level on Load B.
 - Release Button B and press again to increase the light level on Load B.
 - Turn OFF Load B.




Figure 1
Room Controller mounted
into a 4 x 4 junction box




Figure 2
Room Controller RJ45 ports
to connect control devices

Understanding Low Voltage Load Capacity

The room controller is capable of providing a source of 24VDC to power the connected low voltage devices such as switches, sensors and wireless transmitters. The room controller's current capacity is 250 mA. Since the control components require different amounts of current to operate properly, the following table will help to determine how many low voltage devices can be connected to a single room controller regardless of the RJ45 port in which the device is connected. If two or more room controllers are connected together, the capacity is determined for each room controller based on the control devices that are actually connected into that specific room controller. The maximum capacity per room controller is 30 Loads. Below is the correlation in regards of current requirements per low voltage device.

- Switches, Daylight Photocell, and PIR Occupancy Sensor = 1 Load
- PIR only Occupancy sensor with RP option = 2 Loads
- Dual Technology and Ultrasonic Occupancy sensor = 3 Loads
- Dual Technology and Ultrasonic Occupancy sensor with RP option = 4 Loads

NOTE: Only one daylight sensor can be connected in each room/zone

Self-Configuration

The room controller's sequence of operation will automatically reconfigure as devices are connected as described in the following sections. Note that self-configuration will automatically be disabled once the room has been manually configured. See *Manual Configuration* section.


Occupancy Sensors

The room controller is compatible with any Hubbell Wiring Device-Kellems low voltage occupancy sensor. An RJ45 wiring adapter (***sold separately***) is required to make the sensor compatible with the connection to a RJ-45 port in the room controller. See **Figure 3** and *HBLRJ45A10 installation instructions*. This adapter is color coded to match the flying leads on the sensors.

An occupancy sensor connected to a room controller will be recognized after the first time it cycles occupancy.

When **ONLY** an occupancy sensor is connected to the room controller, the room controller will set its operation mode to Auto ON / Auto OFF. Once a smart switch is connected to the room controller, the operation mode will automatically switch to Manual ON / Auto OFF (vacancy mode). To change one or more load(s) to Auto ON operation see Manual Configuration section below.

Figure 3



Smart Switches

These devices will automatically configure themselves to control the available loads within 5 seconds after being connected to the room controller. For best results, do not press any buttons for 5 seconds after connecting a switch to the room controller.

The buttons on the following switch catalog numbers are configured as toggle ON/OFF operation mode by default: **RCS1x**, **RCS2x**, **RCS2x**, **RCS4x**, and **RCS6x**. These switches will self configure to sequentially control the loads. For example, an **RCS1x** will control Load A and Load B simultaneously because it only has one button, an **RCS2x** will control loads A and B, independently because it has 2 buttons.


The relationship between the buttons and the loads can be configured. See **Manual Configuration** below. **NOTE:** If the zone has more loads than buttons, the last button in the sequence will automatically control the all remaining loads simultaneously. This insures that no load is left uncontrolled during the self-configuration process.

Switches with specific functions like catalog numbers **RCSNFX** and **RCSTOX**, **RCSRLx**, **RCSSCx**, **RCSNRLFx** will self-configure by default to their respective descriptions. For example; **RCSRLx** is a Raise/Lower dimmer. Its default operation will be to change ALL the light levels of connected light fixtures. The relationship between the switch functions and the loads being controlled can be modified. See **Manual Configuration** below.

Daylight Sensor

The daylight sensor will self-configure to control Load A when connected to a room controller. The photocell operation can be verified by observing Load A lighting while alternately covering the photocell (Load A light will be ON and bright if dimming enabled) or exposing the photocell to bright light (Load A light will be OFF or dimmed if so enabled). The relationship between the daylight sensor and the load(s) can be changed. See **Manual Configuration** below.


Figure 4



Manual Configuration

The process of manual configuration allows for the adjustment of certain functions by using the A and B pushbuttons and LED indicators on the room controller's enclosure. The functions that can be adjusted are:

1. Assign loads to buttons and switches.
2. Configure loads for Manual ON (vacancy mode) or Auto ON operation mode.
3. Configure loads to respond to the photocell.
4. Calibrate the photocell.



Wiring Device-Kellems
Hubbell Incorporated (Delaware)
Shelton, CT 06484
1-800-288-6000
www.hubbell-wiring.com



How to Enter Manual Configuration Mode from the Room Controller

To enter manual configuration mode, follow these steps:

1. Simultaneously press and hold the A and B pushbuttons on the room controller until the A and B LED's start to blink alternately.
2. Release the A and B pushbuttons. The room controller is now in manual configuration mode. The light fixtures on the circuit connected to Load A will be ON and all other loads will be OFF.

Note: While in configuration mode no more than one load will ever be ON and the A and B buttons on the room controller will NOT be able to control the loads.

Hint: If both loads (A and B) are ON or pressing the A or B button switches a load, the room controller is NOT in configuration mode. Repeat the previous steps to enter manual configuration mode.

Exit Manual Configuration Mode from the Room Controller

To exit manual configuration mode, simultaneously press and immediately release buttons A and B. The room controller will resume normal operation.

Enter Manual Configuration Mode from a Switch

1. Remove the faceplate from any of the switches in the room and locate the rectangular opening in the plastic bezel marked "SVC PIN". Use a small round object such as a straightened paper clip to press the recessed configuration button for 5 seconds.
2. Observe that the button is located slightly offset from the bezel opening. The LED marked "SVC" will blink while the configuration button is being pressed.
3. Release the configuration button and note that one load turns ON and all other loads turn OFF indicating that the room is in manual configuration mode.

Exit Manual Configuration Mode from a Switch


1. Press the configuration button for five seconds. The LED marked "SVC" will blink while the configuration button is being pressed.
2. Release the configuration button. The loads in the room will restore to the levels they were prior to entering manual configuration mode.

Assigning a Lighting Load to Buttons in a Switch

As described in the **Smart Switches** section, all switches assume a default operation of the loads when they are connected to the room controller's RJ45 port. The assignment of the loads to the buttons can easily be changed as follows:

Switches with LED indicators:


1. Enter in **Manual Configuration Mode from the Switch** described above. Load A will be ON. While load A is ON, each button that controls that load will have a lighted LED.
2. To deny the control function of the load from the button, press the switch button to turn OFF the button's LED.
3. To assign control of the load to another button, press the switch's button to light ON the LED the button to be paired.
4. Repeat this process for all buttons.
5. To advance to the next load, press and release button A on the room controller. Load A will turn OFF and the next load will turn ON.



6. Repeat the assignment process above for each load.

Switches WITHOUT LED indicators, (**RCSOOx**, **RCSNRLFx**, **RCSRLx**, etc.):

1. Press the ON button or the Raise button to assign control of the load.
2. Press the OFF button or the Lower button to deny control of the load.
3. Tap the recessed configuration button to advance to the next load as necessary.



After all loads are assigned, exit manual configuration mode. Test the button operation and repeat the above if necessary.

Configure Loads for Auto ON or Manual ON (Vacancy Mode) Operation

1. Enter **Manual Configuration Mode from the Room Controller** (see section above).
2. While load A is ON, the B LED indicator light on the room controller will identify the current operation mode for the load.
 - a. If LED B is OFF, the load will operate in manual on (vacancy) mode.
 - b. If LED B is ON, the load will operate in auto ON mode when the motion sensor detects occupancy.
3. Press and release button B on the room controller to change the operation mode for the current load.
4. To advance to the next load, press and release button A on the room controller.
5. Repeat the above for all loads.
6. When finished, exit manual configuration mode.

Hint: a load set to Manual ON (vacancy) mode must be controlled by an RCSx smart switch, otherwise the load will never turn ON.

Photocell Configuration Mode

1. Set the room controller to manual configuration mode. See **Manual Configuration Mode from the Room Controller** section on page 5.
2. Simultaneously press and hold buttons A and B for three seconds until LED A begins to blink rapidly. This indicates the room controller has transitioned from load configuration mode into photocell configuration mode.
3. While in photocell configuration mode, only one load will be ON. If the selected load has dimming capability, the light will cycle between minimum to maximum light levels to identify itself during the selection process.
4. Press and release button B on the room controller. LED B will blink in a pattern to indicate the performance level for daylight harvesting. The blink patterns are as follows:
 - a. Double blink/pause indicates normal baseline performance (default setting).
 - b. Triple blink/pause indicates more aggressive performance, lights will dim more.
 - c. Single blink/pause indicates less aggressive performance, lights will dim less.
 - d. No blinking indicates that the selected load will not participate in daylight harvesting.
5. Press and release button B on the room controller to cycle through the performance choices for the selected load. The “more aggressive” selection will cause the light level to be reduced more during daylight harvesting. The “less aggressive” selection will cause the light level to be reduced less.

Hint: As a default, if the room controller is equipped with dimming capability (LLC2RD), the photocell will operate in continuous dimming daylight harvesting mode. If the room controller does not have dimming capability (LLR2R), the photocell will operate in switching (ON/OFF) daylight harvesting mode based on a default set point of 150 foot-candles.

6. Press and release button A on the room controller save your selection and to advance to the next load.

7. Repeat the above to set the performance for all loads to be controlled by the photocell.
8. Proceed to auto calibration of the photocell.

Hint: The above process can be used to set up multi-zone daylight harvesting in applications where more than one row of lights are to be controlled. Select a more aggressive performance for the row closest to the windows and a less aggressive performance for the row away from the windows. As an example, of this process it is possible to set up a room with three zones of daylight harvesting using the triple blink setting for the row by the window, the double blink setting for the row in the center, and the single blink setting for the row away from the window.

Auto-Calibrating the Photocell

The photocell must be calibrated before it will perform proper daylight harvesting operation. Be sure to complete the load assignment process above before proceeding with auto calibration of the photocell.

1. Place the room controller in photocell configuration mode. See **Photocell Configuration Mode** on page 6.
2. Simultaneously press and hold buttons A and B for three seconds until both LED A and B begin to blink rapidly indicating the auto calibration process has started.
3. Release buttons A and B. The lights will cycle OFF and ON during the calibration process.
4. When calibration is complete, the room controller will automatically exit configuration mode and return to normal operation. Daylight harvesting will now be active based on the settings made during configuration.

Reset the Room Controller to Factory Default Settings

To erase all manual configurations and restore the room controller to its factory default settings, perform the following steps:

1. Simultaneously press and hold buttons A and B on the room controller. After a few seconds, LED's A and B will begin blink alternately.
2. Continue to hold buttons A and B until the blink pattern changes to a double blink pattern.
3. Release buttons A and B. When the blinking stops, all lighting loads will turn ON indicating the room controller has been reset to factory default settings.

Hint: If the installation has more than one room controller connected together in the room, the reset process done on any one of the room controllers will reset ALL of the room controllers.

Reset Factory Defaults Using a Switch

1. Remove the faceplate from any wall switch and locate the rectangular opening in the plastic bezel marked "SVC PIN".
2. Use a thin object such as a straightened paper clip to press the recessed configuration button for at least 10 seconds. Observe that the button is located slightly offset from the opening in the bezel.
3. The LED marked "SVC" will blink while the configuration button is being pressed.
4. Release the configuration button and note that all loads in the room turn on indicating that the room has been reset to factory default settings.

