

INSTRUCTIONS FOR CONDUIT ENTRY INTO HOFFMAN RAINPROOF ENCLOSURES

A. Conduit Entry Above Live Parts:

1. Use only U.L. listed rain tight or liquid tight conduit hubs.
2. Install hubs and conduit according to the hub manufacturers instructions.

B. Conduit Entry Below Live Parts:

1. Punch or drill the correct hole for the size of conduit to be used (see table below) or use the appropriate knockout (where provided).
2. Secure the conduit with locknuts inside and out, or with a locking bushing on the inside and a locknut on the outside.

<u>CONDUIT SIZE</u>	<u>HOLE SIZE</u>
1/2"	7/8"
3/4"	1 1/8"
1"	1 3/8"
1 1/4"	1 3/4"
1 1/2"	2"
2"	2 1/2"
2 1/2"	3"
3"	3 5/8"