

## RT200 Two Wire to U-Ground Adaptor Installation Instructions

- **NOTICE:** Only for installation on a non-decorator style standard duplex receptacle in accordance with national and local electrical codes and included instructions.
- **CAUTION: RISK OF ELECTRIC SHOCK.**
  - Verify that the device type and rating are suitable for the application.
  - Turn off power at the breaker before installing.
- **CAUTION:** If a path to Ground through the wall box (i.e. plastic wall box) is not present where the receptacle is installed, and/or the receptacle does not have an auto grounding feature, this device will not provide Ground path protection.
- Remove the center screw from the wall-plate and remove the wall-plate to verify the wall box type and available Ground path connection.
- Place the wall-plate back in position over the receptacle and insert the two-wire U-Ground adaptor into the receptacle so the opening of the metal U-Ground adaptor termination is positioned over the wall-plate screw hole.
  - **CAUTION:** Do not turn on power until the wall plate has been re-installed.
- Install the wall-plate screw through the metal U-Ground adaptor termination and through the wall-plate and tighten the screw 5 – 7 lbf-in. (.6 - .8 Nm)
  - **CAUTION:** Do not over tighten screw or risk stripping the receptacle wall-plate mounting screw threads and/or damaging the wall-plate.

Wiring Device-Kellems  
Hubbell Incorporated (Delaware)  
Shelton, CT 06484  
1-800-288-6000  
[www.hubbell-wiring.com](http://www.hubbell-wiring.com)

PD2494 Rev. 10/11