

CAUTION: Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

P563000

WARNING - Follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a Qualified Electrical Contractor.

WARNING - Risk of fire or electrical shock.

WARNING - To comply with the National Electric Code and Underwriters Laboratories Requirements, when installed outdoors or in wet locations, the edge of the wall plate coming in contact with the mounting surface must be sealed with a latex waterproof caulking to prevent water from entering the outlet box.

NOTE - SUITABLE FOR WET LOCATIONS WHEN COVERS (H) ARE SECURELY INSTALLED FLUSH TO CYLINDER.

CANOPY MOUNTING & WIRE CONNECTION ASSEMBLY STEPS:

1. A —————> B, C
2. D —————> E — 
3. F —————> B
4. G —————> F, B — 

C & E
(NOT FURNISHED)
(NO INCLUIDA)
(NON FOURNIE)



