

Cool Boot Cabinet Top Air Sealing Fitting

Panduit Part Number: CTG3X8

INSTALLATION INSTRUCTIONS

© Panduit Corp. 2010

Printed In USA

New Cable Installation

Step 1. Remove cabinet top cover from desired cabinet opening as shown in Fig. 1.



Fig. 1

Step 2. Install Cool Boot by pressing down on top of the outer edges of the fitting assembly as shown in Fig. 2.



Fig. 2

Step 3. Route cabling through the Cool Boot fitting and seal the hook and loop strip along the top edge of the fabric sleeve as shown Fig. 3.



Fig. 3

Step 4. Pull cinch tie tight around the cable bundle as show in Fig. 4. Wrap cinch tie around the cable bundle and attach to itself. If applicable, trim off excess cinch tie material.



Fig. 4

INSTALLATION INSTRUCTIONS

Retrofit Applications

Step 1a. Disengage the hook and loop cinch tie, as well as the hook and loop strips along the top edge and side of the fabric sleeve, as shown in Fig. 1a.



Fig. 1a

Step 2a. Open the fitting to accept the existing cable bundle by separating the end of the fitting assembly as shown in Fig. 2a. Place the fitting around the cable bundle.



Fig. 2a

Step 3a. Reattach the hook and loop side strip as well as the cinch tie. Align Cool Boot fitting with cabinet top bezel and insert by pressing down on the top of the outer edges of the fitting assembly as shown in Fig. 3a.



Fig. 3a

Step 4a. Reattach the hook and loop at the top edge of the fabric sleeve. Then, pull the hook and loop cinch tie tight around the cable bundle, as shown in Fig. 4a. Wrap cinch tie around the cable bundle and attach to itself. If applicable, trim off excess cinch tie material.



Fig. 4a

Instruction Sheet RW261

WORLDWIDE SUBSIDIARIES AND SALES OFFICES

17301 Ridgeland Avenue
Tinley Park, IL 60477-3901
Web Site: www.panduit.com

PANDUIT®
RACEWAY SYSTEMS DIVISION

Fax: 708-532-1811
Technical Support: 800-777-3300