

# PATCHRUNNER High Capacity Vertical Cable Manager Frame Assembly Instructions


## **INSTALLATION INSTRUCTIONS CM699**

© Panduit Corp. 2014

#### **PART NUMBERS**


VERTICAL CABLE MANAGEMENT			
7FT OPTIONS		8FT OPTIONS	
Dual	Single	Dual	Single
PEV12B1	PEVF12B1	PEV1296B1	PEVF1296B1
PEV10B1	PEVF10B1	PEV1096B1	PEVF1096B1
PEV8B1	PEVF8B1	PEV896B1	PEVF896B1
PEV6B1	PEVF6B1	PEV696B1	PEVF696B1






Number "2" (not shown in view) represents the right side of the manager when viewing from the front.


Step 2: Installing Center Brackets to Left Side of Manager (designated by "1")



# Step 3: Installing Center Brackets to Right Side of Manager (designated by "2")



## **Completed Assembly of Vertical Manager Frame**



Reference Panduit Instruction Sheet CM425 for rack, finger, and door installation instructions with 7ft managers. Reference Panduit Instruction Sheet CM513 for rack, finger, and door installation instructions with 8ft managers.

For instuctions in Local Languages and Technical Support:



E-mail: cs@panduit.com Fax: (708)444-6448