




**Power
Defense™**

**Circuit Breaker
Accessory**


**For PDG1
Frame**

DIN Rail Adapter - Three or Four Pole
Cat. No - PDG1XDIN34P
Style No - 66C1587G22
Quantity - 1

Package Contents:
1 Din Rail Adapter
2 EG Mounting Screws
(Longer screws)
2 G Mounting Screws
(shorter screws)



- Disconnect voltage and trip breaker before any installation or removal.
- Insert screws through opposite corners of breaker and thread a couple turns into the Din Rail Adapter.
- Clip Din Rail Adapter Tabs on bottom of din rail, and push breaker towards mounting panel until Adapter snaps on din rail.
- Thread screws down to mounting panel. Do not over-tighten.
- To remove, loosen screws away from mounting panel. Place screwdriver in Slot and pull up Slider to release from din rail.



IL012186EN H01




**Power
Defense™**

**Circuit Breaker
Accessory**

**For PDG1
Frame**

DIN Rail Adapter - Three or Four Pole
Cat. No - PDG1XDIN34P
Style No - 66C1587G22
Quantity - 1

Package Contents:
1 Din Rail Adapter
2 EG Mounting Screws
(Longer screws)
2 G Mounting Screws
(shorter screws)



- Disconnect voltage and trip breaker before any installation or removal.
- Insert screws through opposite corners of breaker and thread a couple turns into the Din Rail Adapter.
- Clip Din Rail Adapter Tabs on bottom of din rail, and push breaker towards mounting panel until Adapter snaps on din rail.
- Thread screws down to mounting panel. Do not over-tighten.
- To remove, loosen screws away from mounting panel. Place screwdriver in Slot and pull up Slider to release from din rail.



IL012186EN H01




**Power
Defense™**

**Circuit Breaker
Accessory**


**For PDG1
Frame**

DIN Rail Adapter - Three or Four Pole
Cat. No - PDG1XDIN34P
Style No - 66C1587G22
Quantity - 1

Package Contents:
1 Din Rail Adapter
2 EG Mounting Screws
(Longer screws)
2 G Mounting Screws
(shorter screws)



- Disconnect voltage and trip breaker before any installation or removal.
- Insert screws through opposite corners of breaker and thread a couple turns into the Din Rail Adapter.
- Clip Din Rail Adapter Tabs on bottom of din rail, and push breaker towards mounting panel until Adapter snaps on din rail.
- Thread screws down to mounting panel. Do not over-tighten.
- To remove, loosen screws away from mounting panel. Place screwdriver in Slot and pull up Slider to release from din rail.



IL012186EN H01




**Power
Defense™**

**Circuit Breaker
Accessory**

**For PDG1
Frame**

DIN Rail Adapter - Three or Four Pole
Cat. No - PDG1XDIN34P
Style No - 66C1587G22
Quantity - 1

Package Contents:
1 Din Rail Adapter
2 EG Mounting Screws
(Longer screws)
2 G Mounting Screws
(shorter screws)



- Disconnect voltage and trip breaker before any installation or removal.
- Insert screws through opposite corners of breaker and thread a couple turns into the Din Rail Adapter.
- Clip Din Rail Adapter Tabs on bottom of din rail, and push breaker towards mounting panel until Adapter snaps on din rail.
- Thread screws down to mounting panel. Do not over-tighten.
- To remove, loosen screws away from mounting panel. Place screwdriver in Slot and pull up Slider to release from din rail.



IL012186EN H01