Pass & Seymour Diegrand*

INSTALLATION INSTRUCTIONS

- Turn power off.
 - Pull 10/4 wires through box.
- 3. Mount box to surface using mounting lugs provided.
- Place a bead of caulk around the base of the box if mounting to an irregular surface.
- 5. Install fittings in remaining threaded openings.
- 6. Attach Flange to cover.
- 7. Attach the white (neutral) wire to the silver "W" terminal.
- Attach the black (hot) wire to the "Y" terminal.
- 9. Attach the red wire to the "X" terminal.
- 10. Attach the green (ground) wire to the green "G" terminal.
- 11. Fasten cover to box with the four screws provided.

CAUTION:

- Use only copper wire.
- Wiring and installation must comply with local and national electrical codes.
- DIRECT CONNECTION OF GENERATOR CURRENT AND LINE CURRENT COULD RESULT IN FIRE OR EXPLOSION. GENERATOR CURRENT AND LINE CURRENT MUST BE KEPT ISOLATED FROM EACH OTHER.
- 4. TO PREVENT FIRE HAZARDS AND OTHER DAMAGE, ALL ELECTRICAL WIRING, SO CKETS AND PLUGS MUST BE RATED TO HANDLE THE CURRENT AND VOLTAGE OF THE GENERATOR