


Part Number(s): ER4P23, ER4P29, ER4P2396, ER4P2996

© Panduit Corp. 2013


INSTALLATION INSTRUCTIONS

CM644


Required Hardware (included):



24X




24X




48X

Tools required for assembly and floor mounting:



Optional grounding method:





RCGBNJ*-sold separately



* denotes more than one variation of part number

Rack Assembly



① 2X





② 2X



③




Rack Assembly



4**5**

Rack Assembly


⑥



⑦



***Minimum 23 Ft-lbs. (31.2 N-m)**

Securing Rack to Floor

For Instructions in Local Languages
and Technical Support:

www.panduit.com/resources/install_maintain.asp

PANDUIT
www.panduit.com

E-mail:
cs@panduit.com

Fax:
(708) 444-6448