



## NLDX.E164862 - MOTOR CONTROLLERS, MAGNETIC

## Motor Controllers, Magnetic

See General Information for Motor Controllers, Magnetic

**SCHNEIDER ELECTRIC INDUSTRIES S A, DBA TELEMECANIQUE**

E164862

8001 Knightdale Blvd  
Knightdale, NC 27545 USA

**Investigated to ANSI/UL 508**

**Across-the-line contactors, AC motor or resistance air heating applications** Model(s) LC1-K followed by four, five or six numbers, may be followed by one or two letters or one or two numbers.

LC7-K followed by four, five or six numbers, may be followed by one or two letters or one or two numbers.

LP1-K followed by four, five or six numbers, may be followed by one or two letters or one or two numbers.

LP4-K followed by four, five or six numbers, may be followed by one or two letters or one or two numbers.

**Across-the-line reversing contactors, AC motor or resistance air heating application** Model(s) LC2-K, followed by up to nine additional suffixes

**Across-the-line starters (600 v max), combination motor controllers, integral 32 line consisting of** Model(s) LA1-LC1, followed by three numbers, may be followed by B, E, F, M, N, Q or U.

LB1-LC03\*##, LB6-LC03\*##, LD1-LC03H51, LD1-LC03XH51, LD4-LC03H51, LD4-LC03XH51, LD5-LC03H51, LD5-LC03XH51

**Across-the-line starters kits for reversing contactors LC2DT** Model(s) L1V

**Across-the-line starters, open or enclosed type** Model(s) LC1-D, followed by 09, 12, 16 or HN, 25 or LS, 40, 50 or RS, 63 or 80, followed by 3, 4, 8 or 9, followed by a letter, with or without A60, A65, A602, H7 or S002.

LC1-F, followed by F, G, H, J, K, L or X, followed by 22, 23, 24, 42, 43 or 44, may be followed by 04, 13, 31 or 40.

LC1-S followed by A, B, C, D, F, G, H or J, followed by 22, 23, 24, 42, 43 or 44, may be followed by a letter, may be followed by 13, 22, 31 or 40

LC2-D, followed by 09, 12, 16 or HN, 25 or LS, 40, 50 or RS, 63 or 80, followed by 3, 4 or 9, with or without a suffix letter, may be followed by A60, A65, A602, S008, S009 or H7.

LC2-SA9, -SB9, -SC9, -SD9, LP1-D or LP2-D, followed by 12, 16 or HN, 25 or LS, 50 or RS or 80, followed by 3, 4, 8 or 9, may be followed by a letter, may be followed by A60, A65 or H7.

LE2-F followed by F, G, H or J, followed by 43, may be followed by 0, followed by numbers.

**Across-the-line starters, open or enclosed type, connector kits** Model(s) LA9F103

**Across-the-line starters, open or enclosed type, may be factory or field installed** Model(s) LA1-LC###

**Across-the-line, open or enclosed type** Model(s) LC2-D, followed by 09 or 12, followed by 3, 4 or 9, with or without suffix S009.

**Across-the-line, open or enclosed type, may be factory or field installed on the D line device** Model(s) LA1-D04, LA1-D10, LA1-D11, LA1-D1111, LA1-D13, LA1-D20, LA1-D22, LA1-D40, LA2-D20, LA2-D22, LA2-D24, LA3-D20, LA3-D22, LA3-D24

**Adaptors for integral products, door Interlocks** Model(s) LA9LB###, LA9LC###

**AS-i communication modules** Model(s) ASILUFC51

**Connecting means for LC.D115 and 150 contactors** Model(s) LA9D11550, LA9D11560

**Contact modules** Model(s) LUA1C##, LUFN##

**Control removable connections** Model(s) LU9 followed by one or two letters, followed by one or two digits or by one letter and a digit.

**Control units** Model(s) LUCBT1BL, LUCDT1BL, LUCMT1BL

**Controller and multifunction motor protection relays** Model(s) LUTM10BL, LUTM20BL

**Limiter blocks** Model(s) LUALB1

**Magnetic motor controllers** Model(s) 792 followed by XBX, XCX or XDX, followed by 3, may be followed by C, may be followed by M4, may be followed by L, followed by 0A thru 240A, or 0D thru 220D, with or without a four digit suffix.

LA4SKE1\*

**Magnetic Motor Controllers** Model(s) LC.K...S335 or S207, followed by four, five or six digit numbers, followed by one or two letters and one or two digit numbers.

LC1D AC coil devices, followed by two digit numbers, followed by 8, may be followed by one digit number, followed by one or two letters, may be followed by a digit number.

**Magnetic motor controllers** Model(s) LC1SK0600\*#, LP1SK0600\*\*

RXM followed by 1, 2, 3 or 4, may be followed by A, 5 or G, may be followed by 1, 2, 3, B1, B2 or B3, followed by JD, BD, ED, FD, GD, MD, B7, E7, F7, P7 or U7.

**Magnetically operated contactors and reversing contactors, open type, ac or dc coil devices** Model(s) LC1DT followed by 60 or 80, followed by A, may be followed by 3 or 6, may be followed by 5, followed by two or three alpha-numeric digits.

T02DN13 may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric characters

T02DN23 may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric characters

**Magnetically operated contactors and reversing contactors, open type, reversing kit busbars** Model(s) LA9D65A69 (LA9D65A6 + LA9D65A9)

**Magnetically operated contactors and reversing contactors, open type, reversing kits** Model(s) LAD9R3 (LAD4CM + LA9D65A69)

**Magnetically operated contactors and reversing contactors, open type, three and four pole devices** Model(s) T02AN23 followed by one or two letters, may be followed by a number

T02BN13 followed by one or two letters, may be followed by a number

T02BN23 followed by one or two letters, may be followed by a number

T02CN13 followed by one or two letters, may be followed by a number

T02CN23 followed by one or two letters, may be followed by a number

**Magnetically operated contactors, open type, "Euronorme"** Model(s) LC1-F, followed by 115, 150, 185, 225, 265, 330, 400, 500, 630, 780, 800 or 6309, may be followed by 2, 4 or 6, may be followed by numbers or letters.

LC1-SB3, LC1-SC3

**Magnetically operated contactors, open type, may be factory or field installed on the D line device** Model(s) LA1-D04, LA1-D10, LA1-D11, LA1-D1111, LA1-D13, LA1-D20, LA1-D22, LA1-D40, LA2-D20, LA2-D22, LA2-D24, LA3-D20, LA3-D22, LA3-D24, LA9-D09906, LA9-D10, LA9-D101, LA9-D11, LA9-D16906

**Mechanical interlock kits for horizontally mounted LC2-D reverser** Model(s) LA9D11502

**Mechanical interlocks with incorporated electrical interlock contacts** Model(s) LA9-DXX02

**Modular system, downstream terminal blocks, for use with "Quickfit" system** Model(s) LAD-33

**Modular system, power connection modules, for use with "Quickfit" system** Model(s) LAD-34

**Modular system, power splitter boxes, for use with "Quickfit" system** Model(s) LAD-324 (4 starters are allowed)

**Motor starters** Model(s) LUB followed by 12 or 32, may be followed by 0.

LUS followed by 12 or 32, may be followed by 0.

**Motor starters, suitable for tap conductor application** Model(s) LUB32 may be followed by 0, may be followed by NR, may be followed by 00 or 0.

LUS or LUB, followed by 12 or 32, may be followed by 0.

**Overload protection units, may be factory or field installed on LD1, LD4 or LD5 devices** Model(s) LB1LD03\*##, LB6LD03\*##

**Power connection kits for horizontally mounted LC2-D reverser** Model(s) LA9D11569, LA9D11570, LA9D11571

**Reversing contactors** Model(s) LC2-D329

**Thermal overload fault signalizings** Model(s) LUFDA\*##, LUFDH\*##

**Vertical interlocks for F-line reverser** Model(s) LA4FX470, LA4FX471, LA4FX4X

**Vertical mechanical interlocks for F-Line reversers** Model(s) LA9-F followed by F, G, H or J, followed by 4, followed by F, G, H or J.

## Investigated to ANSI/UL 60947-1 and ANSI/UL 60947-4-1

**ac or dc coil devices** Model(s) LC1D followed by 40, 50, 65 or 80, followed by A, may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric digits and maybe followed by S304

LC1D50ANR followed by 0, 1 or 2, followed by a two or three alpha-numeric digits

LC1DT followed by 60 or 80, followed by A, may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric digits

LC2D followed by 40, 50, 65 or 80, followed by A, may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric digits and maybe followed by S304

**Accessory Connection Module** Model(s) LAD5C11, LAD5C12, LAD5C31, LAD5C32

**Accessory Manual Contact Holder Pusher** Model(s) LAD9FP3 for use with all models in this report as well as the models LC1-D150 and LC1-D115004 covered by E48539. Report dated 1997-11-10

**Accessory Open type** Model(s) Connection Module Cat. No LAD5C followed by 11 or 31 for Direct On Line Motor Starters and followed by 12 or 32 for Reversing Motor Starters.

IP20 Cover 4 poles Cat. No. LAD96580

Kit Cat. Nos. LADT3R1 for reversing contactor Cat. No. LC2DT203

Kit Cat. Nos. LADT9R1 and R1V for reversing contactors Cat. Nos. LC2DT.

Kit for power supply switching Cat. No. LAD9R3S

LA9D65A69, LAD4CM, LAD96566, LAD9R3, Mechanical interlock Cat. No. LAD4CM

Mounting Auxiliary Adaptor kit Cat. No. LAD4BB3

Reversing kit busbars Cat. No. LA9D65A69

**Across-the-line contactors** Model(s) LC1SKGC301 All references are followed by a letter and followed by a digit number or a letter

LC1SKGC310 All references are followed by a letter and followed by a digit number or a letter

LC1SKGC400

**Across-the-line motor starters (600 v max), combination motor controllers, integral 63 Line consisting of** Model(s) LD1 followed by LD followed by 030 or 130, may be followed by a letter or a group of two letters

LD4 followed by LD followed by 030 or 130, may be followed by a letter or a group of two letters

LD5 followed by LD followed by 030 or 130, may be followed by a letter or a group of two letters

**Across-the-line motor starters (600 v max), integral 18 Line consisting of** Model(s) LD1-LB followed by 030, may be followed by a letter or a group of two letters

LD5LB followed by 030, may be followed by a letter or a group of two letters

**Across-the-line reversing and nonreversing contactors, "Tesy offer"** Model(s) LC1-D115 may be followed by one digit number, followed by one suffix letter, followed by one digit number or one suffix letter

LC1-D150 may be followed by one digit number, followed by one suffix letter, followed by one digit number or one suffix letter

LC2-D115 may be followed by one digit number, followed by one suffix letter, followed by one digit number or one suffix letter

LC2-D150 may be followed by one digit number, followed by one suffix letter, followed by one digit number or one suffix letter

**Across-the-line reversing and nonreversing contactors** Model(s) LC1-D115 followed by two digit numbers, followed by one or two digit numbers, followed by one or two letters, followed by a digit number or a letter

LC1-D150 followed by two digit numbers, followed by one or two digit numbers, followed by one or two letters, followed by a digit number or a letter

**Across-the-line reversing contactors, AC motor or resistance air heating application** Model(s) LC2-K followed by up to nine additional suffixes

LP2-K, LP5-K or LC2, followed by additional alpha/numeric numbers or letters, may be followed by S335

LP2.K followed by a two to four digit number, LP5.K followed by a two to four digit number

**Across-the-line starters** Model(s) LC1-D323 may or may not be followed by A65 or A60

LC1-D329 may or may not be followed by A65 or A60

**Across-the-line starters kits for reversing contactor LC2DT203** Model(s) LADT3R1

**Across-the-line starters kits for reversing contactors** Model(s) LAD9R1, LAD9R1V

**Across-the-line starters kits for reversing contactors LC2DT** Model(s) LADT9R1

**Across-the-line starters, ac and dc coil devices** Model(s) LC1D or LC2D followed by two numbers, may be followed by a number, followed by one or two letters, may be followed by a number, and may be followed by S182 or S335 or S207

LC1DT followed by two numbers, may be followed by a number, followed by one or two letters, may be followed by a number.

LC2DT followed by two numbers, may be followed by a number, followed by one or two letters, may be followed by a number.

**Across-the-line starters, ac coil devices** Model(s) DPE, followed by two numbers, may be followed by a number, followed by one or two letters, may be followed by a number.

**Across-the-line starters, open or enclosed type** Model(s) LC2-F followed by F, G, H, or J: followed by 43: followed by numbers

LE2-F followed by F, G, H, or J: followed by 43: may be followed by 0, followed by numbers

**Across-the-line starters, open or enclosed type** Model(s) LC1-D followed by 16 or HN, 25 or LS, followed by 3, 4, 8, or 9, may or may not be followed by a suffix letter with or without A60, A65, A602, S002 or H7

LC2-D followed by 16 or HN, 25 or LS, followed by 3, 4, or 9, may or may not be followed by a suffix letter, with or without final Suffix A60, A65, A602 or H7

**Adaptors for integral products** Model(s) LA9LB960 for connection of field wiring to Cat. No. LA9LB930

**Adaptors for integral products, bus bars** Model(s) LA9LB930 device for connection of Cat. LD.LB devices together from a single source

**Adaptors for integral products, door Interlocks** Model(s) LA9LB followed by three numbers, LA9LC followed by three numbers

**Alarm modules** Model(s) LUFW10

**AS-i communication modules** Model(s) ASILUF51, ASILUFC5

**Auxiliary Contact Block** Model(s) LA1-LC followed by three digits, may be followed by B, E, F, M, N, Q, or U

**Auxiliary contact blocks** Model(s) LA9D09906, LA9D16906

**Busbar kits** Model(s) LA9D65A6, LA9D65A9

**Communication Module** Model(s) LUL032

**Communication modules** Model(s) LULC09

**Connecting means for LC.D115 and 150 contactors** Model(s) LA9-D11550, LA9-D11560

**Connection Module** Model(s) LAD5C followed by 11 or 31 for Direct On Line Motor Starters and followed by 12 or 32 for Reversing Motor Starters

**Contact modules** Model(s) LUA1C followed by two digits, LUFN followed by two digits

**Control circuit filter accessories** Model(s) LUA4F11, LUA4F12

**Control pre-wired accessories** Model(s) LU9, followed by one or two letters followed by one or two digits or by one letter and a digit, followed by C

**Control removable connections** Model(s) LU9 followed by one or two letters, followed by one or two digits or by one letter and a digit

**Control units** Model(s) LUCA followed by a letter and a digit or by a digit and a letter or by two digits, followed by one or two letters

LUCB followed by a letter and a digit or by a digit and a letter or by two digits, followed by one or two letters

LUCB T1 followed by BL

LUCB followed by a letter and a digit or by a digit and a letter or by two digits, followed by one or two letters

LUCD followed by a letter and a digit or by a digit and a letter or by two digits, followed by one or two letters

LUCM followed by a letter and a digit or by a digit and a letter or by two digits, followed by one or two letters

LUCM T1 followed by BL

**Controller and multifunction motor protection relays** Model(s) LUT M followed by 10 or 20, followed by BL

**Door interlock mechanisms** Model(s) LU9AP00, LU9AP11, LU9AP12

**Downstream terminal blocks** Model(s) LAD-331

**Horizontal interlocks for F-line reverser** Model(s) LA9FX970

**Limiters blocks** Model(s) LUA LB1

**Low voltage ride-through modules** Model(s) LADLVRT120V, LADLVRT208V, LADLVRT24V

**Magnetic motor controllers** Model(s) LA4SKE1 followed by a letter

LC1SK0600 followed by a letter and a digit number

LC1SKGC200, LP1SK0600 followed by two letters

**Magnetically latched 2, 3 or 4-pole, 2 or 3-phase AC motor controllers, open type** Model(s) CR1-F All catalog numbers may be followed by a three or four digit number, may be followed by S011, may be followed by a single numeral, may be followed by additional suffix letters or numbers, Cat. No. LA9F103

T02XN13 where X may be E, F, G, H, or J. All catalog numbers may be followed by a three or four digit number, may be followed by S011, may be followed by a single numeral, may be followed by additional suffix letters or numbers, Cat. No. LA9F103

**Magnetically operated contactors** Model(s) LC.K, followed by four, five or six digit numbers may be followed by one or two letters and one or two digit numbers

**Magnetically operated contactors and reversing contactors, open type, ac or dc coil devices** Model(s) LC1D or LC2D, followed by 40, 50 or 65, followed by A, may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric digits.

T02DN13 may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric characters

T02DN23 may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric characters

**Magnetically operated contactors and reversing contactors, open type, IP20 Cover 4 poles** Model(s) LAD96580

**Magnetically operated contactors and reversing contactors, open type, kits for power supply switching** Model(s) LAD9R3S

**Magnetically operated contactors and reversing contactors, open type, mounting auxiliary adaptor kits** Model(s) LAD4BB3

**Magnetically operated contactors and reversing contactors, open type, three and four pole devices** Model(s) T02AN13, followed by one or two letters, may be followed by a number

**Magnetically operated contactors, open type, "Euronorme"** Model(s) LC1-D followed by a letter, followed by K, followed by two digits, may be followed by a suffix letter and number

LC1-SD3

**Magnetically operated contactors, open type, Tesys Offer** Model(s) LC2-D115 followed by two digit numbers, followed by one or two digit numbers, followed by one or two letters, followed by a digit number or a letter

LC2-D150 followed by two digit numbers, followed by one or two digit numbers, followed by one or two letters, followed by a digit number or a letter

**Magnetically operated three or four pole contactors, open type** Model(s) LP.K or LC7K, followed by four, five or six digit numbers, may be followed by one or two letters and one or two digit numbers

**Mechanical interlock kits for horizontally mounted LC2-D reverser** Model(s) LA9-D11502

**Mechanical interlocks with incorporated electrical interlock contacts** Model(s) LA9-D followed by two digit numbers, followed by 02

**Modbus communication modules** Model(s) LULC031, LULC032, LULC033, LULC07, LULC08, LULC15

**Modular system, control connection modules, for use with "Quickfit" system** Model(s) APP-2D1, APP-2D1D, APP-2D2, APP-2D2D

**Modular system, control splitter boxes, for use with "Quickfit" system** Model(s) APP-2R2C, APP-2R2H3, APP-2R2H4, APP-2R4C, APP-2R4H3, APP-2R4H4

**Modular system, for use with "Quickfit" system, ASI quick fit modules** Model(s) ASI followed by C or E, followed by R, followed by 2 or 4, may be followed by E

**Modular system, power and control splitter boxes, for use with "Quickfit" system** Model(s) APP-2R2E, APP-2R2H1, APP-2R2H2, APP-2R4E, APP-2R4H1, APP-2R4H2

**Modular system, power splitter boxes, for use with "Quickfit" system** Model(s) LAD-32 followed by 2 or 4 (number of allowed starters)

**Modular system, upstream terminal blocks, for use with "Quickfit" system** Model(s) LAD-3B

**Motor Controllers, Magnetic, Relay** Model(s) 92 followed by S, followed by 7 or 11, followed by A or D, followed by 22D, may be followed by up to three numbers or blank, may be followed by up to four numbers

RPF followed by 2A or 2B, followed by B, E, F, J, or P, followed by D OR 7

W92 followed by S, followed by 7 or 11, followed by A or D, followed by 22D, may be followed by up to three numbers or blank, may be followed by up to four numbers

**Motor starters** Model(s) LUS followed by 12 or 32, may be followed by 0, may be followed by NR, may be followed by 00 or 0

**Motor starters, suitable for tap conductor application** Model(s) LUB followed by 12 or 32, may be followed by 0, may be followed by NR, may be followed by 0 or 00

**Open** Model(s) LC1-F followed by a letter followed by 22, 23, 24, 42, 43 or 44, followed or not by a suffix letter, followed or not by two or three digit numbers

LC1-S followed by a letter, followed by 22, 23, 24, 42, 43 or 44, followed or not by a suffix letter, followed or not by two or three digit numbers

LE1-D 09 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE1-D 12 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE1-D 16 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE1-D 25 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE1-D 32 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE1-D 50 followed by 3 or 9, followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE1-D 63 followed by 3 or 9, followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE1-D followed by 09, 12, 16 or HN, 25 or LS, followed by 3 or 4, followed by 0, 4, or 5, with or without 1, with or without a suffix letter, followed by two suffix numbers followed by a Suffix H7

LE2-D 09 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE2-D 12 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE2-D 16 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE2-D 25 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE2-D 32 followed by 3 or 9: followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE2-D 50 followed by 3 or 9, followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

LE2-D 63 followed by 3 or 9, followed by one or two letters, followed by 06 or 07, may be followed by 01 through 15, may be followed by 12, 24, 48 or 60

**Open magnetically operated 3 or 4 phase alternating current reversing controllers** Model(s) LA9F225 followed by 76, 77 or 82

**open or enclosed magnetically operated three or four pole, 3 phase, alternating-current motor controllers with or without overload relays** Model(s) LC1-D followed by 40, 50 or RS, 63 or 80 followed by 3, 4, 8 or 9, may or may not be followed by a suffix letter with or without A65

LC2-D followed by 09, 12, 16, 25, 40, 50 or RS, 63 or 80, followed by 3, 4 or 9, may or may not be followed by a suffix letter, may or may not be followed by A60 or S008, A602 or S009 with or without Suffix H7

LC2-SA9 may or may not be followed by 12, 16 or 25 followed by 3, 4, 8 or 9, followed by a suffix letter, Suffix H7

LC2-SB9 may or may not be followed by 12, 16 or 25 followed by 3, 4, 8 or 9, followed by a suffix letter, Suffix H7

LC2-SC9 may or may not be followed by 12, 16 or 25 followed by 3, 4, 8 or 9, followed by a suffix letter, Suffix H7

LC2-SD9 may or may not be followed by 12, 16 or 25 followed by 3, 4, 8 or 9, followed by a suffix letter, Suffix H7

LE1-D followed by 40, 50 or RS, 63 or 80, followed by 3 or 4, followed by 0, 4 or 5, with or without 1, with or without a suffix letter, followed by two suffix numbers followed by a Suffix H7

LP1-D12 followed by 3, 4, 8 or 9, followed by a suffix letter, with or without Suffix H7

LP1-D16 followed by 3, 4, 8 or 9, followed by a suffix letter, with or without Suffix H7

LP1-D25 followed by 3, 4, 8 or 9, followed by a suffix letter, with or without Suffix H7

LP1-D50 followed by 3, 4, 8 or 9, followed by a suffix letter, with or without Suffix H7

LP1-D80 followed by 3, 4, 8 or 9, followed by a suffix letter, with or without Suffix H7

LP1-HN followed by 3, 4, 8 or 9, followed by a suffix letter, with or without Suffix H7

LP1-LS followed by 3, 4, 8 or 9, followed by a suffix letter, with or without Suffix H7

LP2-D may or may not be followed by 12, 16 or 25 followed by 3, 4, 8 or 9, followed by a suffix letter, Suffix H7

**Open type magnetic and thermal overload protection and auxiliary contact blocks** Model(s) LA1 followed by 03P, followed by a two-digit number, and auxiliary contact blocks, Cat. Nos. LA1, LB, followed by a group of three letters

LB followed by 03P, followed by a two-digit number, and auxiliary contact blocks, Cat. Nos. LA1, LB, followed by a group of three letters

LB03P followed by a two-digit number, and auxiliary contact blocks, Cat. Nos. LA1, LB, followed by a group of three letters

LB1 followed by 03P, followed by a two-digit number, and auxiliary contact blocks, Cat. Nos. LA1, LB, followed by a group of three letters

**Open type magnetically operated 2, 3, or 4-pole, 2 or 3 phase AC motor controllers** Model(s) LC1-F All catalog numbers may be followed by a three or four digit number, may be followed by S011, may be followed by a single numeral, may be followed by additional suffix letters or numbers

LC1-F1000

**open type magnetically operated across-the-line motor starters** Model(s) LB1-LC03 followed by a letter, followed by two digits

LB6-LC03 followed by a letter, followed by two digits

LD1-LC.30 with or without a letter, LD4-LC.30 with or without a letter, LD5-LC.30 with or without a letter

**Open type magnetically operated three or four pole contactors, "Tesys offer"** Model(s) LC1-D40-004 followed by the coil voltage code denoted by a suffix letter and a digit, maybe followed by a letter

LC1-D40-008 followed by the coil voltage code denoted by a suffix letter and a digit, maybe followed by a letter

LC1-D40-6 followed by the coil voltage code denoted by a suffix letter and a digit, maybe followed by a letter

LC1-D65-004 followed by the coil voltage code denoted by a suffix letter and a digit, may be followed by a letter

LC1-D65-008 followed by the coil voltage code denoted by a suffix letter and a digit, may be followed by a letter

LC1-D65-6 followed by the coil voltage code denoted by a suffix letter and a digit, may be followed by a letter

LC1-D80 004 followed by the coil voltage code denoted by a suffix letter and a digit, may be followed by a letter

LC1-D80 008 followed by the coil voltage code denoted by a suffix letter and a digit, may be followed by a letter

LC1-D80 6 followed by the coil voltage code denoted by a suffix letter and a digit, may be followed by a letter

LC1-D80 followed or not by a digit, followed by suffix letters

**open type magnetically operated three or four pole contactors, "Tesys offer"** Model(s) LC1-D95 followed by the coil voltage code denoted by a suffix letter and a digit, may be followed by a letter

**Open type magnetically operated three or four pole contactors** Model(s) LC1-D09 followed by two, three or four digits, may be followed by a suffix letter

LC1-D12 followed by two, three or four digits, may be followed by a suffix letter

LC1-D18 followed by two, three or four digits, may be followed by a suffix letter

LC1-D25 followed by two, three or four digits, may be followed by a suffix letter

LC1-D32 followed by two, three or four digits, may be followed by a suffix letter

LC1-D40 followed by two digits, may be followed by a suffix letter or number

LC1-D65 followed by two digits may be followed by a suffix letter or number

LC1-D80 followed by two digits, may be followed by a suffix letter, or number

LP1-D09 followed by two three or four digits, may be followed by a suffix letter

LP1-D12 followed by two three or four digits followed by two three or four digits, may be followed by a suffix letter

LP1-D18 followed by two digits, may be followed by a suffix letter

LP1-D25 followed by two, three or four digits followed by two, three or four digits, may be followed by a suffix letter

LP1-D32 followed by two, three or four digits, may be followed by a suffix letter

LP1-D40 followed by two digits, may be followed by a suffix letter, may be followed by S207.

LP1-D80 followed by two digits may be followed by a suffix letter

**Open type magnetically operated three pole contactors, "Tesys offer"** Model(s) LC1-D50 followed or not by a digit, followed by suffix letters, may be followed by S207.

LC1-D50 may be followed by 6 followed by the coil voltage code denoted by a suffix letter and a digit, may be followed by a letter

LC1-D65 followed or not by a digit, followed by suffix letters, may be followed by S207.

**Open type magnetically operated three pole contactors** Model(s) LC1-D50 followed by two digits, may be followed by a suffix letter or number

LP1-D50 followed by two digits, may be followed by a suffix letter, may be followed by S207.

LP1-D65 followed by two digits, may be followed by a suffix letter, may be followed by S207.

**Open type three or four pole contactors, "Tesys offer"** Model(s) LC2-D followed by two digit numbers may be followed by 3 digit numbers, followed by a suffix letter and a digit number

**Open type three or four pole contactors** Model(s) LA9-D followed by two digit numbers followed by 978

**Open type, magnetically operated three or four pole contactors, "Tesys offer"** Model(s) LC1-D40 followed or not by a digit, followed by suffix letters, may be followed by S207.

**Open type, Motor controllers** Model(s) 750 followed XBXR or XCXR, maybe followed by C, maybe followed by M4 and/or L, followed by 6A, 12A, 24A, 48A, 120A, 230A, 240A, 6D, 12D, 24D, 48D, 60D, 110D, 125D or 220D, maybe followed by additional numbers

781, 782, 783 or 784 followed by XAXR, XBXR, XCXR or XDX, may be followed by C, may be followed by T and/or M4 and/or L, followed by 6A, 12A, 24A, 48A, 120A, 230A, 240A, 6D, 12D, 24D, 48D or 110D, 220D may be followed by additional numbers

788 followed XBXR or XCXR, maybe followed by 69, maybe followed by C or C1, maybe followed by M4 and/or L, followed by 6A, 12A, 24A, 48A, 120A, 230A, 240A, 12D, 24D, 48D, 60D, 110D, 125D or 220D, maybe followed by additional numbers.

DPE dc coil devices followed by two digit numbers may be followed by one digit number, followed by one or two letters, may be followed by a digit number.

DPE dc coil devices, followed by two digit numbers may be followed by one digit number, followed by one or two letters, may be followed by a digit number

LC1D ac or dc coil devices, followed by 40, 50 or 65, followed by A, may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric digits.

LC1D DC coil devices followed by two digit numbers, followed by 8, may be followed by one digit number, followed by one or two letters, may be followed by a digit number. and may be followed by S335 or S207

LC1D dc coil devices, followed by two digit numbers may be followed by one digit number, followed by one or two letters, may be followed by a digit number

LC1D50ANR ac or dc coil devices, followed by 0, 1 or 2, followed by a two or three alpha-numeric digits.

LC1DT ac or dc coil devices followed by 60 or 80, followed by A, may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric digits

LC1DT DC coil devices, followed by two digit numbers, may be followed by one digit number, followed by one or two letters, may be followed by a digit number

LC1DT followed by two digit numbers, may be followed by one digit number, followed by one or two letters, may be followed by a digit number. and may be followed by S335 or S207

LC2D ac or dc coil devices, followed by 40, 50 or 65, followed by A, may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric digits.

LC2D followed by two digit numbers may be followed by one digit number, followed by one or two letters, may be followed by a digit number

LC2DT DC coil devices followed by two digit numbers, may be followed by one digit number, followed by one or two letters, may be followed by a digit number. and may be followed by S335 or S207

LC2DT DC coil devices, followed by two digit numbers, may be followed by one digit number, followed by one or two letters, may be followed by a digit number

RPM followed by 1 or 2, followed by 1, 2, or 3, followed by JD, BD, ED, FD, MD, B7, E7, F7, P7 or U7.

RUM followed by C or F, followed by 2 or 3, followed by 1, 2 or 3, followed by E7, F7, P7, B7, FD, GD, JD, MD, BD, ED or ND, maybe followed by additional numbers.

T02AN13, T02BN13, T02CN13, T02AN23, T02BN23, and T02CN23 followed by one or two letters, may be followed by a number.

T02DN13 and T02DN23, may be followed by 3 or 6, may be followed by 5, followed by a two or three alpha-numeric characters.

**Open, magnetically operated contactors** Model(s) LC1-D09-00 may be followed by a suffix letter

LC1-D12-00 may be followed by a suffix letter



LC1-D18-00 may be followed by a suffix letter

LC1-D25-00 may be followed by a suffix letter

LC1-D32-00 may be followed by a suffix letter

LC1-D95 followed by two digit numbers, may be followed by a suffix letter

**Overload protection units, may be factory or field installed on LD1, LD4 or LD5 devices** Model(s) LB1LD03 followed by a letter, followed by two-digits

LB6LD03 followed by a letter, followed by two-digits

**Parallel bus splitters** Model(s) LU9G02, LU9G03, LU9GC3, LU9GC7

**Parallel wiring modules** Model(s) LUFC00

**Pilot device kits** Model(s) LA9BA followed by 01 through 20, followed by W, may be followed by 12, 24, 48 or 60

**Power connection kits for horizontally mounted LC2-D reverser** Model(s) LA9-D11569, LA9-D11570, LA9-D11571

**Power connection modules** Model(s) LAD-341

**Power connections** Model(s) LA9F15076, LA9F15077, LA9F15082, LA9F80076, LA9F80082, LA9FX976, LA9FX977, LA9FX982

**Reverser blocks** Model(s) LU2M followed by 32 or B0, followed by one or two letters

**Reverser wiring kits** Model(s) LA9-D##69 followed by two digit numbers followed by 69 for motor control or followed by 70 for distribution circuit control

LA9-D##70 followed by two digit numbers followed by 69 for motor control or followed by 70 for distribution circuit control

**Reversing contactors** Model(s) LC2.K, followed by up to nine suffixes.

LC2F followed by three or four digit numbers, followed or not by a digit number, followed or not by a suffix letter and a digit number

LE2F followed by three or four digit numbers, followed or not by a digit number, followed or not by a suffix letter and a digit number

**Reversing kit** Model(s) LAD9R3 (Cat. No. LAD4CM + Cat. No. LA9D65A69)

**Reversing motor starters** Model(s) LU2S followed by 12, 32, A0 or B0, followed by one or two letters

**Reversing motor starters, suitable for tap conductor application** Model(s) LU2B followed by 12, 32, A0 or B0, followed by one or two letters

**Side mounted contact modules** Model(s) LUA8E20

**Side reverser blocks** Model(s) LU6M followed by 32 or B0, followed by one or two letters

**Thermal overload fault signalizings** Model(s) LUFD followed by a letter followed by 2 digits

**Vertical interlocks for F-line reverser** Model(s) LA9FX470, LA9FX471, LA9FX4X

**Vertical mechanical interlocks for F-Line reversers** Model(s) LA9-F followed by F, G, H, or J: followed by 4: followed by F, G, H, or J

**Visualization modules** Model(s) LUFV2

# - Represents any number from 0 thru 9.

\* - Represents a letter.

[Click here to view the Colombia Market Access Certification](#)

Last Updated on 2019-01-24

---

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2019 UL LLC"