











A(0.400)




01	Module / Boitier	 NW
02	Captive / Prisonnier	
03	Spring / Ressort	
04	Contact actuator / Poussoir de contact	
05	Mobile bridge / Pont mobile	
06	Spring / Ressort	
07	Fixed contact assembly / Assemblage contact fixe	
08	Stirrup screw / Vis étrier	
09	Return cam / Came de rappel	 GREASE
10	S/A Lever / S/E Levier	
11	Circlip / Circlip	

See assembly JOYSTICK XKB* movie NVE8420900

12	Handle support / Support poignée	
13	Circlip / Circlip	
14	Sheath / Fourreau	
15	Friction washer / Rondelle de friction	
16	Main cam / Came principale	 GREASE
17	Axle / Axe	
18	Support / Support	
19	Cam / Came	 GREASE
20	Pin / Goupille	
21	Self locking ring / Anneau "Self locking"	
22	Flange support / Bride support	 GREASE
23	Zero position pavement / Pavé position zéro	 GREASE
24	Left position pavement / Pavé position gauche	 GREASE
25	Right position pavement / Pavé position droite	 GREASE

26	Protection cover / Cache de protection	 GREASE
27	Sector gear / Secteur denté	
28	Screw / Vis	
29	Spring / Ressort	
30	Plunger / Poussoir	
31	Nozzle / Embout	
32	Stirrup screw support / Support vis étrier	
33	Stirrup / Etrier	
34	Screw / Vis	
35	Screw / Vis	
36	Screw / Vis	
37	Grid / Grille	

38	Screw / Vis	
39	Seal / Joint	
40	Screw / Vis	
41	Bellow / Soufflet	
42	Bottom handle / Poignée bas	
43	Upper handle / Poignée haut	