NKCR.E164353 - AUXILIARY DEVICES

Auxiliary Devices

See General Information for Auxiliary Devices

SCHNEIDER ELECTRIC INDUSTRIES S A, DBA TELEMECANIQUE

E164353

8001 Knightdale Blvd Knightdale, NC 27545 USA



Investigated to ANSI/UL 508

Accessories for Handy Box Model(s) ZBR M2

Accessories, add-on square trims Model(s) ZB5-AZ31

Accessories, boots Model(s) ZB2-BPX+, ZBPX+, ZBWX+

Accessories, legend holders, legend plates, metal and plastic guards Model(s) ZBC-YX+, ZBC-ZX+, ZBYX+, ZBZX+

Accessories, padlockable flaps Model(s) ZB4-BZ6X+

Accessories, plugs Model(s) ZB4-SZ3, ZB5-SZ3, ZB5-SZ5

Accessory kits Model(s) ZB6-YXXX+

Accessory kits (16 mm line), "Class 9001" Model(s) Z203, Z204, Z205, Z206, Z207, Z208, Z209, Z210, Z211, Z212, Z214, Z215, Z216

Adapters Model(s) LA7K0064

Analogue joystick controllers Model(s) XDALXXXXX+, XDAVXXXXX+

AS-interface fail safe monitors Model(s) ASiSAFEMON1, ASiSAFEMON1B, ASiSAFEMON2, ASiSAFEMON2B

Auxilary Device Modular Tower Light, Accessory Light Unit Model(s) XVUC29P

Auxilary Device Modular Tower Light, Terminal Block Unit Model(s) XVUZ03, XVUZ04

Auxilary Device Modular Tower Light, Voice Unit Model(s) XVUC9V, XVUC9VP

Auxiliary Device Self Powered Switch and Receiver, Package Model(s) XB4 R followed by F, M, G, E or C, followed by A, B, C or D, followed by two or three digits.

XB5 R followed by F, M, G, E or C, followed by A, B, C or D, followed by two or three digits.

Auxilary Device Self Powered Switch and Receiver, Rope Pull Switch Model(s) ZBR P, followed by 1 or 2

Auxilary Device Enclosed Model(s) XVUC43, XVUC44, XVUC45, XVUC46, XVUC47, XVUC48, XVUZ100T, XVUZ250T, XVUZ400T

Auxilary Device Enclosed Accessories for flush kit: Metal bezel, earthplates Model(s) ZB4 BZ, followed by three digit number.

Auxilary Device Enclosed Boots (accessories) Model(s) ZB2-BP followed by any alphanumeric number., ZBD followed by any alphanumeric number., ZBG followed by any alphanumeric number.

Auxiliary Device Enclosed Hand held Remote controller, Control panel base station Model(s) ZARB followed by 12 or 18, followed by H or W. May be followed by M.

Auxiliary Device Enclosed Hand held Remote controller, Package of Remote and Control panel base Model(s) XAR followed by S or SK, followed by 8D, 8L or 12D, followed by 12W, 12H, 18W or 18H.

Auxiliary Device Enclosed Hand held Remote controller, Remote Model(s) ZART followed by 8D, 8L or 12D. May be followed by M.

Auxiliary Device Enclosed Limit Switch Model(s) XCR followed by A, B, E, or F, followed by 1 or 5, followed by 1, 2, 5, 7, or 8, may be followed by 1, may be followed by H7 or S, may be followed by up to five digits.

XCRT followed by 1 or 2, followed by 15, may be followed by H7 or S, may be followed by up to five digits.

Auxiliary Device Enclosed Operators Model(s) ZB4-B, ZB5-A or ZB5-C followed by A, B, C, D, F, G, H, J, K, L, P, R, S, T or X, followed by 1, 2, 3, 4 5, 6, 7, 8 or 9, followed by one, two, three or four numbers, may be followed by M and/or 7.

Auxilary Device Enclosed Plastic bezel, plastic bezel label support, plastic brace., Cat. No. Model(s) ZB5 AZ followed by three digit number.

Auxilary Device Open type Model(s) XB5AS84449, XB5AS86449B4

Auxilary Device Open type Contact blocks Model(s) ZBE, followed by 0, 1 or 2 followed by two digit number, may be followed by 6 or 6P, may be followed by 3, 5 or 9, may be followed by J

Auxilary Device Open type Hand held Remote controller, "Field bus Comm Analog card" Model(s) ZARCFBA01

Auxilary Device Open type Hand held Remote controller, "Network communication card" Model(s) ZARCIOT01

Auxilary Device Open type LED pilot light transcient voltage suppressors subunit Model(s) ZBZ VG or ZBZ VM

Auxilary Device Open type Tower Light Model(s) XVGU3SHAG, XVGU3SHAV, XVGU3SWG, XVGU3SWV

Auxiliary contact blocks, open type Model(s) LN1-DN11, LN1-DN116

Auxiliary Devices, "Modular Tower Light, Accessory Flash Light Unit" Model(s) XVUC63, XVUC64, XVUC65, XVUC66, XVUC67, XVUC68

Auxiliary Devices, "Terminal Block Unit" Model(s) XVUZ00

Auxiliary devices Model(s) LA4SKC1Y+, LA4SKE1Y+, XPSAXE5120C, XPSAXE5120P, XPSBCE3110C, XPSBCE3110P, XPSBCE3410C, XPSBCE3410C, XPSBCE3710P

Auxiliary devices, limit switches Model(s) XCMU21*

Auxiliary switch units, open type Model(s) LA1-DC22, LA1-DC223, LA1-DC226, LAD-C223, LAD-C223, LAD-C226

Auxillary Device: Modular Tower Light, Accessory Buzzer Unit Model(s) XVUC9S, XVUC9SQ

Auxillary Device: Modular Tower Light, Accessory Extender Unit Model(s) XVUC020, XVUC020Q

Auxillary Device: Modular Tower Light, Accessory Flexible Unit Model(s) XVUZ06

Auxillary Device: Modular Tower Light, Accessory Light Unit Model(s) XVUC23, XVUC24, XVUC25, XVUC26, XVUC27, XVUC28, XVUC29

Auxillary Device: Modular Tower Light, Power Unit Model(s) XVUC21B, XVUC21BQ, XVUC21M, XVUC21MP, XVUC21MQP

Auxillary Device: Modular Tower Light, Terminal Block Unit Model(s) XVUZ01, XVUZ01Q, XVUZ02Q, XVUZ02Q, XVUZ05, XVUZ400, XVUZ800

Auxillary Device: Self powered switch and Receiver, Pushbutton Model(s) ZB4 R followed by T, M or Z, followed by A, or C, followed by one or three numbers.

ZB5 R followed by T, M or Z, followed by A, or C, followed by one or three numbers.

Base provided adapters Model(s) LA7-D

Biometric switches Model(s) XB5-S followed by 1, 2, 3, 4 or 5, followed by B, followed by 2, followed by L with a number or

followed by M12.

Bodies for limit switches Model(s) ZCD followed by two numbers, may be followed by F, G, M, N or P, followed by two numbers.

ZCM-D followed by a two digit number, may be followed by C, L or M, followed by a one to five digit number.

ZCP followed by two numbers, may be followed by F, G, M, N or P, followed by two numbers.

ZCT followed by two numbers, may be followed by F, G, M, N or P, followed by two numbers.

Cable entry supports Model(s) ZC-DEFXX+, ZC-DEGXX+, ZC-DENXX+, ZC-DEPXX+, ZC-PEFXX+, ZC-PEGXX+, ZC-PENXX+, ZC-PEXX+, ZC-PEXX+,

Cam-operated master switches Model(s) XKBAXXXXX+, XKBEXXXXX+

Coil suppressors Model(s) LAD4, followed by two or three letters and control wiring kits.

LAD4. followed by two or three letters and control wiring kits.

LAD4BB, may be followed by V and a letter.

Connectors Model(s) ZCM-CXXLXX+

Contact blocks Model(s) ZB2-BE-201 (h), ZB2-BE-202 (h), ZB2-BE101, ZB2-BE1016, ZB2-BE1019, ZB2-BE1026, ZB2-BE1026, ZB2-BE1029, ZB6-E1B, ZB6-E1E, ZB6-E2B, ZB6-E2E, ZB6-Z1B, ZB6-Z1E, ZB6-Z2B, ZB6-Z2E

ZBE, followed by 1 or 2 followed by two numbers, may be followed by 6 or 6P, may be followed by 3, 5 or 9.

ZEN-L1111

Contact blocks with or without pilot lights (16 mm line), "Class 9001" Model(s) DU01, DU02, DU10, DU11, DU20, DUB01, DUB02, DUB10, DUB11, DUB20, DUF01, DUF02, DUF11, DUF20, DUFB01, DUFB02, DUFB10, DUFB11, DUFB20, DUFR01, DUFR02, DUFR10, DUFR11, DUFR20

Contact subunits Model(s) ZB4-BZXXX+, ZB4-BZXXXX+, ZB5-AZXXX+, ZB5-AZXXXX+, ZB5-AZXXXX+, ZBE501, ZBE501, ZBE502, ZBE5023, ZBE503, ZBE503, ZBE504, ZBE504, ZBE505, ZBE5053, ZD4-PAXXX+, ZD5-PAXXX+, ZD6-PAXXX+

Control stations Model(s) XAL-D or XAL-K, followed by 1, 2, 3, 4 or 5, followed by a two digit number, may be followed by a letter and/or a number, followed by H7.

XAL-D01H7, XAL-D02H7, XAL-D03H7, XAL-D04H7, XAL-D05H7, XAL-K01H7, XAL-K02H7, XAL-K03H7, XAL-K04H7, XAL-K05H7

Electromechanical output relays Model(s) RE-7 followed by C, M, P, R, T or Y, followed by A, B, D, E, L, M, P, R, V or Y, followed by 11, 12 or 13, followed by BU or MW.

RE-8 followed by C, P, R, T or Y, followed by A, B, D, E, G, L or T, followed by 0, 1, 2, 3, 4 or 5, followed by 1 or 2, followed by B, F or Q, may be followed by U.

RM4J followed by A, followed by 0 or 3, followed by 1 or 2, followed by B, F, M, Q or MW.

RM4L followed by A or G, followed by 0 or 3, followed by 1 or 2, followed by B, F, M, Q or MW.

RM4T followed by A, G, R or U, followed by 0, 2 or 3, followed by 0, 1, 2, 3, 4.

RM4U followed by A or B, followed by 0 or 3, followed by 1, 2, 3, 4 or 5, may be followed by B, F, M, Q or MW.

Enabling switches, grip type Model(s) XY2-AU1, XY2-AU2

Enclosures Model(s) XAL-B followed by 01, 02, 03, 04 or 05, followed by 1, followed by two numbers, may be followed by additional digits.

XAL-J followed by 01, 02, 03, 04 or 05, followed by 1, followed by two numbers, may be followed by additional digits.

XAP-G followed by two thru five numbers., XAP-M followed by two thru five numbers.

Field additions Model(s) D09906 (c), D09980 (c), D16906 (c), LA1-D04 (a), LA1-D10 (a), LA1-D11 (a), LA1-D1111 (a), LA1-D13 (a), LA1-D20 (a), LA2-D22 (a), LA2-D22 (a), LA2-D24 (a), LA3-D20 (a), LA3-D20A65 (a), LA3-D20H35 (a), LA3-D20H7 (a), LA3-D22 (a), LA3-D22A65 (a), LA3-D22H35 (a), LA3-D22H7 (a), LA3-D24 (a), LA3-D24A65 (a), LA3-D24H35 (a), LA3-D24H7 (a), LA4-K-A1F (b), LA4-K-A1U (b), LA4-K-C1B (b), LA4-K-C1E (b), LA4-K-E1B (b), LA4-K-E1E (b), LA4-K-E1FC (b), LA4-K-E1UG (b), LA4-K-KA1U (b), LA4-K-KC1B (b), LA4-K-KC1E (b), LA4-K-KE1B (b), LA4-K-KE1FC (b), LA4-K-KE1UG (b), LA9D09982 (c), LA9D101 (c), LA9D101 (c), LA9D111 (c)

Foot switches Model(s) XPE followed by B or G, followed by one, two or three alphanumeric digits.

Illuminated operators Model(s) ZB4-B, ZB5-A or ZB5-C followed by W, A, H, P, K or L, followed by one, two, three, four or five numbers may be followed by 3, may be followed by S, may be followed by 7, C0, C1 or CUST

Illuminated push button subunits Model(s) ZB4-BW0 followed by two thru five numbers and/or letters.

ZB5-AW0 followed by two thru five numbers and/or letters.

Illuminated push buttons, full voltage type Model(s) Z..BW06 (d), Z..BW06X+(d)

Illuminated push buttons, resistor type Model(s) Z..BW07 (d), Z..BW07X+(d)

Illuminated push buttons, transformer type Model(s) Z..BW01 (d), Z..BW02 (d), Z..BW03 (d), Z..BW04 (d), Z..BW94 (d), Z..BW95 (d), Z..BW98 (d)

Illuminated push buttons/selector blocks Model(s) ZB6, followed by Z followed by B, G, H or M, followed by two numbers, followed by B or E.

Indicating banks and beacons, enclosed type Model(s) XVB followed by C followed by 9, 07 or 21, may be followed by B or M

XVB followed by C or L, followed by 0, 1, 2, 3, 4, 5, 6 or 8, may be followed by B, E, G or M, followed by one digit, may be followed by D.

XVD followed by B, G or M may be followed by 1 or 2, may be followed by S, may be followed by up to 8 digits included A, C, G, R or 6, may be followed by S and two digits.

XVD followed by C followed by 9, 07 or 21, may be followed by B or M

XVD followed by C or L, followed by 0, 1, 2, 3, 4, 5, 6 or 8, may be followed by B, E, G or M, followed by one digit, may be followed by D.

XVD followed by LS, followed by 3 or 6, may be followed by B, G or M, followed by one digit.

Indicator bank adaptor AS-i units Model(s) XVA-S102

Indicator bank base unit AS-i units Model(s) XVB-C21A

Inductive proximity sensors AS-i units Model(s) XS1-M30AS101, XS7-C40AS101, XS8-C40AS101

Input indicators, open type, and coil suppressor kit modules for use with control circuit contactor types CA.D, LC.D or LP.D Model(s) LA4-D, followed by a letter, followed by a letter or a number, may be followed by a letter.

LA9.D0998X+

Interface modules Model(s) ABR-2 followed by E or S, followed by 1, followed by 0 or 1, followed by 1, 2, 5 or 6, followed by B, E, F or M.

ABR-2EB312B, ABR-2SB312B

ABS-2 followed by EA, EC, SA or SC, followed by 01 or 02, followed by E or M, followed by A, B, E, F or M.

RMC followed by A, L, N or V, followed by 2, 5 or 6, followed by 0, 1, 2 or 5, followed by BD.

RMPT-10BD, RMPT-13BD, RMPT-20BD, RMPT-23BD, RMPT-30BD, RMPT-33BD, RMPT-50BD, RMPT-53BD, RMPT-53BD, RMT-J60BD, RMT-J80BD, RMT-J90BD, RMT-K40BD, RMT-K60BD, RMT-K80BD, RMT-K90BD

Interface relays Model(s) ABR-1, followed by E or S, followed by 1, 3, 4 or 6, followed by 0 or 1, followed by 1, 2 or 8, followed by B, E, F, G or M.

XCK-N followed by 21, 25, 26, 27, 28, 29, 01, 05, 06, 07, 08, 09, 31, 35, 37 or 39, followed by 02, 03, 06, 08, 10, 18, 21, 27, 39, 45 or 49, followed by P20, G11, F12 or P16, followed by blank or SXX (XX may be one or two digits).

XCN-R followed by 21, 25, 26, 27, 28, 29, 01, 05, 06, 07, 08, 09, 31, 35, 37 or 39, followed by 02, 03, 06, 08, 10, 18, 21, 27, 39, 45 or 49, followed by P20, G11, F12 or P16, followed by blank or SXX (XX may be one or two digits).

Joystick controllers Model(s) XD2-GA followed by two thru nine numbers., XD2-PA followed by two thru nine numbers.

XD4-PA followed by two numbers, may be followed by a letter.

XD5-PA followed by two numbers, may be followed by a letter.

XDL-PA followed by two thru nine numbers.

Joystick switches Model(s) XD3-PAXX+

Joystick switches, open type Model(s) XDP- followed by A, B, C or D followed by four numbers, followed by C, followed by 1 or 2.

Keypads AS-i units Model(s) XBL-C5012F581, XBL-C5012R581

LED beacons Model(s) LRSC followed by -12 or -24, followed by R, Y, G or B, followed by -A.

LRX followed by -12 or -24, followed by R, Y, G or B, followed by -A.

XVR followed by 08 or 10, followed by B or J, followed by 03, 04, 05 and 06, may be followed by any letters (R, O, G, B or C).

LED Beacons Model(s) XVR08B03, XVR08B04, XVR08B05, XVR08B06, XVR08J03, XVR08J04, XVR08J05, XVR08J06, XVR10B03, XVR10B04, XVR10B05, XVR10B06, XVR10J03, XVR10J04, XVR10J05, XVR10J06

LED mini sign towers Model(s) LEU followed by T or G, followed by WB or blank, followed by -AC, may be followed by W, followed by -1 thru -5.

LOU followed by T, followed by WB or blank, followed by -AC, may be followed by W, followed by -1 thru -5.

XVC followed by 4, followed by M, followed by 1 through 5, may be followed by 5, may be followed by S, may followed by T, may be followed by any letters(R, O, G, B or C).

XVC followed by 4, followed by M, followed by 1 thru 5, may be followed by 5, may be followed by S, followed by T or blank, may be followed by any letters (R, O, G, B or C).

XVC followed by 6, followed by M, followed by 1 through 5, may be followed by 5, may be followed by S, may be followed by K, may be followed by T, may be followed by any letters (R, O, G, B or C).

XVC4M1, XVC4M15S, XVC4M2, XVC4M25S, XVC4M3, XVC4M35S, XVC4M4, XVC4M45S, XVC4M5S, XVC4M55S, XVC6M1, XVC6M15S, XVC6M15SK, XVC6M15SK, XVC6M15SK, XVC6M25SK, XVC6M25SK, XVC6M25SK, XVC6M3K, XVC6M45SK, XVC6M45SK, XVC6M45SK, XVC6M45SK, XVC6M45SK, XVC6M5SSK, XVC

LED rotating light beacons Model(s) LRLK may be followed by B, followed by -12 or -24, followed by R, Y, G or B, followed by -A

LRMT followed by -12, -24, -120 or -230, followed by B, G, R or Y, followed by -A, may be followed by L.

XVR followed by 12, followed by B or J, followed by 03, 04, 05 and 06, may be followed by S, may be followed by any letters (R, O, G, B or C).

XVR followed by 13 followed by B, J, G or M, followed by 03, 04, 05 and 06, may be followed by L, may be followed by any letters (R, O, G, B or C).

XVR12B03, XVR12B03S, XVR12B04, XVR12B04S, XVR12B05S, XVR12B06S, XVR12B06S, XVR12B06S, XVR12J03, XVR12J03S, XVR12J04, XVR12J04S, XVR12J05S, XVR12J06S, XVR12J06S, XVR13B03, XVR13B03L, XVR13B04L, XVR13B05L, XVR13B06L, XVR13B06L, XVR13B06L, XVR13B06L, XVR13G05L, XVR13G05L, XVR13G06L, XVR13J03, XVR13J04, XVR13J05, XVR13J06, XVR13M03L, XVR13M04L, XVR13M06L

LED sign towers Model(s) UTL followed by B or blank, followed by -AC, followed by W or blank, followed by -1 thru -5.

XVC followed by 1, followed by M, followed by 1 through 5, may be followed by K or SK, may be followed by any letters (R, O, G, B or C).

XVC1M1K, XVC1M1SK, XVC1M2K, XVC1M2SK, XVC1M3K, XVC1M3SK, XVC1M4K, XVC1M4SK, XVC1M5K, XVC1M5SK

LED tower lights Model(s) UTL may be followed by B, followed by -24, followed by -1 thru -5.

XVC followed by 1, followed by B, followed by 1 through 5, may be followed by S, followed by K, may be followed by T, may be followed by any letters (R, O, G, B or C).

XVC1B1K, XVC1B1KT, XVC1B1SK, XVC1B1SKT, XVC1B2K, XVC1B2KT, XVC1B2SK, XVC1B2SKT, XVC1B3SK, XVC1B3SK, XVC1B3SKT, XVC1B4K, XVC1B4KT, XVC1B4SK, XVC1B4SKT, XVC1B5KT, XVC1B5KT, XVC1B5SKT, XVC1B5SKT

Limit switches Model(s) XCD-R followed by D, P or T, followed by four numbers, followed by F, G, M, N or P, followed by two digit number may be followed by a suffix of letter and/or number up to 3 digits.

XCK-D followed by D, P or T, followed by four numbers, followed by F, G, M, N or P, followed by two digit number may be followed by a suffix of letter and/or number up to 3 digits.

XCK-P followed by D, P or T, followed by four numbers, followed by F, G, M, N or P, followed by two digit number may be followed by a suffix of letter and/or number up to 3 digits.

XCK-S followed by 1 to 9, followed by two numbers, may be followed by H7 or H29, may be followed by S followed by a suffix of letter or/and number of two digits

XCK-SD followed by 1 to 9, followed by two numbers, may be followed by H7 or H29, may be followed by S followed by a suffix of letter or/and number of two digits

XCK-T followed by D, P or T, followed by four numbers, followed by F, G, M, N or P, followed by two digit number may be followed by a suffix of letter and/or number up to 3 digits.

XCKVR followed by a two digit number, followed by D or SR, followed by 1 or 2, followed by H29 or H7.

XCN-T followed by 21, 25, 27, 29, followed by 02, 03, 06, 08, 10, 18, 21, 27, 39, 45 or 49, followed by P16, or G11, followed by blank or SXX (XX may be one or two digits).

XCN-TR followed by 21, 25, 27, 29, followed by 02, 03, 06, 08, 10, 18, 21, 27, 39, 45 or 49, followed by P16, or G11, followed by blank or SXX (XX may be one or two digits).

XCP-R followed by D, P or T, followed by four numbers, followed by F, G, M, N or P, followed by two digit number may be followed by a suffix of letter and/or number up to 3 digits.

XCT-R followed by D, P or T, followed by four numbers, followed by F, G, M, N or P, followed by two digit number may be followed by a suffix of letter and/or number up to 3 digits.

ZCK-S followed by 1 to 9, followed by two numbers, may be followed by H7 or H29, may be followed by S followed by a suffix of letter or/and number of two digits

ZCK-SD followed by 1 to 9, followed by two numbers, may be followed by H7 or H29, may be followed by S followed by a suffix of letter or/and number of two digits

Limit switches for interlocking Model(s) XCS, followed by LF or LE followed by six numbers, followed by 2 or 3, may be followed by two numbers.

Limit switches for safety applications Model(s) XCS-A followed by three thru seven numbers., XCS-B followed by three thru seven numbers., XCS-C followed by three thru seven numbers.

Limit switches, cable entry supports Model(s) ZC, followed by DE or PE, followed by F, G, N or P, followed by a two digit number.

Low voltage intelligent motor protection relays Model(s) LR97D followed by 015, 07, 25 or 38, followed by B, E, F7 or M7.

LT47 followed by 06, 30 or 60, followed by B, E, F7 or M7, followed by S or A.

Magnetically operated auxiliary contacts, AC and DC coil devices Model(s) CAD, followed by two numbers, may be followed by a number, followed by one or two letters, may be followed by a number and may be followed by S207 or S335

Magnetically operated control switches Model(s) CA2-DK22 or CA3-DK22, may be followed by 6, may be followed by a letter.

CA2-DN or CA4-DN, followed by two numbers, may be followed by 6, may be followed by a letter.

CA2-KN, followed by two or three number, may be followed by one or two letters and one or two numbers.

Cat. Nos. CAK, followed by a 2 or 3 digit number, followed by two letters, maybe followed by S207 or S335.

Cat. Nos. CAK, followed by a 2 or 3 digit number, followed by two letters, maybe followed by S335

Cat. Nos. CAK, followed by a 2 or 3 digit number, followed by two letters, maybe followed by S335.

Manually operated emergency stop switches Model(s) XY2-CE followed by 1 thru 7 or F, G, J or K, followed by A or C, followed by three numbers, followed by H7 or H7TK.

Mechanical latches, open type Model(s) LA6-DK, followed by a number, may be followed by 6, followed by one or two letters.

LAD6K10, may be followed by 6, followed by one or two letters.

Miniature limit switches Model(s) XCM-D followed by a four or five digit number, followed by C, L, or M followed by a one or two digit number, may be followed by up to 4 alphanumeric characters.

XCM-N followed by a four or five digit number, followed by C, L, or M followed by a one or two digit number, may be followed by up to 4 alphanumeric characters.

XCS-M followed by a four or five digit number, followed by C, L, or M followed by a one or two digit number, may be followed by up to 4 alphanumeric characters.

MOV, Diode and LED socket modules Model(s) RUW240BD, RUW241P7, RUW242B7, RUW242P7, RXM021BN, RXM021FP, RXM021RB, RXM040W, RXM041BN7, RXM041FU7

Multifunction motor protection relays Model(s) LT6POM005FM, LT6POM025FM

Operating heads Model(s) ZB6, followed by A, C or D followed by a letter, followed by a number or a letter, may be followed by 1 thru 7.

ZB6-ASXXX+

Operating heads for limit switches Model(s) Cat. No. ZCE (+)

Operator modules Model(s) GC2DSP

Operators Model(s) ZB4-B, ZB5-A or ZB5-C, followed by A, B, C, D, G, H, J, K, L, P, R, S, T or X, followed by one thru four numbers, may be followed by M.

ZD4-PAXX+, ZD5-PAXX+

Operators (16 mm line), "Class 9001" Model(s) D5, D6, D8 or D9 followed by A, B, C, E, G, L, R or V, followed by a number, followed by a letter.

Overload relay adaptors for use with overload relay Model(s) LA7 D followed by 1064, 2064, 3058 or 3064

LR2/LR3 D1 followed by 1064, 2064, 3058 or 3064

LR2/LR3 D2 followed by 1064, 2064, 3058 or 3064

LR2/LR3 D3 followed by 1064, 2064, 3058 or 3064

LR2/LR3 D4 followed by 1064, 2064, 3058 or 3064

Overload relays Model(s) LR, followed by 1, 3 or 4, followed by D, followed by 09, 12, 16, 25, 40, 63 or 80, followed by three numbers, may be followed by A65, when used with contactors LC1-D or LP1-D or adaptors LA7-D09 followed by 54 or 64, may be followed by A60 or A65.

LR3D3, followed by two numbers, may be followed by one letter, may be followed by 3 or 6.

Pendant stations Model(s) XAC, followed by A, followed by 20 or 21 followed by 1, 3, 5, or 7, may be followed by 3 or 4.

XAC.A followed by a one or two numbers, followed by 71, 81, 91 or may be followed by a combination of s and D (up to three letters), may be followed by 3, 4 or 5, may be followed by one digit, followed by H7.

XAC.A02H7, XAC.A03H7, XAC.A04H7, XAC.A05H7, XAC.A06H7, XAC.A08H7, XAC.A12H7

Photoelectric detectors AS-i units Model(s) XUJ-K063539AS (f), XUJ-K103534AS (f), XUJ-K123538AS (f), XUJ-K703538AS (f)

Photoelectric sensors Model(s) XUE followed by A, F, H, J or T, followed by five or six numbers, may be followed by H7.

XUR followed by H, followed by five numbers, may be followed by H7.

Pilot devices, open type Model(s) XB2-M followed by A, B, C, D, E, G, H, J, K, L, P, Q, R, S, T, V, W, X or Y, followed by numbers.

Pilot light blocks Model(s) ZAL-V followed by B, G, or M, followed by 1, 3, 4, 5 or 6.

ZAL-V18 followed by B, BG, G, J or M, followed by one digit.

ZB6 followed by E or Z, followed by B, G, H or M, followed by one digit, followed by B.

ZBV followed by B, BG, G, J or M, followed by one digit, may be followed by 3, 5, 9 or S

ZBV-18 followed by B, BG, G, J or M, followed by one digit, may be followed by 3, 5, 9 or S

ZBV-6 followed by one digit, may be followed by 3, 5 or 9.

Pilot light blocks (16 mm line), "Class 9001" Model(s) DUF, DUFB

Pilot light heads Model(s) ZB4-BV0 followed by one or two numbers, may be followed by S.

ZB5-AV0 followed by one or two numbers, may be followed by S.

ZB5-CV0 followed by one or two numbers, may be followed by S.

Pilot light subunits Model(s) ZB4-BV followed by one thru four number and/or letter suffixes.

ZB5-AV followed by one thru four number and/or letter suffixes.

Pilot lights Model(s) XB5-E followed by V, followed by B, G or M, followed by a number, may be followed by 3.

Pilot lights, flashing type Model(s) Z..BV181 (q), Z..BV184 (q), Z..BV191 (q), Z..BV194 (q)

Pilot lights, full voltage type Model(s) Z..BV68X+(g), Z..BV6X+(g)

ZB2-BV006X+ (for use with Pendant station XAC-A)

Pilot lights, resistor type Model(s) Z..BV7X+(g)

Pilot lights, transformer type Model(s) Z..BV1X+(g), Z..BV2X+(g), Z..BV3X+(g), Z..BV4X+(g), Z..BV94X+(g), Z..BV95X+(g), Z..BV98X+(g)

Proximity switches Model(s) XCS followed by ZC, ZP or ZR, followed by 5 or 7, followed by 0 or 9, followed by 0 or 1, followed by 1, 2 or 5, may be followed by 0, may be followed by LxxM8 or LxxM12.

XSD followed by A40, A50, A60, C40, C60, H40, H60, J40, J60, M40, M60 or T2, followed by numbers or may be followed by a letter.

Push button control stations AS-i units Model(s) XAL-S2001, XAL-S2002, XAL-S2003

Push buttons and pilot light assemblies (22 mm line) Model(s) XB4-B followed by A, C, D, G, H, J, K, L, P, R, S, T, V, W or X, followed by two thru five or Six numbers and/or letters.

XB5-A followed by A, C, D, G, H, J, K, L, P, R, S, T, V, W or X, followed by two thru five or Six numbers and/or letters.

Push buttons and pilot lights (16 mm line) Model(s) XB6, followed by A, C or D followed by A, D, E, F, G, K, S, V or W, followed by three or four numbers and/or letters, may be followed by a letter.

Push buttons, selector switches and illuminated push buttons Model(s) XB7-N followed by A, D, G, H, J, L or W, followed by two, four or five numbers, may be followed by B, G or M, may be followed by 1 or 2.

Push buttons, selector switches, emergency stop switches, pilot lights and illuminated push buttons, Model(s) XB7-E followed by A, H, D, G, S, V or W, followed by two thru four numbers, may be followed by B, G or M, may be followed by 1 or 2, may be followed by P, may be followed by S or 3.

Safety interlock switches Model(s) XCS-PLXXX+

Safety modules, "Series Preventa" Model(s) XPS-MC followed by two numbers, followed by X or Z, may be followed by C or P.

Safety relays, "Series Preventa" Model(s) XPS-AL followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-AM followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

 $XPS-AMF\ followed\ by\ T,\ f$

XPS-AP followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-APF followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-AS followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-ASF followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-AT followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-AX followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-BA followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

 $XPS-BC\ followed\ by\ T,\ fo$

XPS-CEN followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-CEP followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-DA followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-ECM followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-ECP followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-FB followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-NS followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-OT followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-PVK followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-PVT followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

XPS-VN followed by four or five numbers, may be followed by Z, may be followed by T, followed by three numbers.

Safety relays Model(s) XPS-AC followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-AF followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-AFL followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-AK followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-AR followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-ATE followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-AV followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-BF followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-CM followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-DMB followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-DME followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-MP followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-TSA followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-TSW followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-VC followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

XPS-VNE followed by four thru six numbers, may be followed by P, may be followed by T, with or without three numbers.

Safety switches Model(s) XCS-MP50L*, XCS-MP59L*, XCS-MP70L*, XCS-MP79L*, XCS-MP80L*, XCS-MP89L*

Selector cam switches Model(s) XB3-D followed by five numbers, followed by C, M or S, followed by two or three numbers.

Self powered receivers Model(s) XB5 RFB01, ZBR RC, ZBR RD

Self Powered Switch and Receiver, Antenna Model(s) ZBRA2

Self Powered Switch and Receiver, Access Point Model(s) ZBRN2

Self Powered Switch and Receiver, Access Point Model(s) ZBRN1

Self Powered Switch and Receiver, Ethernet protocol module Model(s) ZBRCETH

Self powered switches and receivers, handy boxes Model(s) ZBR M followed by three, four or five digits, vollowed by two digits, for use with transmitter components Pushbutton, ZBR4R or ZBR5R series

Self powered switches and receivers, relay-antennaes Model(s) ZBR A1

Self powered switches and receivers, transmitters Model(s) ZBR T1, ZBR T2, ZBR TP

Single digit displays Model(s) ZA2-VAXX+

Switch units, open type Model(s) LA1-DC22, LA1-DC226

LA1-DN or LA8-DN, followed by 01, 02, 04, 10, 11, 13, 20, 22, 31 or 40, may be followed by 6, may be followed by 5040.

Terminal kits Model(s) XPS-MCTCXX+, XPS-MCTSXX+

Test output units Model(s) ZB.-.V156, ZB.-.VB.156, ZBZ-.156

Thermal overload relays Model(s) LR-D15XX+, LR-D15XX6+, LR1-D32353

LR2-D33 followed by two digit numbers may be followed by 6 or by A66

LR2-D43 followed by two digit numbers may be followed by 6 or by A66

LR2D3321A66, LR2K-0301, LR2K-0302, LR2K-0303, LR2K-0304, LR2K-0305, LR2K-0306, LR2K-0307, LR2K-0308, LR2K-0310, LR2K-0312, LR2K-0314, LR2K-0316

LR3-D33 followed by two digit numbers may be followed by 6 or by A66

LR3-D43 followed by two digit numbers may be followed by 6 or by A66

LR3D3 or LRD3, followed by two numbers, may be followed by L, may be followed by 3 or 6.

LRD-33 followed by two digit numbers may be followed by 6 or by A66

LRD-43 followed by two digit numbers may be followed by 6 or by A66

Thermal overload relays, adapters Model(s) LAD7B106

Thermistor protection units for operation with PTC (Positive Temperature Coefficient) thermistor probe Model(s) LT3 followed by SEOO, or SAOO, or SMOO, followed by one or two letters.

Timers Model(s) LAD T0, LAD T03, LAD T06, LAD T4, LAD T43, LAD T46, LAD-R2, LAD-R23, LAD-R26, LAD-R43, LAD-R43, LAD-R46, LAD-RO, LAD-RO6, LAD-S2, LAD-S23, LAD-S26, LAD-T2, LAD-T23, LAD-T26

Top-adder auxiliary switch blocks, open type Model(s) LA1-KN, followed by two or three numbers, may be followed by 7, M or P

Tower Light, "Series XVGU" Model(s) XVGU3SHAG, XVGU3SHAV, XVGU3SWG, XVGU3SWV

Transformers for illuminated pushbuttons Model(s) ZB-W3, ZB-W4, ZB-W5, ZB-W8, ZB-W9

Transformers for pilot lights Model(s) ZB-V3, ZB-V4, ZB-V5, ZB-V8, ZB-V9, ZBV5B, ZBV8B, ZBV9B

Transient suppressors Model(s) LA4SKC1U, LA4SKE1E, LA4SKE1U

Trip wire switches Model(s) XY2CH followed by 1 or 3, followed by 1, 2, 3, or 4, followed by 0, 1, 2, 3, 4, 5, 6 or 9, followed by 1, 5, 7 or 9, followed by H7, may be followed by TK.

Model(s) Wall mounting support Model(s) XVUZ12

Investigated to ANSI/UL 60947-1 and ANSI/UL 60947-4-1

Adapter Model(s) LAD7B10 may be followed by S183 and wiring kits Cat. No. LAD7C1 and LAD7C2

Adapter base Model(s) LA7-D

Ambient compensated and differential electronic thermal overload relays Model(s) LR9D followed by two or four digit numbers, LR9F

Ambient compensated and differential thermal overload relays Model(s) LR3D3 followed by two digit numbers may be followed by a L or blank, may be followed by 3 or 6

LRD3

Auxiliary Devices, "TeSys Island" Model(s) TPRPMxxx TPRPM 038 I I I III IV I - Type - Overload relay II- Designates thermal trip setting range (Amps) 009: 0.18 - 9 038: 0.76 - 38 III - Type of connection Blank: Screw type terminals IV - Optional Digits: None

Auxiliary Devices, "TeSys Island Frame size 3" Model(s) TPRPXXXX TPRPM080 I II III IV I - Type - Overload relay II-Designates thermal trip setting range (Amps) 080: 4-80 III - Type of connection Blank: Screw type terminals IV - Optional Digits: None

Auxiliary Devices Model(s) LR3-D35 followed by two digit numbers, may be followed by 6

Coil suppressors Model(s) LAD4BB may be followed by V and a letter

Contactor Mounting Adaptor Model(s) LA7-D4054 may be followed by A65

Low voltage intelligent motor protection relays, "Type TeSys T" Model(s) LTMEV40 may be followed by 08, 27 or 100, may be followed by M, P, D, C or E, followed by BD or FM. Filter LTM9F for use with TeSys T

LTMR may be followed by 08, 27 or 100, may be followed by M, P, D, C or E, followed by BD or FM. Filter LTM9F for use with TeSys T

Low voltage intelligent motor protection relays Model(s) LR97D followed by 015, 07, 25 or 38, followed by B, E, F7 or M7

LT47 followed by 06, 30 or 60, followed by B, E, F7 or M7, followed by S or A

Low voltage intelligent motor protection relays, filters Model(s) LTM9F (Dedicated for TeSys T)

Multifunction Motor Protection Relay Model(s) LT6 followed by POM005FM or POM025FM

Overload Relay Model(s) LA7-D09 followed by 54 or 64 followed or not by A60 or A65

Overload relay adaptors for use with overload relay Model(s) LR2-D1, LR2-D2, LR2-D3, LR2-D4, LR3-D1, LR3-D2, LR3-D3, LR3-D4

Thermal overload relay Model(s) LR2-D25 followed by two digit numbers, may be followed by 6. Adapter base, Cat. No. LA7-D

LR2-D35 followed by two digit numbers, may be followed by 6

Thermal overload relays Model(s) LR-D15 followed by two digit numbers, may be followed by 6 or S165, may be followed by A1

LR1 followed by 40, 63, 80 followed by three digit numbers may or may not be followed by A65

LR1-09 followed by three digit numbers followed or not by A65

LR1-12 followed by three digit numbers followed or not by A65

LR1-16 followed by three digit numbers followed or not by A65

LR1-25 followed by three digit numbers followed or not by A65

LR1-D followed by 32, followed by three digit numbers followed by A65

LR2 D33 followed by two digit numbers may be followed by 6 or by A66

LR2 D43 followed by two digit numbers may be followed by 6 or by A66

LR2-D13 followed by two digit numbers, may be followed by 6

LR2-D15 followed by two digit numbers, may be followed by 6 or S165, may be followed by A1

LR2-D23 followed by two numbers, may be followed by 6

LR2K followed by -0301, -0302, -0303, -0304, -0305, -0306, -0307, -0308, -0310, -0312, -0314, -0316

LR3 D33 followed by two digit numbers may be followed by 6 or by A66

LR3 D43 followed by two digit numbers may be followed by 6 or by A66

LR3 followed by 09, 12, 16 and 25 followed by three digit numbers followed or not by A65

LR3-D followed by 40, 63, 80 followed by three digit numbers may or may not be followed by A65

LR3-D-32 followed by three digit numbers followed by A65

LR3-D13 followed by two digit numbers, may be followed by 6

LR3-D15 followed by two digit numbers, may be followed by 6 or S165, may be followed by A1

LR3-D23 followed by two numbers, may be followed by 6

LR3-D25 followed by two digit numbers, may be followed by 6

LR4-D followed by 09, 12, 16 and 25 followed by three digit numbers followed or not by A65

LRD 33 followed by two digit numbers may be followed by 6 or by A66

LRD 43 followed by two digit numbers may be followed by 6 or by A66

LRD followed by two digit numbers followed by L, may be followed by one digit number, may be followed by S183

Thermal overload relays, adapters Model(s) LAD7B106 may be followed by S183(#)

LAD7B205 may be followed by S183 and NEMA adapter 9065SAD75

Thermal overload relays, wiring kits Model(s) LAD7C1(#), LAD7C2(#)

Model(s) LA7 D followed by 1064, 2064, 3058 or 3064

Investigated to ANSI/UL 60947-1 and ANSI/UL 60947-5-1

Accessories: Illuminated rings for pushbuttons Model(s) Cat. No. ZBY9W followed by one digit, , followed by B, G or M, followed by three or four digits.

Auxilary Device Open type Model(s) DPEAN followed by 01, 02, 04, 10, 11, 13, 20, 22, 31 or 40, may be followed by 6 or 3, may be followed by 5040, may be followed by S (for LADN22 only)

LA1-DC followed by 22, may be followed by 6 or 3

LA1-DN followed by 01, 02, 04, 10, 11, 13, 20, 22, 31 or 40, may be followed by 6 or 3, may be followed by 5040, may be followed by S (for LADN22 only)

LA8DN followed by 01, 02, 04, 10, 11, 13, 20, 22, 31 or 40, may be followed by 6 or 3, may be followed by 5040, may be followed by S (for LADN22 only)

LAD-8N followed by 01, 02, 04, 10, 11, 13, 20, 22, 31 or 40, may be followed by 6 or 3, may be followed by 5040, may be followed by S (for LADN22 only)

LAD-C followed by 01, 02, 04, 10, 11, 13, 20, 22, 31 or 40, may be followed by 6 or 3, may be followed by 5040, may be followed by S (for LADN22 only)

LAD-N followed by 01, 02, 04, 10, 11, 13, 20, 22, 31 or 40, may be followed by 6 or 3, may be followed by 5040, may be followed by S (for LADN22 only)

Auxiliary contactors Model(s) CAD ac coil devices, followed by two digit numbers may be followed by one digit number, followed by one or two letters, may be followed by a digit number and maybe followed by S335

Auxiliary contacts Model(s) CAD dc coil devices followed by two digit numbers may be followed by one digit number, followed by one or two letters, may be followed by a digit number and maybe followed by S207

Auxiliary Devices, "TeSys Island" Model(s) TPRSM001 TPRSM- 001 I II III I - Type - Interface Module II- 001 III - Type of connection Blank: Screwless terminals IV - Optional Digits

Auxiliary Devices Model(s) CA2-DN122 with or without Nos. -9, A60, -A65, with or without No. H7

CA2-DN131 with or without Nos. -9, A60, -A65, with or without No. H7

CA2-DN140 with or without Nos. -9, A60, -A65, with or without No. H7

CA3 DN followed by two digits, may be followed by *6, may be followed by a suffix letter

CA3-DK22 may be followed by a suffix letter may be followed by a suffix letter

GV4ADM1111

Auxiliary devices Model(s) LA1SK02, LA1SK11, LA1SK20, LA4SKC1 followed by a letter, LA4SKE1 followed by a letter

Auxiliary switch contact blocks, open type Model(s) LA1-DX followed by a two digit number, *may be followed by 6

LA1-DY followed by a two digit number, *may be followed by 6

LA1-DZ followed by a two digit number, *may be followed by 6

Auxiliary switch units Model(s) LA1-KN followed by a 2 or 3 digit number, may be followed by 7, M or P

Coil suppressors Model(s) LAD4 followed by two or three letters and control wiring kits

Control relays Model(s) CA2SK followed by 11 or 20, followed by a letter, followed by a digit number or a letter

CA3SK followed by 11 or 20, followed by a letter, followed by a digit number or a letter

Control Station Model(s) Cat. No. XAL-D or -K , may be followed by W, followed by 01, 02, 03, 04 or 05, followed by H7.

Control switches Model(s) CA2-DK22 may be followed by a suffix letter may be followed by a suffix letter

CA2-DN followed by two digits, may be followed by *6, may be followed by a suffix letter

CA2-KN followed by a 2 or 3 digit number may be followed by one or two letters and a one or two digit number

LA4-K followed by E1B, E1E, E1UG, C1B, C1E, A1U, A1F, or E1FC

Industrial control relay with mechanically interlocked, alternating contacts Model(s) CA2SKE20

input indicator and coil suppressor kit modules Model(s) LA4-D followed by a letter, followed by a letter or digit number, followed or not by a letter

Input indicator and coil suppressor kit modules Model(s) LA9-D0998 followed by two digits, may be followed by *6, may be followed by a suffix letter

Magnetic Motor Controllers Model(s) LA2-D20 may or may not be followed by H7, A65, or H35

LA2-D22 may or may not be followed by H7, A65, or H35

LA2-D24 may or may not be followed by H7, A65, or H35

LA3-D20 may or may not be followed by H7, A65, or H35

LA3-D22 may or may not be followed by H7, A65, or H35

LA3-D24 may or may not be followed by H7, A65, or H35

Magnetic motor controllers or auxiliary devices Model(s) LA1-D followed by 04, 10, 11, 13, 20, 22, 40 or 1111, may or may not be followed by H7, A65 or H35

Magnetically operated control switches Model(s) CA3-KN

CA4-KN followed by a 2 or 3 digit number, may be followed by one or two letters and one or two digit numbers

CAK followed by a 2 or 3 digit number, followed by one letters and one digit numbers, maybe followed by S335

CAK followed by a 2 or 3 digit number, followed by two letters, maybe followed by S207 or S335

Mechanical Latching Mechanisms Model(s) LA6-DK followed by a number, may be followed by 6, followed by one or two letters

LAD6K10 may be followed by a suffix letter may be followed by a suffix letter

Operator modules Model(s) GC2DSP, LTMCU, LTMCUC, LTMCUF

Plug-in devices Model(s) LAD4-D followed by 3, followed by B, E, S, G, U, R, or N

LAD4-RC followed by 3, followed by B, E, S, G, U, R, or N

LAD4-T followed by 3, followed by B, E, S, G, U, R, or N

LAD4-V followed by 3, followed by B, E, S, G, U, R, or N

Thermistor protection units for operation with PTC (Positive Temperature Coefficient) thermistor probe Model(s) LT3 followed by SE00, or SA00, or SM00, followed by one or two letters

Timer Model(s) LAD-R0 may be followed by 6 or 3, LAD-T0 may be followed by 6 or 3, LAD-T4 may be followed by 6 or 3

Timers Model(s) LAD-R2 may be followed by 6 or 3, LAD-R4 may be followed by 6 or 3, LAD-S2 may be followed by 6 or 3, LAD-T2 may be followed by 6 or 3

Investigated to

Adapters Model(s) 9065SAD75

Open type, Thermal overload relays with ambient compensation Model(s) LR3D followed by two digit numbers may be followed by one digit number, may be followed by S183(#)

LRD followed by two digit numbers may be followed by one digit number, may be followed by S183 (#)

Thermal overload relays Model(s) LR3D followed by two digit numbers followed by L,

- # Investigated to ANSI/UL 60947-1, ANSI/UL 60947-4-1A, CAN/CSA-C22.2 No. 60947-1 and CAN/CSA-C22.2 No. 60947-4-1A
- (a) May be factory or field installed on the CA2-D, CA3-D devices.
- (b) May be factory or field installed on the CA2KN or CA3KN devices.
- (c) May be factory or field installed on the LC1-D, LC2-D or LE1-D devices.
- (d) These illuminated units are intended to be used in XA2.B, XB3.B illuminated push button and illuminated selector switch Series.
- (f) Provided with the back cover adaptor XUJ-ZAS1.
- (g) These pilot light units are to be used in XA2.B, XB2.B, XB3.B Series.
- (h) Models are for use in XA2-B, XB2-B, XB3-B, push buttons and selector switches.
- * May be followed by additional numbers and letters.
- + followed by a two or three digit or alphanumeric number

Click here to view the Colombia Market Access Certification

Last Updated on 2019-08-15

La présence d'un produit ou d'un nom de société dans cette base de données ne signifie pas nécessairement que les produits ainsi identifiés ont été fabriqués dans le cadre du service de suivi d'UL. Seuls les produits portant la marque UL peuvent être considérés comme certifiés et couverts par le service de suivi d'UL. Recherchez toujours la marque sur un produit.

UL autorise la reproduction des documents contenus dans le répertoire de certifications en ligne, aux conditions suivantes : 1. Les (fichiers de) certifications, informations des guidages, assemblages, constructions, dessins et/ou systèmes doivent être présentés dans leur totalité et de manière non trompeuse, sans aucune manipulation des données (ou de dessins). 2. La mention « Réimprimé depuis le répertoire des certifications en ligne avec la permission d'UL » doit être apposée près du matériau extrait. En outre, le document réimprimé doit comporter une déclaration relative aux droits d'auteur au format suivant : "© 2019 UL LLC"