2

ECN 21373

4/01/10

REVISIONS DESCRIPTION APPROVED OP INITIAL RELEASE ECN 16074F 03/30/01 1P ADDED SHEET 3 WITH 508214C00 09/08/05 ECN 19904B 508214A01 WAS A00;B01 WAS B00 10/22/09 ECN 21306 REVISED COMPANY NAME

3P REVISED PHONE NO

#### NOTE:

D

1. FOR PRINT FORMAT, GRAPHICS AND TEXT SEE 508214A.PDF

**SIEMENS** 

Siemens Industry,Inc. Norcross, Ga. 30092 U.S.A. For questions call 1-800-241-4453 or our web site: http://www.sea.siemens.com/dpd

Item: Replacement Wire Grip Kit Catalog Numbers HL65678


For use with: 400-1200 Amp Type

VBII Safety Switches

Page 1 of 3

Pc. No. 508214A01

# Installation Instructions for Replacement Wire Grip Kit



# **DANGER**

Hazardous voltage. Will cause death or serious

urn off and lock out all power upplying this Safety Switch

efore restoring power to switch.

9. Reinstall all wires and torque lugs to the Wire Tightening Torque values listed in the Terminal & Wire Information Table on the interior label.

10. Replace all line shields.


11. Close cover before supplying power to the


### **⚠** SAFETY INSTRUCTIONS

Note: This instruction outlines recommended installation procedure.

400 / 600 Amp Wire Grips

- 1. Turn OFF and lock out all power supplying the Safety Switch.
- 2. Turn the Safety Switch OFF.
- 3. Remove line shields.
- 4. Verify that NO voltage is present at the wire
- 5. Remove wires from all wire grips.
- 6. Remove and retain the mounting hardware as shown in Figures 1 & 2.
- 7. Remove and discard old wire grips.
- 8. Using the mounting hardware removed in step 6, install wire grips furnished in this kit. Torque hardware to the Lug Mounting Torque value listed in the Terminal & Wire Information Table on the interior label.





508214A01 (PAGE 1 OF 3)

MATERIAL: 20# WHITE BOND PAPER SIZE 8.5 X 11 INCHES 508214A01 BLACK PRINTING ON WHITE BACKGROUND MATERIAL/SPECIFICATION PART NO. CONFIDENTIAL- PROPERTY OF Siemens Industry, Inc. UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES DO NOT SCALE DRAWING Siemens Industry, Inc. TOLERANCES: .XX ± 0.01 **INSTRUCTION SHEET** .XXX ± 0.001 ANGULAR ± 1.0 ° WIRE GRIP REPLACEMENT KIT SIZE FSCM NO. DWDWAF DA70E1/15/01 508214 3P CHDKAF DA1011/15/01 PRO/E FILE 508214 SHEET1 AP**VND**AFTA DA70ff/15/01

Released Production, 3P v2, Apr 12, 2010

Page 2 of 3 Pc. No. 508214A01



### **A** DANGER

Hazardous voltage. Will cause death or serious injury.

his Safety Switch before installing kit.

Replace line shields and close cover before restoring power to switch.

### Installation Instructions for Replacement Wire Grip Kit

800 / 1200 Amp Wire Grips


- Turn OFF and lock out all power supplying the Safety Switch.
- 2. Turn the Safety Switch OFF.
- 3. Remove line shields.
- Verify that NO voltage is present at the wire grips.
- 5. Remove wires from all wire grips.
- 6. Remove and retain the mounting hardware as shown in Figures 3 7.
- 7. Remove and discard old wire grips.

- Using the mounting hardware removed in step 6, install wire grips furnished in this

   Lit. Torque hardware to the Lug Mounting.
- kit. Torque hardware to the Lug Mounting
  Torque value listed in the Terminal & Wire
  Information Table on the interior label.
- Reinstall all wires and torque lugs to the Wire Tightening Torque values listed in the Terminal & Wire Information Table on the interior label.
- 10. Replace all line shields.
- 11. Close cover before supplying power to the Safety Switch.

Four (4)
Wire Grips
on 1200 Amp Only

800 / 1200 Amp Line Base Assembly
(Non-Fused 1200 Amp Shown)
Fig. 3





508214A01 ( PAGE 2 OF 3 ) Siemens Industry,Inc. Norcross,Ga.30092 U.S.A. For questions call 1-800-241-4453 or our web site: http://www.sea.siemens.com/dpd


Page 3 of 3 Pc. No. 508214A01

# Hazardous voltage, Will cause death or serious injury. Turn off and lock out all power supplying this Safety Switch before installing kit. Replace line shields and close cover before restoring power to switch.

## Installation Instructions for Replacement Wire Grip Kit








508214A01 (PAGE 3 OF 3)

2

© 1999 Siemens Energy & Automation, Inc.



4

3

Released Production, 3P v2, Apr 12, 2010

2

Item: Replacement Wire Grip Kit
Catalog Numbers HL67A

For use with:


800 Amp (MOD A) Type VBII Safety Switches

Siemens Industry,Inc. Norcross,Ga.30092 U.S.A. For questions call 1-800-241-4453 or our web site:

Page 1 of 1

Pc. No. 508214B01

## Installation Instructions for Replacement Wire Grip Kit



http://www.sea.siemens.com/power

### **DANGER**

Hazardous voltage.
Will cause death or serious

Turn off and lock out all power supplying this Safety Switch before installing kit.

Replace line shields and close cover before restoring power to switch.

 Reinstall all wires and torque lugs to the Wire Tightening Torque values listed in the Terminal & Wire Information Table on the interior label.


10. Replace all line shields.


11. Close cover before supplying power to the Safety Switch.

### **⚠ SAFETY INSTRUCTIONS**

Note: This instruction outlines recommended installation procedure.

- 1. Turn OFF and lock out all power supplying the Safety Switch.
- 2. Turn the Safety Switch OFF.
- 3. Remove line shields.
- Verify that NO voltage is present at the wire grips.
- 5. Remove wires from all wire grips.
- 6. Remove and retain the mounting hardware as shown in  $Figures\ 1\ \&\ 2$
- 7. Remove and discard old wire grips.
- 8. Using the mounting hardware removed in step 6, install wire grips furnished in this kit. Torque hardware to the Lug Mounting Torque value listed in the Terminal & Wire Information Table on the interior label.





508214B01 (PAGE 1 OF 1)

MATERIAL: 20# WHITE BOND PAPER SIZE 8.5 X 11 INCHES 508214B01 BLACK PRINTING ON WHITE BACKGROUND MATERIAL/SPECIFICATION PART NO. CONFIDENTIAL- PROPERTY OF Siemens Industry, Inc. UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES DO NOT SCALE DRAWING Siemens Industry, Inc. TOLERANCES: .XX ± 0.01 **INSTRUCTION SHEET** .XXX ± 0.001 ANGULAR ± 1.0 ° WIRE GRIP REPLACEMENT KIT 0.000 SIZE FSCM NO. DWDWAF DA70E1/15/01 508214 3P CHDKAF DA1011/15/01 PRO/E FILE 508214 SHEET3 AP**VND**AFTA DA70ff/15/01

3

Released Production, 3P v2, Apr 12, 2010