





"THE ENGINEERED ENCLOSURE"







Hot Box® Enclosures have been trusted since 1986, and requested by name. Leading the industry with innovative designs, Hot Box enclosures are built to speed the installation and maintenance of backflow prevention, pump and sprinkler assemblies, pressure vacuum breakers, and air release valves. The enclosures facilitate an installation in the most economical, safe, and accessible location - outside and above ground. More and more designers, utilities, and contractors are putting the backflow preventer at the curb to eliminate costly problems encountered in equipment rooms.

Features such as heater sizing, drain-sizing, service access, and rigid construction make Hot Box enclosures the ultimate solution for protecting outdoor infrastructure and piping systems.







#### •

# **Table of Contents**

| Products/General                   | 4-49  |
|------------------------------------|-------|
| Overview/ASSE-Code Requirements    | 4-7   |
| Enclosure Selection                | 8-11  |
| Hot Box® Select Six                | 12-13 |
| Aluminum Enclosures Intro          | 14-15 |
| DURA FOLD® Aluminum Enclosures     | 16-17 |
| Single Aluminum Enclosures         | 18-19 |
| Dual Aluminum Enclosures           | 20-21 |
| Custom Aluminum Enclosures         | 22-23 |
| Fiberglass Enclosures Intro        | 24-25 |
| DESIGNER SERIES™ Enclosures        | 26-27 |
| Flip-Top Fiberglass Enclosures     | 28-29 |
| EZ BOX® Enclosures                 | 30-31 |
| VENT GUARD® Enclosures             | 32-33 |
| VALVE COVER™ Enclosures            | 34    |
| VALVE GUARD® Enclosures            | 35    |
| Poly EZ Box® Enclosures            | 36-37 |
| HOT ROK® Fiberglass Enclosures     | 38-39 |
| POLYROK® Enclosures                | 40-41 |
| Pump Guard™ Enclosures             | 42-43 |
| GLASS PAD™ Mounting Bases          | 44    |
| Options & Accessories              | 45-49 |
| Technical Information              | 50-78 |
| Standard Drawings                  | 50-51 |
| Frequently Asked Questions         | 52-53 |
| Installation Guides                | 54-59 |
| Heater & Heat Trace Tape           | 60-63 |
| Order Form & Typical Winterization | 64-65 |
| Typical Installation Examples      | 66-69 |
| Product Specifications             | 70-73 |
| Hot Box® Catalog Numbering System  | 74-75 |
| Terms & Conditions                 | 76-78 |







### **Hot Box® Enclosures**

Hot Box offers the broadest range of enclosures in the industry with multiple material types, styles, and sizes. All are built with the same attention to quality and performance that you know and expect from Hot Box. Our comprehensive product offering is designed to ensure that your application requirements are met, and your expectations are exceeded.



#### **Aluminum Enclosures**

Manufactured from corrosion and UV resistant stucco embossed aluminum, these enclosures have a highly durable, industrial style, riveted construction (optional Mill Finish and Marine Grade aluminum available). Commonly used for larger projects due to its ability to be easily customized, aluminum provides both versatility and strength. Bonded foam insulation will not sag or delaminate from the walls, unlike glued or tacked board insulation.



### **Fiberglass Enclosures**

Reinforced fiberglass revolutionized the Hot Box industry by reducing both installation time and cost. With five different fiberglass models to protect your backflow, pump, air release valve, or anything that needs to be protected from the elements, fiberglass is often chosen for smaller devices (up to 4") due to its lightweight nature. For smaller applications, typically one person can easily install a Hot Box on their project, thus reducing your labor costs.



#### Poly EZ Box® (Plastic) Enclosures

Polyethylene enclosures can efficiently provide protection for up to a 2" device. Commonly specified by irrigation suppliers and landscape architects, the PEZ enclosures are available in green or brown. Combining easily recycled materials with a lightweight, cost effective design, our PEZ product line has both attractive designs and the high quality the industry expects.



### Fiberglass Hot Rok® & Plastic PolyRok® **Enclosures**

Hot Rok and PolyRok are camouflaging enclosures. They are commonly used by irrigation contractors and landscape architects to blend in with the natural environment.







#### **(**

### **ASSE Performance Requirements**

#### **ASSE Standard # 1060**

In 1996, The American Society of Sanitary Engineering (ASSE) developed the ASSE 1060 industry standard for outdoor enclosures to cover fluid conveying components. Born from the organization's philosophy of "prevention rather than cure," the ASSE 1060 seeks to protect public health and safety by providing performance requirements to safeguard equipment from freezing, tampering, and vandalism. As a result, the ASSE 1060 standard has been adopted by utilities and Water Authority departments across the nation. To this day, the ASSE 1060 remains the water industry's gold standard.

#### Hot Box®-ASSE 1060 Certified

All Hot Box standard enclosures meet or exceed the test provisions of the ASSE 1060 standard and proudly bear the ASSE 1060 seal. To achieve the certification, Hot Box enclosures must pass numerous independent material and product performance tests.

Laboratory Test Requirements for ASSE 1060 2006:

- Section 3.1 Air Inlet Test (Class I-V, II-V and II-V)
- Section 3.2 Structural Test (All Classes)
- Section 3.3 Access for Testing and Maintenance (All Classes)
- Section 3.4 Hinged Access Panel Restraints Test
- Section 3.5 Drainage Performance Test (All Classes)
- Section 3.6 Freeze Protection Capability Test (Class I and I-V)
- Section 3.7 Security/Locking Mechanism Test





Class I - Freeze Protection Enclosures (Heated): Designed and constructed to maintain a minimum internal temperature of 40°F with external temperatures as low as -30°F.

Class II - Freeze Retardant Enclosures (Insulated Non-Heated): Designed and constructed to be installed in locations with minimum external temperatures of 33°F.

Class III - Non-Freeze Protection Enclosures (Uninsulated Non-Heated): Designed and constructed to provide system security for components when freezing temperatures are not a consideration.

#### Hot Box®- Reduced Liability...Increased Credibility

Hot Box is the #1 trusted outdoor protection enclosure manufacturer in the industry. Our enclosures undergo rigorous physical, environmental, and internal equipment testing. When an engineer, architect, or contractor specifies or installs an ASSE certified Hot Box enclosure, they know the safety and quality of the enclosure will bring peace of mind and integrity to the entire project.

Look for the Seal




to Know it's Real!









## **ASSE Performance Requirements**



#### DRAIN PORT DETAILS FOR FIBERGLASS ENCLOSURES





| BFP<br>SIZE | ENCLOSURE                                                | ENCLOSURE<br>OLD # | DRAIN<br>SIZE | BFP<br>DISCHARGE | # PER<br>ENCL. |
|-------------|----------------------------------------------------------|--------------------|---------------|------------------|----------------|
| JIZL        |                                                          | ULD #              | JIZL          | DISCHARGE        | ENCL.          |
| 3/4"-1"     | HF011019022<br>HF013027023<br>HF013027035<br>HT013026024 | HB1<br>HB1T        | R4"           | 200<br>GPM       | 2              |
|             | HF021033025<br>HF013039028<br>HF013039036<br>HT019048040 | HB2<br>HB2T<br>HR2 | R5"           | 300<br>GPM       | 2              |
| 2 1/2"-3"   | HF026070045<br>HF026070055                               | HB3N<br>HB3E       | R6"           | 450<br>GPM       | 2              |

THE DRAINPORTS IN EACH ENCLOSURE ARE SIZED TO ALLEVIATE A FULL DISCHARGE OF THE BACKFLOW PREVENTER. (LAB TESTED PER A.S.S.E. STANDARD #1060.)







### **Code & Specification Requirements**

The following are samples of building codes and manufacturer's specifications that demonstrate the need for an enclosure to protect infrastructure from freezing temperatures:

#### **ASSE STANDARD #1060 Outdoor Enclosures for Fluid Conveying Components**



Section 3.2.1: Enclosure is capable of supporting a minimum vertical load of 100 lb./sf.

Section 3.3.1: Enclosure has been designed to be accessed and provide sufficient room for monitoring, testing,

maintenance, repair or replacement of the component located inside the enclosure.

Section 3.5.1: Depth of water within the enclosure does not exceed 8 inches during full flow of the backflow prevention assembly relief discharge, and that the depth of the water does not exceed 1/4" after full flow has ceased.

Section 3.6.1: Enclosures shall contain a heat source capable of maintaining the temperature of the component and associated piping at 40°F (4.4°C) inside the enclosure when subjected to -30°F (-34.4°C) outside air temperature.



#### **AMERICAN SOCIETY OF PLUMBING ENGINEERS-ASPE**

Data Book:

Reduced pressure principle devices, double check valves and vacuum breakers installed in regions subject to freezing must be protected by the insulation of the units in above-ground, heated structures.



#### **INTERNATIONAL PLUMBING CODE® 2015**

Section 608.14.1: Outdoor enclosures for backflow prevention devices shall comply with ASSE 1060.



#### **AWWA M-14**

A reduced pressure backflow assembly must be protected from freezing temperatures, and a double check (backflow) valve assembly must be protected from freezing temperatures.



#### **FEBCO**

The backflow prevention assembly must be protected from freezing.



#### **WATTS**

In an area where freezing conditions can occur, the backflow prevention assembly should be installed in a properly insulated utility building or shelter.



#### NFPA 13

8.16.4.1.3: Where aboveground waterfilled supply pipes, risers, system risers, or feed mains pass through open areas, cold rooms, passageways, or other areas

exposed to temperatures below 40°F (4°C), the pipe shall be permitted to be protected against freezing by insulated coverings, frost proof casings, or other means capable of maintaining a minimum temperature between 40-120°F (4-49°C).



#### PLUMBING-HEATING-COOLING **CONTRACTORS ASSOCIATION (PHCC) National Standard Plumbing Code**

Freezing: The plumbing system shall be protected from freezing or overheating. The following conditions shall be met:

In areas with seasonal freezing temperatures, all waste, vent and water supply piping in exterior walls and other areas shall be protected from freezing.

#### THE COUNCIL OF AMERICAN BUILDING OFFICIALS (C.A.B.O.) One and Two Family **Dwelling Code**

Freezing: Water, soil, or waste pipe shall not be installed or permitted outside of a building or in an exterior wall unless adequate provision is made to protect such pipe from freezing where necessary.

#### THE SOUTHERN BUILDING CODE CONGRESS International (S.B.C.C.I) Standard Plumbing Code

Freezing: A water, soil, or waste pipe shall not be installed or permitted outside of a building or concealed in outside walls or on any place where they may be subject to freezing temperature, unless adequate provision is made to protect them from freezing.



#### THE BUILDING OFFICIALS & CODE **ADMINISTRATORS International. In.** (B.O.A.C.) National Plumbing Code

In climates with freezing temperatures, plumbing piping in exterior walls or areas subject to freezing temperatures shall be protected against freezing by insulation or heat or both.



#### NATIONAL BUILDING CODE OF **CANADA**

Where piping may be exposed to freezing conditions it shall be protected from frost.









### **Enclosure Selection**

With hundreds of Hot Box® Enclosures available, you may be asking yourself, which enclosure should I choose? Below is a guide to help you choose from our many different options:

#### **HOT BOX® SELECT SIX (See pages 12-13)**

Hot Box® would like to introduce our new "Select Six" aluminum enclosures. It's just another way we're creating innovative products that make it easy for you to protect your equipment:

- Six nominal sizes accommodate standard and N-pattern pipe sizes from 2 ½" to 10" dia.
- Reduced lead times.
- Protects against freezing conditions with optional, wall-mounted heaters that offer better performance and safety with the heater raised above the discharge point.
- Available in Mill Finish aluminum or Federal Brown.

#### STANDARD SIZE ENCLOSURES (See pages 14-21 & 24-43)

Hot Box® has a wide variety of standard enclosure sizes available in different styles and material types to meet your needs:

- Better fit with standard sizes ranging from 6"W x 20"L x 22"H to 87"W x 172"L x 85"H.
- Dura Fold® and Designer Series™ Enclosures are the industry benchmarks. These models provide both ease of installation and accessibility.
- Other traditional enclosure styles include: flip-top fiberglass, sectional aluminum, and drop over.
- Material types: aluminum, fiberglass, and polyethylene.
- Various options, such as vents, fans, lights, and alarms are available to modify any standard enclosure. See pages 45-49 for details.

#### **CUSTOM SIZE ENCLOSURES (See pages 22-23)**

Hot Box® offers custom sized sectional and Dura Fold® aluminum enclosures which can be manufactured to an engineer's exact specifications depending on the application:

- Best fit with dimensions manufactured to engineer's specifications.
- Peace of mind with ASSE 1060 certified enclosures up to 172"L x 87"W x 85"H (larger enclosures built with same design and quality).
- Special configurations, like wall-mounted enclosures, available upon request.
- Various material thicknesses available depending on specification requirements.
- Various options, such as vents, fans, lights, and alarms are available to modify any custom sized enclosure. See pages 45-49 for details.








# Hot Box® Select-A-Box Tool


Selecting a standard Hot Box\* enclosure for your application is easy. Our Select-A-Box tool quickly shows all available styles of Hot Box\* enclosures to fit your specific backflow device. Once you select the style of enclosure desired, the tool will provide a drawing, piping layout diagram, specification, and installation instructions.



#### Step #1


Select your manufacturer, model, valve type and clearance requirement from the drop-down menus provided<sup>1</sup>, then hit submit<sup>2</sup>.

**Notes:** 1) Helpful notes<sup>3</sup> 2) You can hit reset<sup>4</sup> at any time to start over. 3) If you hit "Submit"early, then it will indicate which "Required"<sup>5</sup> piece of information is missing.



### Step # 2

The Select-A-Box tool will display all available styles of Hot Box\*. Please click on the heated or unheated part# of your preferred style to proceed\*. Your project specifications are viewable below the table for verification\*. If you need to make changes, then simply select the "Go-Back" button\*.



#### Step # 3

The Product Results page with Piping Layout<sup>1</sup> will be displayed. Click on the available PDF's for drawings<sup>2</sup>, specifications<sup>3</sup>, or installation instructions<sup>4</sup>.

Visit www.hpsapps.com/hotbox/ or scan the QR code to select a Hot Box® Enclosure today.











## **Enclosure Selection-By Pipe Size**

If you only know your pipe size because the valve manufacturer and type has yet to be determined, the chart below can help you select a Hot Box® Enclosure. Please note that the Hot Box Select-A-Box tool can potentially provide a better fit, and one of the Hot Box Select Six can cover a wider range of pipe sizes and valves types.

|           | Backflow Preventer (Straight) Sizing Guide by pipe size |                                    |                                                                                  |                                    |                                        |                                    |                                        |                                                   |  |  |  |  |  |
|-----------|---------------------------------------------------------|------------------------------------|----------------------------------------------------------------------------------|------------------------------------|----------------------------------------|------------------------------------|----------------------------------------|---------------------------------------------------|--|--|--|--|--|
|           |                                                         |                                    | Standard HotBox Enclosure Standard HotBox<br>12" bottom clearance 18" bottom cle |                                    |                                        |                                    | Box Enclosure<br>nterline              |                                                   |  |  |  |  |  |
| Pipe Size |                                                         | Quarter Turn                       |                                                                                  |                                    | er Turn                                | Quarte                             | Excluded bfp's                         |                                                   |  |  |  |  |  |
| 0.75      | 0.75 Tall No.                                           |                                    | 3027023                                                                          |                                    | 13027035                               |                                    | 13027035                               | ·                                                 |  |  |  |  |  |
| 0.70      | Model No.                                               | DF1/                               |                                                                                  |                                    | /HB1T                                  |                                    | /HB1T                                  |                                                   |  |  |  |  |  |
| 1         | Part No.                                                |                                    | 3027023                                                                          |                                    | 13027035                               |                                    | 13039036                               |                                                   |  |  |  |  |  |
|           | Model No.                                               | DF1/                               |                                                                                  | DF1T                               | /HB1T                                  | DF2T                               | /HB1T                                  |                                                   |  |  |  |  |  |
| 1.25-1.50 | 5-1.50 Part No. HD/HF013039028                          |                                    |                                                                                  |                                    | 13039036                               |                                    | 13039036                               |                                                   |  |  |  |  |  |
|           | Model No.                                               |                                    | /HB2                                                                             |                                    | /HB2T                                  |                                    | /HB2T                                  |                                                   |  |  |  |  |  |
| 2         | Part No.                                                | HD/HF01                            |                                                                                  |                                    | 13039036                               | HD/HF0                             |                                        |                                                   |  |  |  |  |  |
|           | Model No.                                               | DF2/HB2                            |                                                                                  | DF2T/HB2T                          |                                        | DF2T/HB2T                          |                                        |                                                   |  |  |  |  |  |
| Pipe Size |                                                         | NRS                                | OS&Y                                                                             | NRS                                | OS&Y                                   | NRS                                | OS&Y                                   | Excluded bfp's                                    |  |  |  |  |  |
| 2.5       | Part No.<br>Model No.                                   | HD/HE/HF026070045<br>DF3N/EZ3/HB3N | HD/HE/HF026070045<br>DF3N/EZ3/HB3N                                               | HD/HE/HF026070045<br>DF3N/EZ3/HB3N | HA/HD/HF026070055<br>HB3E-AL/DF3E/HB3E | HD/HE/HF026070045<br>DF3N/EZ3/HB3N | HA/HD/HF026070055<br>HB3E-AL/DF3E/HB3E | 909RPDA (LA045072052)                             |  |  |  |  |  |
| 3         | Part No.<br>Model No.                                   | HD/HE/HF026070045<br>DF3N/EZ3/HB3N | HD/HE/HF026070045<br>DF3N/EZ3/HB3N                                               | HD/HE/HF026070045<br>DF3N/EZ3/HB3N | HA/HD/HF026070055<br>HB3E-AL/DF3E/HB3E | HD/HE/HF026070045<br>DF3N/EZ3/HB3N | HA/HD/HF026070055<br>HB3E-AL/DF3E/HB3E | 909RPDA (LA045072052)                             |  |  |  |  |  |
| 4         | Part No.<br>Model No.                                   | HA/HD032090050<br>HB4N/DF4N        | HA/HD032090057<br>HB4E/DF4E                                                      | HA/HD032090050<br>HB4N/DF4N        | HA/HD032090057<br>HB4E/DF4E            | HA/HD032090057<br>HB4E/DF4E        | HA/HD032090057<br>HB4E/DF4E            | 909RPDA (HA051096067)<br>350AST OSY (HA045072060) |  |  |  |  |  |
| 6         | Part No.<br>Model No.                                   | HA036105053<br>HB6N                | HA036105053<br>HB6N                                                              | HA036105053<br>HB6N                | HA036105064<br>HB6E                    | HA036105053<br>HB6N                | HA036105064<br>HB6E                    |                                                   |  |  |  |  |  |
| 8         | Part No.<br>Model No.                                   | HA040118058<br>HB8N                | HA040118074<br>HB8E                                                              | HA040118058<br>HB8N                | HA040118074<br>HB8E                    | HA040118058<br>HB8N                | HA040118074<br>HB8E                    | 909RPDA (HA054153075)                             |  |  |  |  |  |
| 10        | Part No.<br>Model No.                                   | HA042142065<br>HB10N               | HA042142085<br>HB10E                                                             | HA042142085<br>HB10E               | HA042142085<br>HB10E                   | HA042142085<br>HB10E               | HA042142085<br>HB10E                   |                                                   |  |  |  |  |  |

|           | Backflow Preventer (N pattern) Sizing Guide by pipe size |                                |                                |                                   |                                   |                          |      |                                              |  |  |  |  |  |
|-----------|----------------------------------------------------------|--------------------------------|--------------------------------|-----------------------------------|-----------------------------------|--------------------------|------|----------------------------------------------|--|--|--|--|--|
|           |                                                          |                                | Box Enclosure<br>n clearance   |                                   | Box Enclosure<br>n clearance      | Standard Hotl<br>30" cei |      |                                              |  |  |  |  |  |
| Pipe Size |                                                          | NRS                            | OS&Y                           | NRS                               | OS&Y                              | NRS                      | OS&Y | Excluded bfp's                               |  |  |  |  |  |
| 2.5       | Part No.<br>Model No.                                    | HD/HM041041045<br>DF4FE/HB4FEM | HD/HM041041045<br>DF4FE/HB4FEM | HD/HM041041045<br>DF4FE/HB4FEM    | HD/HM041041045<br>DF4FE/HB4FEM    | n/a                      | n/a  |                                              |  |  |  |  |  |
| 3         | Part No.<br>Model No.                                    | HD/HM041041045<br>DF4FE/HB4FEM | HD/HM041041045<br>DF4FE/HB4FEM | HD/HM041041045<br>DF4FE/HB4FEM    | HD/HM041041045<br>DF4FE/HB4FEM    | n/a                      | n/a  |                                              |  |  |  |  |  |
| 4         | Part No.<br>Model No.                                    | HD/HM041041045<br>DF4FE/HB4FEM | HD/HM041041045<br>DF4FE/HB4FEM | HA/HD/HM047047049<br>DF6FE/HB6FEM | HA/HD/HM047047049<br>DF6FE/HB6FEM | n/a                      | n/a  |                                              |  |  |  |  |  |
| 6         | Part No.<br>Model No.                                    | HD/HM053053056<br>DF8FE/HB8FEM | HD/HM053053056<br>DF8FE/HB8FEM | HD/HM053053056<br>DF8FE/HB8FEM    | HD/HM053053056<br>DF8FE/HB8FEM    | n/a                      | n/a  |                                              |  |  |  |  |  |
| 8         | Part No.<br>Model No.                                    | HA045072060<br>HB8000ANT       | HA065072060<br>HB8000AET       | HA051096067<br>HB8FN-DT           | HA051096067<br>HB8FN-DT           | n/a                      | n/a  |                                              |  |  |  |  |  |
| 10        | Part No.<br>Model No.                                    | HA045082062<br>HB6FN-DT        | HA071105064<br>HB6E-D          | HA071105064<br>HB6E-D             | HA071105064<br>HB6E-D             | n/a                      | n/a  | 450OSY (HA083123074)<br>475OSY (HA083123074) |  |  |  |  |  |

The above enclosures are based from the largest backflow device for each pipe size unless listed in the "Excluded bfp's" column. Sizing verification is ultimately the responsibility of the customer For the unheated version replace the Hotbox part number prefix "H" with an "L"

Part numbering system: Prefix x Width x Length x Height

Prefix Definition: (digits 1 & 2)

HA Heated Sectional Aluminum
HD Heated Durafold Aluminum

HE Heated Drop Over Fiberglass
HF Heated Fliptop Fiberglass

HM Heated Designer Series

Heated Polyethylene drop over

LA Unheated Sectional Aluminum

LD Unheated Durafold Aluminum

LE Unheated Drop Over Fiberglass
LF Unheated Fliptop Fiberglass

LM Unheated Designer Series
LP Unheated Polyethylene drop over

Note: The enclosure recommendations are based on the largest backflow device for each pipe size unless listed in the "Excluded bfp's" column. Sizing verification is ultimately the responsibility of the customer. Customers are also responsible for verifying the clearances meet all local code requirements.








### **(**

# **Enclosure Selection-Manual Sizing**

### HOW TO SIZE A HOT BOX ENCLOSURE



#### Formulas:

| BW Backflow Width<br>WC Width Clearance |                                                       |                      |                                                             | Size  | Elbow<br>Length                     | Elbow<br>Style                    |
|-----------------------------------------|-------------------------------------------------------|----------------------|-------------------------------------------------------------|-------|-------------------------------------|-----------------------------------|
| + <u>WC</u>                             | <u>Width Clearance</u><br>=Enclosure Width            |                      |                                                             | 0.50  | 3.25                                | Threaded                          |
|                                         | -Eliciosare wiatii                                    |                      |                                                             | 0.75  | 3.75                                | Threaded                          |
|                                         |                                                       |                      |                                                             | 1.00  | 4.06                                | Threaded                          |
| BL                                      | Backflow Length                                       |                      |                                                             | 1.50  | 5.13                                | Threaded                          |
| EL                                      | Elbow Length                                          |                      |                                                             | 2.00  | 5.75                                | Threaded                          |
| EL                                      | Elbow Length                                          |                      |                                                             | 2.50  | 8.50                                | Flanged                           |
| LC                                      | Length Clearance                                      |                      |                                                             | 3.00  | 9.25                                | Flanged                           |
| + LC                                    | Length Clearance                                      |                      |                                                             | 4.00  | 11.00                               | Flanged                           |
| 1                                       | =Enclosure Length                                     |                      |                                                             | 6.00  | 13.50                               | Flanged                           |
|                                         | Enclosure Length                                      |                      |                                                             | 8.00  | 15.75                               | Flanged                           |
|                                         |                                                       |                      |                                                             | 10.00 | 19.00                               | Flanged                           |
| ВН                                      | Backflow Height                                       | BTH                  | Backflow Top Height                                         | 12.00 | 21.50                               | Flanged                           |
| BC<br>+ <u>HC</u>                       | Backflow Clearance Height Clearance =Enclosure Height | OR CH<br>+ <u>HC</u> | Centerline Height <u>Height Clearance</u> =Enclosure Height |       | ngth on threade<br>ople for ease of | d elbows include<br>f attachment. |

See the backflow manufacturers website for the backflow dimensions.

w/ centerline

Hot Box suggests a minimum 3" clearance (each side) for 2" pipe and smaller and 6" clearance (each side) for  $2 \frac{1}{2}$ " pipe and larger. These clearances can be adjusted to better fit a particular Hot Box enclosure.



w/ bottom clearance







### **Hot Box® Select Six**

#### **SPECS MADE SIMPLE**

Hot Box® Select Six Enclosures are six enclosure sizes designed to accommodate standard and N-pattern pipe sizes from 2  $\frac{1}{2}$ " to 10" diameter.

- **Reduced Lead Times** A few enclosure sizes fit a variety of backflows.
- Durable and strong The aluminum enclosure is corrosion and UV resistant.
- Fast Access Dura Fold® design allows fast access via hinged and removable sections.
- Reliable Insulation will not sag or delaminate from the walls dues to its strong chemical bond to the aluminum.
- Safe Freeze Protection Wall-mounted heaters above the discharge point provide better performance and safety.
- Peace of Mind ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.
- Finish Options Available in a smooth mill finish aluminum or federal brown.















**(** 

#### Hot Box® - Dura Fold®

|                  |                                     | Inside Clearance (inches) |              |                  |           |             |                        |              |
|------------------|-------------------------------------|---------------------------|--------------|------------------|-----------|-------------|------------------------|--------------|
| Backflow<br>Type | Pipe Dia.   Width   Length   Height |                           | Weight (lbs) | Pad Size<br>(in) | Heater(s) | Part Number |                        |              |
| Standard         | 2 ½" - 3"                           | 26                        | 70           | 45               | 144       | 38 X 82     | (1) 1000W              | HD026070045L |
| Standard         | 4" - 6"                             | 32                        | 90           | 57               | 201       | 44 X 102    | (1) 2000W              | HD032090057L |
| N-Pattern        | 2 ½" - 4"                           | 38                        | 38           | 45               | 109       | 50 X 50     | (1) 1000W              | HD038038045L |
| N-Pattern        | 6" - 8"                             | 53                        | 53           | 53               | 185       | 65 X 65     | (1) 1500W              | HD053053053L |
| N-Pattern        | 10"                                 | 62                        | 68           | 58               | 248       | 74 X 80     | (1) 1000W<br>(1) 1500W | HD062068058L |

For unheated units, replace the "H" in the part# with an "L". For federal brown color, change the L in part number to M.



#### Hot Box® Sectional

|                  |              | Inside ( | Clearance ( | inches) |              |                  |            |              |
|------------------|--------------|----------|-------------|---------|--------------|------------------|------------|--------------|
| Backflow<br>Type | Pipe<br>Dia. | Width    | Length      | Height  | Weight (lbs) | Pad Size<br>(in) | Heater (s) | Part Number  |
| Standard         | 8" - 10"     | 36       | 118         | 80      | 333          | 48 X 130         | (2) 1500W  | HA036118080L |

For unheated units, replace the "H" in the part# with an "L". For federal brown color, change the L in part number to M.









### Hot Box® Aluminum Enclosures

Aluminum Hot Box® Enclosures are crafted from industrial stucco embossed aluminum (smooth mill finish optional). Aluminum is highly durable, and has a riveted construction for added strength. Commonly used for larger projects due to easy customization, aluminum provides both versatility and strength. You can be confident that your insulation will not sag or delaminate from the walls because of the bonded foam insulation. Optional wall-mounted heaters provide the safest and most effective prevention against freezing conditions. All standard models are ASSE 1060 certified, so you can specify and install a product that has been tested by 3rd party engineers. Benefits include:

- Superior Strength Riveted construction provides superior strength and durability.
- Reliable Insulation Spray up foam insulation provides 100% contact with box walls.
- Wall-Mounted Heaters Ensures economical performance and safety by keeping the heater off the ground and above discharge point.
- **Customizable Options** Built to fit your needs. Custom sizes and components such as vents, fans, and alarms are available.













### **(**

### Hot Box® Aluminum Enclosures

Hot Box® offers the broadest range of aluminum enclosures in the industry with many different styles and standard sizes. All are built with the same attention to quality and performance that you know and expect from a Hot Box Enclosure. Our comprehensive product offering is designed to ensure that your application requirements are met, and your expectations are exceeded.



#### **Dura Fold® Enclosures**

Save time and money with quick installation and easy access via hinged access panels and a hinged lid for future testing and maintenance. Dura Fold Enclosures also include all the inherent benefits of our aluminum enclosures, like corrosion and UV resistance, bonded foam insulation, and wall mounted heaters.



### **Single Aluminum Enclosures**

Save time and money during installation as you effortlessly connect two or four sections to assemble your Hot Box Enclosure on-site.



#### **Dual Aluminum Enclosures**

Wider design to accommodate dual and tandem installations, with all the same benefits of our sectional aluminum enclosures.



#### **Custom Aluminum Enclosures**

Innovative custom enclosures by Hot Box are built to fit your specific project. If your project requires pumps, meter bypasses, FDC hookup, custom sizing or custom colors, Hot Box has a full staff of design engineers ready to assist.







### **Dura Fold® Aluminum Enclosures**

Dura Fold® Enclosures feature an innovative design that helps you save time and money. Unique design features facilitate quick installation and easy access for future testing and maintenance. Key benefits include:

- Quick Installation & Easy Access Dura Fold® Enclosures ship assembled to allow quick installation. The design includes hinged walls, as well as front and top lids, to provide easy access. Also the front wall is easily removed to provide unobstructed access for equipment testing and maintenance after installation.
- Corrosion & Scratch Resistant Stucco embossed aluminum sheeting provides a corrosion proof and scratch resistant finish that looks good and stands up to the elements.
- Peace of Mind ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.



- Superior Protection Insulation will not sag or delaminate from the walls due to the strong chemical bond between the aluminum and the insulation. Heaters and/or heat trace tape can provide proven freeze protection.
- Bottom-line, when time and money matter, install a Dura Fold® Enclosure every time!

For unheated units, replace the "H" in the part# with an "L". Pad size=inside Dimensions + 12".

| Catalog Part<br>Number | Model<br>Number | Inside<br>Width (in) | Inside<br>Length (in) | Inside<br>Height (in) | Heater(s) | Weight # |
|------------------------|-----------------|----------------------|-----------------------|-----------------------|-----------|----------|
| HD011019022            | DF.75H          | 11                   | 19                    | 22                    | 30W       | 27       |
| HD013027023            | DF1H            | 13                   | 27                    | 23                    | 60W       | 35       |
| HD013027035            | DF1TH           | 13                   | 27                    | 35                    | 60W       | 44       |
| HD013039028            | DF2H            | 13                   | 39                    | 28                    | 90W       | 48       |
| HD013039036            | DF2TH           | 13                   | 39                    | 36                    | 90W       | 56       |
| HD013047028            | DF2SH           | 13                   | 47                    | 28                    | 90W       | 54       |
| HD013047036            | DF2STH          | 13                   | 47                    | 36                    | 90W       | 64       |
| HD021033024            | DF1.5H          | 21                   | 33                    | 24                    | 60W       | 46       |
| HD022060030            | DF2.5H          | 22                   | 60                    | 30                    | (2)-90W   | 78       |
| HD022060042            | DF2.75H         | 22                   | 60                    | 42                    | (2)-90W   | 96       |
| HD024039032            | DF2000H         | 24                   | 39                    | 32                    | 90W       | 65       |
| HD025053032            | DF2100H         | 25                   | 53                    | 32                    | 1000W     | 77       |
| HD026070045            | DF3NH           | 26                   | 70                    | 45                    | 1000W     | 118      |
| HD026070055            | DF3EH           | 26                   | 70                    | 55                    | 1500W     | 135      |
| HD026083045            | DF3NSH          | 26                   | 83                    | 45                    | 1500W     | 133      |
| HD026083055            | DF3ESH          | 26                   | 83                    | 55                    | 1500W     | 154      |
| HD029060037            | DF3000H         | 29                   | 60                    | 37                    | 1000W     | 85       |
| HD032037035            | DFS4FOH         | 32                   | 37                    | 35                    | 1000W     | 93       |
| HD032090050            | DF4NH           | 32                   | 90                    | 50                    | 1900W     | 163      |
| HD032090057            | DF4EH           | 32                   | 90                    | 57                    | 1900W     | 201      |
| HD033053044            | DF4000H         | 33                   | 53                    | 44                    | 1000W     | 107      |
| HD037043040            | DFS6FOH         | 37                   | 43                    | 40                    | 1000W     | 108      |
| HD041041045            | DF4FEH          | 41                   | 41                    | 45                    | 1000W     | 104      |
| HD042052044            | DFS8FOH         | 42                   | 52                    | 44                    | 1500W     | 138      |
| HD043053036            | DF2200H         | 43                   | 53                    | 36                    | 1000W     | 127      |
| HD047047049            | DF6FEH          | 47                   | 47                    | 49                    | 1500W     | 128      |
| HD048063050            | DFS10F0H        | 48                   | 63                    | 50                    | 1900W     | 175      |
| HD053053056            | DF8FEH          | 53                   | 53                    | 56                    | 1500W     | 179      |
| HD053062042            | DF3100H         | 53                   | 62                    | 42                    | 1500W     | 164      |
| HD054062056            | DF10FEH         | 54                   | 62                    | 56                    | 1900W     | 194      |












# **Dura Fold® Aluminum Enclosures**



**(** 












- Quick & Easy Installation Modular design with a maximum of 4 tongue and groove sections.
- **Easy Access** Lightweight removable doors can easily be removed by one person.
- **Peace of Mind -** ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.
- Superior Freeze Protection Insulation will not sag or delaminate from the walls due to the strong chemical bond between the aluminum and insulation. Wall-mounted heaters are installed above the discharge point to provide better long-term performance and safety.
- **Finish Options** Stucco embossed aluminum is standard. Also available in a smooth mill finish aluminum or optional colors (see page 49 for details).






For unheated units, replace the "H" in the part# with an "L". Pad size=inside Dimensions + 12".







# **Single Aluminum**



**(** 



Page 19

ALUMINUM FOUR SECTION



(TYP)

### **Dual Aluminum**

Wider design for dual or tandem installations. Doors on both sides of the enclosure improve access. Key benefits include (see page 49 for finish and color options):

- Quick & Easy Installation Modular design with a maximum of 4 tongue and groove sections.
- Easy Access Lightweight removable doors can easily be removed by one person.
- Peace of Mind ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.



■ **Superior Freeze Protection -** Insulation will not sag or delaminate from the walls due to the strong chemical bond between the aluminum and insulation. Wall-mounted heaters are installed above the discharge point to provide better long-term performance and safety.

For unheated units, replace the "H" in the part# with an "L". Pad size=inside Dimensions + 12".


| Catalog Part<br>Number | Model<br>Number |    | Inside<br>Length (in) | Inside<br>Height (in) | Heater(s)           |   | Weight # |
|------------------------|-----------------|----|-----------------------|-----------------------|---------------------|---|----------|
| HA055074057            | HB3E-D          | 55 | 74                    | 57                    | (2) 1000W           | 2 | 223      |
| HA055085057            | HB3E-DS         | 55 | 85                    | 57                    | (2) 1000W           | 2 | 239      |
| HA067090050            | HB4N-D          | 67 | 90                    | 50                    | (2) 1500W           | 2 | 251      |
| HA067090057            | HB4E-D          | 67 | 90                    | 57                    | (2) 1500W           | 2 | 270      |
| HA067102050            | HB4N-DS         | 67 | 102                   | 50                    | (2) 1500W           | 2 | 275      |
| HA067102057            | HB4E-DS         | 67 | 102                   | 57                    | (2) 1500W           | 2 | 291      |
| HA071105053            | HB6N-D          | 71 | 105                   | 53                    | (2) 1500W           | 4 | 338      |
| HA071105064            | HB6E-D          | 71 | 105                   | 64                    | (2) 1500W           | 4 | 375      |
| HA071125053            | HB6N-DS         | 71 | 125                   | 53                    | (2) 1500W           | 4 | 373      |
| HA071125064            | HB6E-DS         | 71 | 125                   | 64                    | (2) 1500W           | 4 | 415      |
| HA083123058            | HB8N-D          | 83 | 123                   | 58                    | (2) 1900W           | 4 | 452      |
| HA083123074            | HB8E-D          | 83 | 123                   | 74                    | (2) 1900W           | 4 | 519      |
| HA083145058            | HB8N-DS         | 83 | 145                   | 58                    | (2) 1900W           | 4 | 491      |
| HA083145074            | HB8E-DS         | 83 | 145                   | 74                    | (2) 1000W (2) 1500W | 4 | 564      |
| HA087144065            | HB10N-D         | 87 | 144                   | 65                    | (2) 1500W (2) 1900W | 4 | 571      |
| HA087144085            | HB10E-D         | 87 | 144                   | 85                    | (4) 1500W           | 4 | 674      |
| HA087172065            | HB10N-DS        | 87 | 172                   | 65                    | (2) 1500W (2) 1900W | 4 | 651      |
| HA087172085            | HB10E-DS        | 87 | 172                   | 85                    | (4) 1500W           | 4 | 766      |
| HA038060043            | HB3FN-D         | 38 | 60                    | 43                    | (1) 1500W           | 2 | 145      |
| HA038060048            | HB3FN-DT        | 38 | 60                    | 48                    | (1) 1500W           | 2 | 155      |
| HA038080043            | HB3FE-D         | 38 | 80                    | 43                    | (1) 1500W           | 2 | 194      |
| HA038080048            | HB3FE-DT        | 38 | 80                    | 48                    | (1) 1500W           | 2 | 200      |
| HA040066045            | HB4FN-D         | 40 | 66                    | 45                    | (1) 1500W           | 2 | 159      |
| HA040066051            | HB4FN-DT        | 40 | 66                    | 51                    | (1) 1500W           | 2 | 171      |
| HA040085045            | HB4FE-D         | 40 | 85                    | 45                    | (1) 1900W           | 2 | 207      |
| HA040085051            | HB4FE-DT        | 40 | 85                    | 51                    | (1) 1900W           | 2 | 222      |
| HA045082051            | HB6FN-D         | 45 | 82                    | 51                    | (2) 1000W           | 2 | 229      |
| HA045082062            | HB6FN-DT        | 45 | 82                    | 62                    | (2) 1000W           | 2 | 256      |
| HA045106051            | HB6FE-D         | 45 | 106                   | 51                    | (2) 1000W           | 2 | 260      |
| HA045106062            | HB6FE-DT        | 45 | 106                   | 62                    | (1) 1000W (1) 1500W | 2 | 296      |
| HA051096054            | HB8FN-D         | 51 | 96                    | 54                    | (1) 1000W (1) 1500W | 2 | 269      |
| HA051096067            | HB8FN-DT        | 51 | 96                    | 67                    | (2) 1500W           | 2 | 307      |
| HA051124054            | HB8FE-D         | 51 | 124                   | 54                    | (2) 1500W           | 4 | 325      |
| HA051124067            | HB8FE-DT        | 51 | 124                   | 67                    | (1) 1500W (1) 1900W | 4 | 366      |
| HA054112059            | HB10FN-D        | 54 | 112                   | 59                    | (2) 1500W           | 2 | 317      |
| HA054112075            | HB10FN-DT       | 54 | 112                   | 75                    | (1) 1500W (1) 1900W | 2 | 365      |
| HA054153059            | HB10FE-D        | 54 | 153                   | 59                    | (2) 1900W           | 4 | 394      |
| HA054153075            | HB10FE-DT       | 54 | 153                   | 75                    | (2) 1900W           | 4 | 453      |







## **Dual Aluminum**



**(** 





## **Hot Box® Custom Enclosures**

Do you have a unique project or application? Hot Box® Enclosures have you covered!

Innovative custom Hot Box® Enclosures can be built to fit your specific project. If your project requires pumps, meter bypasses, FDC hookup, custom sizing, options, or custom colors, a full staff of design engineers are available to assist.

For a quote on a custom enclosure, please fill out the checklist on the opposite page and forward it to your area sales representative. The **minimum** information needed to quote a custom enclosure is:

1) Size of the enclosure 2) Heat required 3) Ventilation required.

- **Standard options include:** vents, exhaust fans, alarm and lighting packages, and special colors (see pages 45-49 for details).
- **Specialized options include:** penetrations, FDC boots, stainless steel anchors, hinged doors, acrylic windows, extra insulation, sound insulation, special voltage heaters, explosion proof heaters/equipment, and different material types like 3003 Mill Finish (.05") or 5052 Marine Grade aluminum (.050" or .125"). Contact your representative for details or any other special requirements.

#### **Please Note:**

Orders for custom enclosures cannot be cancelled once production has begun. In addition, custom enclosures are non-returnable.



**Custom Enclosure-Boeing** 



**Custom Enclosure-NASA** 



Custom Enclosure-Gainesville Speedway









# **Custom Enclosure Backflow Prevention Equipment Checklist**

Please fill out completely and send to your local manufacturer representative or customer service representative:

| Installation Type:    | nstallation Heigh  | nt: Pipe                           | e Size:             |             | Valve Typ      | e:      | Backflow Manufacturer: |
|-----------------------|--------------------|------------------------------------|---------------------|-------------|----------------|---------|------------------------|
| Single Line           | 12" Bottom Clearan | nce 🔲 1                            | 1/4"                | 3/8"        | ☐ QT           |         | ☐ Ames                 |
| Dual (Manifold)       | 18" Bottom Clearan | nce                                | 5/8" 3/4"           | <b>1</b> "  | ☐ OS&Y         |         | Apollo/Conbraco        |
| Tandem (2 Separate)   | 30" Center line    |                                    | 1-1/4"              | <br>□ 2"    | ☐ NRS          |         | ☐ Febco                |
| Pump (see below)*     | Other:             |                                    | 2-1/2"  3"          | □ -<br>□ 4" | ☐ Butterfly    | Valves  | ☐ Watts                |
| Other:                |                    |                                    | _                   |             | Other:         |         | Wilkins                |
|                       |                    |                                    | 5"                  | <u> </u>    |                |         | Model #:               |
|                       |                    |                                    | 12"                 | <u> </u>    |                |         | Wiodei #.              |
|                       |                    |                                    | 18" 🗌 20"           | 24"         |                |         | Other:                 |
|                       |                    | '                                  | Varies (please expl | ain)        |                |         |                        |
|                       |                    | Othe                               | er:                 |             |                |         |                        |
| Please continue for m | neters or additio  | nal back                           | flow device:        |             | I              |         |                        |
|                       |                    |                                    |                     |             |                |         |                        |
| Valve Type:           | Backflow Manuf     | facturer:                          | Meter Manu          | ıfacture    | <u>r:</u>      | Meter T | ype: Strainer Type:    |
| □ QT                  | Ames               |                                    | ☐ Badger            | N           | Metron Farnier | Comp    | ound Wye               |
| OS&Y                  | Apollo/Conbraco    | )                                  | Elster              |             | leptune        | Fire Li | ne Plate               |
| NRS                   | Febco              |                                    | Hersey              | S           | ensus/Omni     | Turbir  | ne Basket              |
| Butterfly Valves      | ☐ Watts            |                                    | Master Met          | er          |                |         | ☐ None                 |
| Other:                | Wilkins            |                                    | Model #:            |             |                |         |                        |
|                       | Model #:           |                                    |                     |             |                |         |                        |
|                       |                    |                                    | Other:              |             |                |         |                        |
|                       | Other:             |                                    |                     |             |                |         |                        |
| Additional Equipment: |                    |                                    |                     |             |                |         |                        |
|                       | Aut                | ditional Req<br>ase be specific    |                     |             |                |         |                        |
|                       |                    | ase be specific,                   | ).<br>              |             |                |         |                        |
|                       | r Bypass           | mp Enclosui                        | rec.                |             |                |         |                        |
| PRV Solen             | ioid               | •                                  |                     |             |                |         |                        |
| Test Tee Wafe         |                    | te: If quoting t<br>np or pumps, p |                     |             |                |         |                        |
| Other:                |                    | np dimensions<br>cifications to th |                     |             |                |         |                        |
| Model #:              |                    | se include clea                    |                     |             |                |         |                        |
|                       |                    |                                    |                     |             |                |         |                        |
|                       |                    |                                    |                     |             |                |         |                        |
|                       |                    |                                    |                     |             |                |         |                        |
|                       |                    |                                    |                     |             |                |         |                        |
| Job Name:             |                    |                                    | Job L               | ocation:    |                |         |                        |
| Engineer/Contractor:  |                    | Phone:                             |                     | Fax:        |                | e-mail: |                        |
| Distributor:          |                    | Phone:                             |                     | Fax:        |                | e-mail: |                        |
| Representative:       |                    | Phone:                             |                     | Fax:        |                | e-mail: |                        |
|                       |                    |                                    |                     |             |                |         |                        |









## **Hot Box® Fiberglass Enclosures**

Hot Box® Fiberglass Enclosures are hand crafted to a yacht quality finish to ensure they remain both aesthetically pleasing and meet the needs of your project. The enclosures are built from only the highest quality fiberglass and gelcoat material. The design incorporates bonded foam insulation, and is built to enclose most backflows available on the market (up to a 4" device). Offering the most comprehensive line of heated and unheated sizes in the market, all standard fiberglass enclosures meet the latest ASSE 1060 performance standards—ensuring that you are purchasing from a dependable source. Benefits include:

- **Enduring Quality** Yacht quality finish with a UV stabilized marine grade gelcoat provides years of protection for your equipment.
- **Reliable Insulation** All Hot Box models come with spray foam insulation. Spray foam promotes 100% bonding with the interior wall of the enclosure, preventing deformation in freeze/thaw conditions. Unlike board foam insulation, spray foam insulation will not delaminate and remains firmly affixed to the enclosure's walls.
- **Better Choices** Many different styles and sizes of fiberglass models are available to quickly meet your needs.
- **Optional Accessories-** Add a vent, fan, or alarm to your fiberglass enclosure to make it suitable for a pump or other equipment that needs to be kept cool.







Installation photos of model HB1 with Glass Pad™ mounting base







### $\mathcal{D}$

## **Hot Box® Fiberglass Enclosures**

Hot Box® offers the broadest range of fiberglass enclosures in the industry with many different styles and standard sizes. All are built with the same attention to quality and performance that you know and expect from Hot Box. Our comprehensive product offering is designed to ensure that your application requirements are met, and your expectations are exceeded.



### **Designer Series™ Enclosures**

Save time and money with quick installation and easy access via hinged access panels, and an opening lid which makes future testing and maintenance easy. Designer Series Enclosures also come with all the other inherent benefits of our fiberglass enclosures, like corrosion and UV resistance, bonded foam insulation, and wall-mounted heaters.



### Flip-Top Fiberglass Enclosures

A convenient flip-top lid provides fast and easy backflow access. Weatherproof and vandal resistance is built in with its overlapping lid design.



#### **EZ Box® Enclosures**

This economical one piece drop-over design allows quick and easy installation. Ideal for landscape and irrigation applications where future access needs are limited.



#### Vent Guard® & Valve Cover™ Enclosures

Vent Guard is a protective enclosure designed specifically for the air release valves found in many public water supply systems. Valve Cover hinged enclosures are a good choice for landscape and irrigation applications where ease of access for future maintenance is desired.







#### •

## **Designer Series™ Enclosures**

Designer Series™ Enclosures are innovative fiberglass enclosures that are perfect when ease of installation and full equipment access are top priorities. Unique design features facilitate quick installation and easy access for future testing and maintenance. Key benefits include:

- Quick Installation & Easy Access Designer Series™ Enclosures require minimal installation time. They incorporate easily removable hinged front and rear doors, as well as top lid with gas shock supports. This design provides instant, unobstructed access for equipment testing and maintenance.
- Corrosion & UV Resistant Yacht quality fiberglass with a smooth, UV resistant gelcoat provides a corrosion proof finish that both looks good and stands up to the elements.
- **High Security** Lockable top lid and internal locks are on both the front and rear doors. Interior steel anchors secure the enclosure to the concrete slab.
- **Peace of Mind** ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.
- **Superior Freeze Protection** Insulation will not sag or delaminate from the walls due to the strong chemical bond between the fiberglass and the insulation. Wall-mounted heaters are installed above the discharge point to provide better long-term performance and safety.

Note: Standard fiberglass color is beige (optional colors are available-see page 49 for details).

#### Pad size=inside Dimensions + 12".

| Catalog Part<br>Number | Model Number | Inside<br>Width (in) | Inside<br>Length (in) | Inside<br>Height (in) | Heater<br>(if required) | Weight # |
|------------------------|--------------|----------------------|-----------------------|-----------------------|-------------------------|----------|
| LM041041045            | LB4FEM       | 41                   | 41                    | 44                    | Unheated                | 241      |
| LM047047049            | LB6FEM       | 47                   | 47                    | 48                    | Unheated                | 287      |
| LM053053056            | LB8FEM       | 52                   | 52                    | 55                    | Unheated                | 352      |
| LM054062056            | LB10FEM      | 52                   | 63                    | 55                    | Unheated                | 389      |
| HM041041045            | HB4FEM       | 41                   | 41                    | 44                    | 1000W                   | 253      |
| HM047047049            | HB6FEM       | 47                   | 47                    | 48                    | 1500W                   | 299      |
| HM053053056            | HB8FEM       | 52                   | 52                    | 55                    | 1500W                   | 364      |
| HM054062056            | HB10FEM      | 52                   | 63                    | 55                    | 1900W                   | 401      |


Pad size=inside Dimensions + 12".







# **Designer Series<sup>™</sup> Enclosures**



**(** 



## Flip-Top Fiberglass Enclosures

- Easy Maintenance Access Flip top lid design provides quick access.
- Weatherproof & Vandal Resistance -Overlapping lid seam design helps keep vandals and mother nature out. Also includes a lockable top and steel anchors (padlocks are not included).
- Durable & Corrosion Resistant Reinforced fiberglass with a smooth, UV
  resistant gelcoat provides a corrosion
  proof finish that both looks good and
  stands up to the elements.



- Superior Freeze Protection Wallmounted heater or self-regulating heat trace tape provides freeze protection.
- **Peace of Mind -** ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.

Note: Standard fiberglass color is beige (optional colors are available-see page 49 for details). Also available as uninsulated enclosures (see page 35).

For unheated units, replace the "H" in the part# with an "L". Pad size=inside Dimensions + 12".

| Catalog Part<br>Number | Model<br>Number | Inside<br>Width (in) | Inside<br>Length (in) | Inside<br>Height (in) | Heater(s) | Glass Pad   | Weight # |
|------------------------|-----------------|----------------------|-----------------------|-----------------------|-----------|-------------|----------|
| HF011019022            | HB.75           | 10                   | 18                    | 23                    | 30W       | GG019027005 | 28       |
| HF013027023            | HB1             | 13                   | 26                    | 23                    | 60W       | GG021035005 | 32       |
| HF013027035            | HB1T            | 13                   | 26                    | 36                    | 60W       | GG021035005 | 57       |
| HF013039028            | HB2             | 13                   | 38                    | 29                    | 90W       | GG021047005 | 54       |
| HF013039036            | HB2T            | 12                   | 38                    | 36                    | 90W       | GG021047005 | 65       |
| HF013047028            | HB2S            | 10                   | 44                    | 28                    | 90W       | N/A         | 64       |
| HF013047036            | HB2ST           | 13                   | 47                    | 36                    | 90W       | N/A         | 98       |
| HF021033025            | HB1.5           | 21                   | 33                    | 25                    | 60W       | GG029042005 | 55       |
| HF025039028            | HB2-D           | 25                   | 39                    | 28                    | (2) 90W   | N/A         | 124      |
| HF025039036            | HB2-DT          | 25                   | 39                    | 36                    | (2) 90W   | N/A         | 148      |
| HF025047028            | HB2-DS          | 25                   | 47                    | 28                    | (2) 90W   | N/A         | 139      |
| HF025047036            | HB2-DST         | 25                   | 47                    | 36                    | (2) 90W   | N/A         | 168      |
| HF026070045            | HB3N            | 27                   | 70                    | 46                    | 1000W     | N/A         | 241      |
| HF026070055            | HB3E            | 26                   | 70                    | 55                    | 1500W     | N/A         | 322      |
| HF026083045            | HB3NS           | 26                   | 83                    | 45                    | 1500W     | N/A         | 308      |
| HF026083055            | HB3ES           | 26                   | 83                    | 55                    | 1500W     | N/A         | 374      |
| HL035045035            | HB3000          | 35                   | 44                    | 35                    | 1000W     | N/A         | 170      |
| HL044053044            | HB4000          | 44                   | 53                    | 45                    | 1000W     | N/A         | 251      |
| HL052061052            | HB5000          | 52                   | 61                    | 51                    | 1500W     | N/A         | 320      |


For unheated units, replace the "H" in the part# with an "L". Pad size=inside Dimensions + 12".







# Flip-Top Fiberglass Enclosures



**(** 








#### •


### **EZ Box® Enclosures**

- Quick & Easy Installation Drop-over design is quick and easy to install.
- Affordable Cost effective design is ideal for applications requiring limited access.
- Durable & Corrosion Resistant -Reinforced fiberglass with a smooth, UV resistant gelcoat provides a corrosion proof finish that both looks good and stands up to the elements.
- **Superior Freeze Protection -** Wall-mounted heater or self-regulating heat trace tape provides freeze protection.



Note: Standard fiberglass color is beige (optional colors are available-see page 49 for details). Also available as uninsulated enclosures (see page 35).






For unheated units, replace the "H" in the part# with an "L". Pad size=inside Dimensions + 12". \*\*Catalog Part# LE026070045 through LE052061050 without doors are not ASSE Certified.







# **EZ Box<sup>®</sup> Enclosures**



**(** 






#### •

### **Vent Guard® Enclosures**

- **Durable & Fast Installation -** Lightweight enclosure and reinforced exterior mounting flange make installation a breeze (optional interior mounting plates available).
- Easy Maintenance Quick access without removal of entire unit via hinged and removable lid.
- Maximum Air Flow 4" round or 12" square vents are designed to provide proper air flow for air release valves.
- Durable & Corrosion Resistant Reinforced fiberglass with a smooth, UV
  resistant gelcoat provides a corrosion
  proof finish that both looks good and stands up to the elements.



Note: Standard fiberglass color is beige (optional colors are available-see page 49 for details).

#### Pad size=inside Dimensions + 12".

| Catalog Part<br>Number | Model<br>Number | Inside<br>Width (in) | Inside<br>Length (in) | Inside<br>Height (in) | Glass Pad   | Weight # |
|------------------------|-----------------|----------------------|-----------------------|-----------------------|-------------|----------|
| LV018018024            | AVG1824         | 18                   | 18                    | 24                    | GG028028005 | 43       |
| LV020020036            | AVG2036         | 20                   | 20                    | 36                    | N/A         | 71       |
| LV020020041            | AVG2041         | 20                   | 20                    | 41                    | N/A         | 77       |
| LV022022040            | AVG2240         | 22                   | 22                    | 40                    | N/A         | 90       |
| LV024024048            | AVG2448         | 24                   | 24                    | 48                    | N/A         | 108      |
| LV036036048            | AVG3648         | 36                   | 36                    | 48                    | N/A         | 180      |
| LV048048048            | AVG4848         | 48                   | 48                    | 48                    | N/A         | 210      |

Pad size=inside Dimensions + 12".










# **Vent Guard® Enclosures**



**(** 

LOCKING DETAIL
4 PLACES





Page 33

### **Valve Cover™ Enclosures**

- **Durable & Fast Installation -** Lightweight enclosure and reinforced exterior mounting flange make installation a breeze.
- Easy Maintenance Quick access without removal of entire unit via hinged lid.
- Durable & Corrosion Resistant Reinforced fiberglass with a smooth, UV
  resistant gelcoat provides a corrosion
  proof finish that both looks good and
  stands up to the elements.
- Peace of Mind ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.




Note: Standard fiberglass color is beige (optional colors are available-see page 49 for details). Also available as uninsulated enclosures (see page 35).

#### Pad size=inside Dimensions + 12".

| Catalog Part<br>Number | Model Number | Inside<br>Width (in) | Inside<br>Length (in) | Inside<br>Height (in) | Heater   | Weight # |
|------------------------|--------------|----------------------|-----------------------|-----------------------|----------|----------|
| LC009018018            | VC1          | 9                    | 18                    | 19                    | Unheated | 32       |
| LC009018024            | VC1T         | 9                    | 18                    | 26                    | Unheated | 41       |
| LC012026020            | VC2          | 12                   | 27                    | 21                    | Unheated | 47       |
| LC012026028            | VC2T         | 12                   | 27                    | 27                    | Unheated | 55       |
| HC009018018            | VCH1         | 9                    | 18                    | 19                    | 30W      | 33       |
| HC009018024            | VCH1T        | 9                    | 18                    | 26                    | 30W      | 42       |
| HC012026020            | VCH2         | 12                   | 27                    | 21                    | 60W      | 48       |
| HC012026028            | VCH2T        | 12                   | 27                    | 27                    | 60W      | 56       |

#### Pad size=inside Dimensions + 12".









**Valve Guard® Uninsulated Enclosures** 

Valve Guard® Enclosures are constructed with the same quality and attention to detail as our standard enclosures, only they are uninsulated and provide no resistance to freezing temperatures. They are intended for improved aesthetics and security purposes only, **not for freeze protection** (ASSE Class III). Order insulated and heated enclosures for colder climates (see page 5 for details):

Class III - Non-Freeze Protection Enclosures (Uninsulated Non-Heated): Designed and constructed to provide system security for components when freezing temperatures are not a consideration.

| EZ (Note 1)          | Old EZ No.         | Enclosure Size<br>(Inside - in) | <b>Mounting Pad</b>    | Glass Pad   | Shipping<br>Weight |
|----------------------|--------------------|---------------------------------|------------------------|-------------|--------------------|
| VE012017021500       | VGEZLV.75          | 14W x 19L x 22.5H 29 x 24 N/A   |                        | 25#         |                    |
| VE014021024500       | VGEZLV1            | 16W x 19L x 25H                 | 33 x 26                | N/A         | 28#                |
| VE006020022          | VGEZ.75            | 8.5W x 22L x 23H                | 32 x 16                | N/A         | 16#                |
| VE014027026          | VGEZ1              | 16W x 29L x 27H                 | 38 x 25                | GG026040005 | 31#                |
| VE012038028          | VGEZ2              | 14W x 40.5L x 29H               | 48 x 22                | GG022056005 | 44#                |
| VE013047027          | VGEZ2S             | 15W x 49L x 28H                 | 59 x 22                | N/A         | 49#                |
| VE026070045          | VGEZ3              | 29W x 73L x 46H                 | 82 x 38                | N/A         | 215#               |
| VE035045035          | VGEZ3000           | 38W x 48L x 36H                 | 57 x 47                | N/A         | 175#               |
| VE044053044          | VGEZ4000           | 47W x 56L x 45H                 | 65 x 56                | N/A         | 240#               |
| VE052061050          | VGEZ5000           | 55W x 64L x 51H                 | 74 x 64                | N/A         | 400#               |
|                      | , 022000           | OOT X O I Z X O II .            | 71701                  | . ,, , ,    |                    |
| POLY EZ (Note 2)     | Old Poly EZ No     | Enclosure Size<br>(Inside)      | <b>Mounting Pad</b>    | Glass Pad   | Shipping<br>Weight |
| VP009024023G or T    |                    | 11W x 26L x 24H                 | 34 x 17                | GG021035005 | 22#                |
| VP011036026G or T    | VGPEZ1             | 13W x 38L x 27H                 | 45 x 19                | GG021047005 | 35#                |
|                      |                    |                                 |                        |             |                    |
| Valve Guard (Note 1) | Old Valve<br>Guard | Enclosure Size<br>(Inside)      | <b>Mounting Pad</b>    | Glass Pad   | Shipping<br>Weight |
| VF011019022          | VG.75              | 13W x 21L x 23H                 | 28 x 20                | GG019027005 | 21#                |
| VF013027023          | VG1                | 15W x 29L x 24H                 | 36 x 22                | GG021035005 | 31#                |
| VF013027023          | VG1T               | 15W x 29L x 36H                 | 36 x 22                | GG021035005 | 41#                |
| VF021033025          | VG1.5              | 23W x 35L x 26H                 | 44 x 32                | GG029042005 | 46#                |
| VF013039028          | VG2                | 15W x 41L x 29                  | 50 x 24                | GG021047005 | 45#                |
| VF013039036          | VG2T               | 15W x 41L 37H                   | 50 x 24                | GG021047005 | 56#                |
| VF013047028          | VG2S               | 15W x 49L x 29H                 | 58 x 24                | N/A         | 51#                |
| VF013047028          | VG3N               | 29W x 73L x 46H                 | 82 x 38                | N/A         | 270#               |
| VL035045035          | VG3000             | 38W x 48L x 36H                 | 57 x 47                | N/A         | 220#               |
| VL044053044          | VG4000             | 47W x 56L x 45H                 | 65 x 56                | N/A         | 270#               |
| VL052061052          | VG5000             | 55W x 64L x 53H                 | 74 x 64                | N/A         | 410#               |
|                      |                    |                                 |                        | ,           |                    |
| Glass Roks (Note 1)  | Old Glass Roks     | Enclosure Size<br>(Inside)      | Mounting Pad Glass Pad |             | Shipping<br>Weight |
| VR006015019          | VGGLR.75           | 09W x 18L x 20H                 | 27 x 21                | N/A         | 20#                |
| VR010026022          | VGGLR1             | 13W x 29L x 22H                 | 40 x 30                | N/A         | 41#                |
| VR015040030          | VGGLR2             | 18W x 43L x 31H                 | 51 x 26                | N/A         | 75#                |
| VR021067043          | VGGLR3             | 24W x 70L x 44H                 | 90 x 40                | N/A         | 310#               |
|                      |                    |                                 |                        |             |                    |
| Poly Roks (Note 2)   | Old Poly Roks      | Enclosure Size<br>(Inside)      | Mounting Pad           | Glass Pad   | Shipping<br>Weight |
| VQ010026022          | VGPLR1             | 13W x 29L x 23H                 | 40 x 27                | GG027036005 | 25#                |
| VQ012043027          | VGPLR2             | 15W x 46L x 28H                 | 56 x 22                | GG022056005 | 50#                |
| Valve Cover (Note 1) | Old Valve<br>Cover | Enclosure Size<br>(Inside)      | Mounting Pad<br>Size   | Glass Pad   | Shipping<br>Weight |
| VC009018018          | VGVC1              | 11W x 20L x 19H                 | 27 x 19                | GG019027005 | 25#                |
| VC009018024          | VGVC1T             | 11W x 20L x 25H                 | 27 x 19                | GG019027005 | 28#                |
| VC012026020          | VGVC2              | 14W x 28L x 21H                 | 35 x 21                | GG021035005 | 30#                |
| VC012026028          | VGVC2T             | 12W x 26L x 28                  | 35 x 21                | GG021035005 | 35#                |

- Note 1: Fiberglass enclosures are constructed of polyester resin with chopped glass.
- Note 2: Polyethylene enclosures consist of 1/8" thick UV stabilized LMDPE (Linear Medium Density Polyethylene).
- Mounting and access hardware is rust resistant and all enclosures are lockable.







#### •

## Poly EZ Box<sup>®</sup> (Plastic) Enclosures

- Quick & Easy Installation Drop-over design is quick and easy to install.
- Affordable Cost effective plastic enclosures ideal for landscape and irrigation applications.
- Weed Eater Resistant Anti-chipping plastic construction.
- UV & Corrosion Resistant UV stabilized plastic provides a corrosion proof enclosure that looks good and stands up to the elements.
- Freeze Protection Self-regulating heat trace tape provides proven freeze protection.



■ **Peace of Mind** - ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.

Note: Two standard colors available: beige or dark green. Also available as uninsulated enclosures (see page 35).

#### Pad size=inside Dimensions + 12".

| Catalog Part<br>Number | Model<br>Number | Inside<br>Width (in) | Inside<br>Length (in) | Inside<br>Height (in) | Heater   | Glass Pad   | Weight # |
|------------------------|-----------------|----------------------|-----------------------|-----------------------|----------|-------------|----------|
| LP009024023G           | PEZ1-Green      | 9                    | 24                    | 23                    | Unheated | GG021035005 | 14       |
| LP009024023T           | PEZ1-Beige      | 9                    | 24                    | 23                    | Unheated | GG021035005 | 14       |
| LP011036026G           | PEZ2-Green      | 11                   | 36                    | 26                    | Unheated | GG021047005 | 20       |
| LP011036026T           | PEZ2-Beige      | 11                   | 36                    | 26                    | Unheated | GG021047005 | 20       |
| HP009024023G           | HPEZ1-Green     | 9                    | 24                    | 23                    | 60W      | GG021035005 | 15       |
| HP009024023T           | HPEZ1-Beige     | 9                    | 24                    | 23                    | 60W      | GG021035005 | 15       |
| HP011036026G           | HPEZ2-Green     | 11                   | 36                    | 26                    | 90W      | GG021047005 | 22       |
| HP011036026T           | HPEZ2-Beige     | 11                   | 36                    | 26                    | 90W      | GG021047005 | 22       |


Pad size=inside Dimensions + 12".








# **Poly EZ Box® (Plastic) Enclosures**



**(** 

LOCKING DETAIL







### Fiberglass Hot Rok® Enclosures

- Enhances Landscape Natural rocklike texture and colors are visually appealing.
- Quick & Easy Installation Drop-over design with optional hinge for ease of maintenance on larger Roks.
- Durable & Corrosion Resistant Reinforced fiberglass with UV stable
  gelcoat exterior provides a corrosion
  proof finish that both looks good and
  stands up to the elements.
- Superior Freeze Protection Selfregulating heat trace tape provides proven freeze protection.



■ **Peace of Mind -** ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.

Note: Also available as uninsulated enclosures (see page 35).

For unheated units, replace the "H" in the part# with an "L".

| Catalog Part<br>Number | Model<br>Number | Style    | Color       | Inside<br>Width A<br>(in) | Inside<br>Length B<br>(in) | Inside<br>Height C<br>(in) | Heater | Weight # |
|------------------------|-----------------|----------|-------------|---------------------------|----------------------------|----------------------------|--------|----------|
| HR006015019E           | GHR.75          | Lift Off | Brown       | 8                         | 16                         | 19                         | 30W    | 25       |
| HR006015019N           | GHR.75          | Lift Off | Granite     | 8                         | 16                         | 19                         | 30W    | 25       |
| HR006015019S           | GHR.75          | Lift Off | Desert Rose | 8                         | 16                         | 19                         | 30W    | 25       |
| HR010026022E           | GHR1            | Lift Off | Brown       | 10                        | 24                         | 19.5                       | 60W    | 50       |
| HR010026022N           | GHR1            | Lift Off | Granite     | 10                        | 24                         | 19.5                       | 60W    | 50       |
| HR010026022S           | GHR1            | Lift Off | Desert Rose | 10                        | 24                         | 19.5                       | 60W    | 50       |
| HR010026022500         | GHR1            | Lift Off | Brown       | 10                        | 24                         | 19.5                       | 60W    | 50       |
| HR010026022501         | GHR1            | Lift Off | Granite     | 10                        | 24                         | 19.5                       | 60W    | 50       |
| HR010026022502         | GHR1            | Lift Off | Desert Rose | 10                        | 24                         | 19.5                       | 60W    | 50       |
| HR015040030E           | GHR2            | Lift Off | Brown       | 15                        | 40                         | 30                         | 90W    | 80       |
| HR015040030N           | GHR2            | Lift Off | Granite     | 15                        | 40                         | 30                         | 90W    | 80       |
| HR015040030S           | GHR2            | Lift Off | Desert Rose | 15                        | 40                         | 30                         | 90W    | 80       |
| HR015040030500         | GHR2            | Lift Off | Brown       | 15                        | 40                         | 30                         | 90W    | 80       |
| HR015040030501         | GHR2            | Lift Off | Granite     | 15                        | 40                         | 30                         | 90W    | 80       |
| HR015040030502         | GHR2            | Lift Off | Desert Rose | 15                        | 40                         | 30                         | 90W    | 80       |
| HR021067043E           | GHR3            | Hinged   | Brown       | 21                        | 73                         | 43                         | 2-90W  | 365      |
| HR021067043N           | GHR3            | Hinged   | Granite     | 21                        | 73                         | 43                         | 2-90W  | 365      |
| HR021067043S           | GHR3            | Hinged   | Desert Rose | 21                        | 73                         | 43                         | 2-90W  | 365      |

For unheated units, replace the "H" in the part# with an "L".

#### **Available Colors:**



Brown
Color code = E



Granite
Color code = N




Desert Rose Color code = S







### Fiberglass Hot Rok® Enclosures



#### Installation:

- Provide applicable GFI protected power, UL STND. 943-NEMA 3R, inside enclosures requiring heat. Mount at least 8" above any discharge point and near the pipe riser on the enclosure access side or install per local code.
- 2. Pour a full concrete pad 4" thick around valve, allowing a minimum 1" radial space between riser and pad or install on a "Glass Pad™".
- 3. Place Hot Rok® Enclosure over the valve onto the pad or footer.
- 4. Use a masonry bit to drill through anchor hinge. Insert concrete screws and bolt firmly to concrete.

- 5. Mark and mount locking hasp.
- 6. Mark and mount support rod anchor.
- 7. For heated enclosures using a self regulating heat trace tape, secure tape to valve with pipe ties or fiberglass/electrician's tape. No pipe insulation is necessary. The Hot Rok® Enclosure provides the necessary insulation.
- 8. Plug the heat source into the specified circuit/receptacle, after verifying proper voltage.
- 9. Lower and secure hasp to staple via pad lock (padlock not included).







### PolyRok® (Plastic) Enclosures

- Enhances Landscape Natural rocklike texture and colors are visually appealing.
- Quick & Easy Installation Drop-over design is quick and easy to install.
- **Affordable** Cost effective plastic enclosures ideal for landscape and irrigation applications.
- **Weed Eater Resistant -** Anti-chipping plastic construction.
- UV & Corrosion Resistant UV stabilized plastic provides a corrosion proof enclosure that looks good and stands up to the elements.
- **Freeze Protection** Self-regulating heat trace tape provides proven freeze protection.
- **Peace of Mind -** ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.

Note: Also available as uninsulated enclosures (see page 35).



| Catalog Part<br>Number | Model<br>Number | Color   | Inside<br>Width A<br>(in) | Inside<br>Length B<br>(in) | Inside<br>Height C<br>(in) | Heater   | Glass Pad   | Weight # |
|------------------------|-----------------|---------|---------------------------|----------------------------|----------------------------|----------|-------------|----------|
| LQ010026022E           | PLR1            | Brown   | 10                        | 26                         | 22                         | Unheated | GG027036005 | 17       |
| LQ010026022N           | PLR1            | Granite | 10                        | 26                         | 22                         | Unheated | GG027036005 | 17       |
| LQ012043027E           | PLR2            | Brown   | 12                        | 43                         | 27                         | Unheated | GG022056005 | 24       |
| LQ012043027N           | PLR2            | Granite | 12                        | 43                         | 27                         | Unheated | GG022056005 | 24       |
| HQ010026022E           | PHR1            | Brown   | 10                        | 26                         | 22                         | 60W      | GG027036005 | 18       |
| HQ010026022N           | PHR1            | Granite | 10                        | 26                         | 22                         | 60W      | GG027036005 | 18       |
| HQ012043027E           | PHR2            | Brown   | 12                        | 43                         | 27                         | 90W      | GG022056005 | 26       |
| HQ012043027N           | PHR2            | Granite | 12                        | 43                         | 27                         | 90W      | GG022056005 | 26       |

#### **Available Colors:**



Brown
Color code = E




Granite
Color code = N







### PolyRok® (Plastic) Enclosures



#### **Installation:**

- Provide applicable GFI protected power, UL STND. 943-NEMA 3R, inside enclosures requiring heat. Mount at least 6" above any discharge point and near the pipe riser on the enclosure access side or install per local code.
- 2. Pour a full concrete pad 4" thick around valve, allowing a minimum 1" radial space between riser and pad or install on a "Glass Pad™".
- 3. Place PolyRok® Enclosure over valve and onto the pad or footer.
- 4. Mark locking staple. Position on concrete.

- 5. Use a masonry bit to drill through anchor hinge. Insert concrete screws and bolt firmly to concrete.
- 6. For heated enclosures using a self regulating heat trace tape, secure tape to valve with pipe ties or fiberglass/electrician's tape. No pipe insulation is necessary. The PolyRok® Enclosure provides the necessary insulation.
- 7. Plug the heat source into the specified circuit/receptacle, after verifying proper voltage.
- 8. Lower and secure staple via pad lock (padlock not included).









### **Pump Guard Enclosures**

- Extended Pump Life Vented enclosures are designed to keep pumps cool and protected from the elements.
- Reduce Noise Keep neighbors happy by dampening the sound with standard insulated models (optional soundproof insulation available).
- Vandalism & Theft Deterrent Secure lockable enclosures can reduce unwanted access.
- Peace of Mind ASSE 1060 certification ensures that requirements for structural strength, drainage capacity, material construction, equipment access, and functional design are met.



■ Increased Cooling Performance - Optional fans and thermostatically controlled louvers can improve cooling performance (see page 46 for details).

Note: Available in all Designer Series, Flip-Top, and aluminum enclosures (popular models below). Standard fiberglass color is beige (optional colors are available-see page 49 for details).

For unheated units, replace the "H" in the part# with an "L". Pad size=inside Dimensions + 12".

| Catalog<br>Part Number | Model<br>Number | Access<br>Type       | Inside<br>Width (in) | Inside<br>Length (in) | Inside<br>Height (in) | Heater | Weight # |
|------------------------|-----------------|----------------------|----------------------|-----------------------|-----------------------|--------|----------|
| HF013027023AAV         | PG1000H         | Flip-Top             | 13                   | 27                    | 23                    | 60W    | 40       |
| HF021033025AAV         | PG1500H         | Flip-Top             | 21                   | 33                    | 25                    | 60W    | 60       |
| HL035045035AAV         | PG3000H         | Flip-Top             | 35                   | 45                    | 35                    | 1000W  | 250      |
| HL044053044AAV         | PG4000FH        | Flip-Top             | 44                   | 53                    | 44                    | 1000W  | 300      |
| HL052061052AAV         | PG5000H         | Flip-Top             | 52                   | 61                    | 52                    | 1500W  | 440      |
| HM041041045AAV         | PG4000H         | Top, Front &<br>Back | 41                   | 41                    | 45                    | 1000W  | 280      |
| HM047047049AAV         | PG6000H         | Top, Front &<br>Back | 47                   | 47                    | 49                    | 1500W  | 300      |
| HM053053056AAV         | PG8000H         | Top, Front &<br>Back | 53                   | 53                    | 56                    | 1500W  | 335      |
| HM054062056AAV         | PG10000H        | Top, Front &<br>Back | 54                   | 62                    | 56                    | 1900W  | 485      |


For unheated units, replace the "H" in the part# with an "L". Pad size=inside Dimensions + 12".







### **Pump Guard Enclosures**



**(** 










### Fiberglass Mounting Pads for Backflow Enclosures

- Save Time & Money No forms to build or concrete to pour.
- **Quick Installation** One trip to install Glass Pad and enclosure with no waiting for concrete to cure.
- Aesthetically Pleasing Professional looking installation with matching enclosure and pad.





| Catalog Part<br>Number | Model<br>Number | Inside<br>Width (in) | Inside<br>Length (in) | Inside<br>Height (in) | Weight # | For Enclosure Model Number                            |
|------------------------|-----------------|----------------------|-----------------------|-----------------------|----------|-------------------------------------------------------|
| GG019027005            | GP.75           | 19                   | 27                    | 4                     | 16       | (HB, LB, VG) .75 + (VC, VGVC)<br>1 & 1T               |
| GG021035005            | GP1             | 22                   | 36                    | 4                     | 20       | (HB, LB, VG, PEZ) 1 & 1T + (VC, VGVC) 2 & 2T + PG1000 |
| GG021047005            | GP2             | 21                   | 47                    | 4                     | 25       | (HB, LB, VG, PEZ) 2 & 2T                              |
| GG022056005            | GPPR2           | 23                   | 57                    | 4                     | 27       | (PHR, PLR, VGPLR) 2 + (EZ,<br>VGEZ) 2                 |
| GG026040005            | GPEZ1           | 26                   | 40                    | 4                     | 26       | (EZ, VGEZ) 1                                          |
| GG027036005            | GPPR1           | 27                   | 36                    | 5                     | 22       | (PHR, PLR, VGPLR) 1                                   |
| GG028028005            | GP1824          | 28                   | 28                    | 5                     | 18       | AVG1824                                               |
| GG028038005            | GPFS1           | 28                   | 38                    | 5                     | 20       | (FS, FSL, VGFS) 1                                     |
| GG029042005            | GP1.5           | 30                   | 42                    | 4                     | 30       | (HB, LB, VG) 1.5 + PG1500                             |







#### Ð

### **Options: General & Vents**

Hot Box® Enclosures can be modified to meet your specific project requirements. Below are many of the options that are available:

- **Standard options include:** vents, exhaust fans, alarm and lighting packages, and special colors (see pages 45-49 for details).
- **Specialized options include:** penetrations, FDC boots, stainless steel anchors, hinged doors, acrylic windows, extra insulation, sound insulation, special voltage heaters, explosion proof heaters/equipment, and different material types like 3003 Mill Finish (.05") or 5052 Marine Grade aluminum (.050" or .125"). Contact your representative for details or other special requirements.

#### **Vent Features:**

- 4" diameter aluminum fixed blade wall vent with foam rubber winter cover that is sized to be pushed inside the vent itself. It is pliable and soft, molding into the opening without resistance.
- 12" x 12" aluminum fixed blade wall vent with integrated insect screen.
- Winter covers are included to help prevent heat loss in the winter. They slide against the back side of the vent and are constructed of the same stucco embossed aluminum as the enclosure (non-insulated).
- Vent location and quantities vary depending on the size of the enclosure.
- Vents come fully installed.

#### **Vent Maintenance:**

- Install the winter covers when temperatures hold at 40°F or less for any prolonged period of time.
- When temperatures rise above 40°F, remove winter covers. Winter covers must be removed when a fan is in use.



4" Diameter Round Vent



12" x 12" Square Vent-Inside without Winter Cover



12" x 12" Square Vent (Outside)



12" x 12" Square Vent-Inside with Winter Cover







### **Options: Exhaust Fan**

#### **Features:**

- 10" diameter 5 blade exhaust fan
- Adjustable thermostat
- Automatic gravity shutter
- Wire fan guard
- Totally enclosed motor
- UL listed for US and Canada
- Fixed blade wall vent(s) & winter cover(s) to prevent heat loss in cold weather

#### **Technical Specs:**

- 120 volt single phase
- 60 Hz
- 1/30 hp motor
- 1550 rpm
- 585cfm @ .00-In. SP
- Maximum 1.5 amps
- Maximum Ambient Temp. 104 degrees F
- Fan location, vent size, and quantity of fan(s) can vary, based on the size of the enclosure

#### Installation:


- Contractors other than Hot Box® are responsible for the installation of the G.F.I. protected 15 amp, 120v, single phase service and receptacle. All installations to be in accordance with local and national codes.
- Plug the fan into the receptacle.
- Adjust the thermostat to the desired temperature.

#### **Maintenance:**

- Install the winter covers into the vents when temperatures hold at 40°F or less for any prolonged period of time. When the weather warms again, and the temperatures consistently reaches 40°F at night, winter covers must be removed.
- Keep the area around the automatic shutter free of objects that could impede air flow.
- Lubricate the motor sleeve bearings annually using S.A.E. 20 (non detergent) oil.



**Complete Exhaust Fan** (Interior View)













# **Options: Alarm Packages**

#### **Power Loss Alarm**



#### Power Loss & Low Temperature Alarm





**PLAHBO Audible Power Loss Alarm -** The alarm consists of the cabinet, battery, battery charger, relays, 95-decible horn, six foot power cord and plug. The alarm is designed to activate the horn if the enclosure loses electrical power.

<del>(</del>

**PLAHBOS Visual Power Loss Alarm -** The alarm consists of the cabinet, battery, battery charger, relays, amber strobe light, six foot power cord and plug. The alarm is designed to activate the strobe light if the enclosure loses electrical power.

**PLAHBO-T Audible Power Loss and Low Temperature Alarm -** The alarm consists of the cabinet, battery, battery charger, relays, 95-decible horn, temperature sensor, six foot power cord and plug. The alarm is designed to activate the horn if the enclosure loses electrical power or if the temperature falls below the set "adjustable" temperature.

**PLAHBOS-T Visual Power Loss and Low Temperature Alarm -** The alarm consists of the cabinet, battery, battery charger, relays, amber strobe light, temperature sensor, six foot power cord and plug. The alarm is designed to activate the strobe light if the enclosure loses electrical power or if the temperature falls below the set "adjustable" temperature.

**PLAHBOT-S Audible and Visual Power Loss and Low Temperature Alarm -** The alarm consists of the cabinet, battery, battery charger, relays, 95-decible horn, amber strobe light, temperature sensor, six foot power cord and plug. The alarm is designed to activate both audible and visual notifications if the enclosure loses electrical power or if the temperature falls below the set "adjustable" temperature.

**Note:** With a fully charged battery the alarm should activate for a minimum of six hours or until deactivated. Alarms operate on 120V, single phase service and plugs into a G.F.I. receptacle.

#### Installation:

- Contractors other than Hot Box® are responsible for the installation of the G.F.I. protected 20 amp, 120-240V, single phase service and receptacle. Alarm and Heater must be supplied by the same electrical service. All installations to be in accordance with the local and national codes.
- Simply plug the alarm into the receptacle and turn the switch to the on position.
- For low temperature alarms, adjust the thermostat to desired temperature (34°-38°F recommended).







### **Options: Lighting Packages**

- Increased Visibility Lighting illuminates equipment for easier maintenance.
- Peace of Mind UL listing for wet & damp locations ensures safety.

#### Packages:

**Single Light Package -** One 24" fluorescent light fixture in a water tight enclosure and hardwired to a single electrical switch.

**Double Light Package -** Two 24" fluorescent light fixtures in water tight enclosures and hardwired to a single electrical switch.

**Quad Light Package -** Four 24" fluorescent light fixtures in water tight enclosures and hardwired to a single electrical switch.

**Note:** The light package required will vary depending on the size of the enclosure.




Single Light Package (Installed)

#### **Technical Specs:**

- 24" fluorescent T8 bulb
- 17 watts (each)
- 120 volt single phase

#### Installation:

- Contractors other than Hot Box are responsible for the installation of the G.F.I. protected 120v, single phase service to the switch. All installations to be in accordance with the local and national codes.
- After enclosure installation is complete, plug in each light in tandem to the next light (if multiple lights are supplied).





HUBBELL





### **Options: Colors**

#### **Standard Colors:**

- All standard Aluminum Sectionalized and Dura Fold® Enclosures come with a stucco embossed aluminum finish, except the Select Six enclosures (which are a smooth mill finished aluminum). No color code is required for the stucco embossed aluminum finish.
- All fiberglass enclosures come standard with a beige gelcoat (color code not required).
- All plastic Poly EZ Box® Enclosures are available in beige (T) or dark green (G) only. Please add color code suffix.
- All fiberglass Hot Rok® Enclosures are available in brown (E), granite (N), or desert rose (S) only. Please add color code suffix.
- All plastic PolyRok® Enclosures are available in brown (E) or granite (N). Please add color code suffix.

#### **Optional Colors:**



#### **Notes:**

- If non-standard color is required, please specify the color code in the 12th digit of the part number.
- The above shown colors may not be an accurate representation of the actual color. If needed, please request a sample from your local Hot Box representative before ordering. Customer approval is required prior to processing the order.
- Custom colors not shown above will require a color sample, Federal Standard color, Munsell color or Sherwin Williams color number.

#### **Aluminum/Prep Procedure:**

Preparation of the exterior of the enclosure to accept paint involves sanding the aluminum and applying a solvent to remove dust and aluminum filings. A Mopoxy high build epoxy primer (Lead and Chromate free) is then applied to allow a Mothane Polyurethane enamel paint (Lead and Chromate free) to adhere properly. Prefinished aluminum sheets are used for the beige and federal brown colors.

#### **Fiberglass Gelcoat:**


Any special gelcoat color will be applied at a thickness of 18 mils.







### **Standard Drawings**




**(** 




Page 50



### **Standard Drawings**



**(** 





HOTBOX

### **Frequently Asked Questions**

#### Are Hot Box® Enclosures ASSE 1060 certified?

- Yes, standard Hot Box® Enclosures have been lab tested and ASSE 1060 certified for vertical roof load (100 lbs/ft2) capacities, freeze protection, drainage aptitude and material construction.
- Custom enclosures up to 87" W X 172" L x 85" H in size are certified. Larger enclosures are not certified by ASSE, but they are engineered in the same manner as certified enclosures.

### Do I need a heated or unheated enclosure, or what ASSE class enclosure do I need?

This question is best answered by comparing the lowest average winter temperature at your location to the definition of the ASSE Class ratings. See below:

- Class I Freeze Protection Enclosures (Heated): Designed and constructed to maintain a minimum internal temperature of 40°F with external temperatures as low as -30°F.
- Class II Freeze Retardant Enclosures (Insulated Non-Heated): Designed and constructed to be installed in locations with minimum temperature of 33°F.
- Class III Non-Freeze Protection Enclosures (Uninsulated Non-Heated): Designed and constructed to provide system security for components when freezing temperatures are not a consideration.

### Can you manufacture custom size enclosures? If so, what are the maximum dimensions?

- We can create custom sizes with our aluminum sectional and Dura Fold® Enclosures. Please speak with your area sales representative for dimensions.
- Custom sectional aluminum enclosures are limited to a maximum interior width of 117" and a maximum interior height of 106.5" with the length being unlimited.
- Custom Dura Fold® Enclosures are limited to a maximum top surface area of 22 sq ft (3168 sq in) or less and a maximum interior length of 90" and height of 66".
- If project quantities are large enough to warrant new tooling, we can customize the sizes of our fiberglass or plastic enclosures.

#### What is the largest removable access panel?

- Due to weight constraints set by ASSE 1060 3.3.3 specification, 44" W x 77  $\frac{1}{2}$ " H is the largest removable access panel.
- When a wider opening is required two 36" W x 72  $\frac{1}{2}$ " H dual hinged access doors will give you a 72" W x 72  $\frac{1}{2}$ " H opening.









### Will field penetrations affect the structural integrity or freeze protection of the enclosure?

<del>(�)</del>

- The structural integrity will not be affected when putting holes in an enclosure (maximum size of 12" diameter). However, it is important to not modify any of the corners or seams of a Hot Box (where two different surfaces meet), since this will reduce the structural integrity of a Hot Box® Enclosure. When in doubt or for special requirements, please contact our Customer Service Team.
- To minimize heat loss it is recommended you make the hole ½" larger than the pipe diameter. Then after installation apply expanding foam (found at any hardware store) around the perimeter of the penetration.

#### Is it necessary to have 3" insulation (R19) in the roof or the walls?

- Hot Box® Heaters and 1 ½" (R10) insulation are more than sufficient to maintain an interior temperature of 40°F (4.4°C) and protect equipment from external temperatures as low as -30°F (-34.4°C) in accordance with ASSE 1060 3.6.1-3.
- Some competitors require 3" of insulation due to the use of less efficient slab mounted heaters.
- If desired, 3" (R19) insulation is available for an additional fee.

#### What is the recommended slab size for Hot Box® Enclosures?

■ The slab should be 12" larger than the interior dimensions of the enclosure. The minimum recommended slab thickness is 4".

#### What are the standard heater electrical connection recommendations?

- Contractors other than Hot Box® are responsible for the installation of the G.F.I. protected service and receptacles (mounted a min. of 9" above the slab).
- We recommend that each heater be on separate 20 amp circuits. Separate circuits help provide redundancy in the event that one circuit fails.
- All installations must be in accordance with local and national codes.

#### What is the wind load rating for Hot Box enclosures?


- All standard fiberglass enclosures are suitable for wind speeds up to 120 mph.
- All standard Sectional Aluminum and Dura Fold® Enclosure sizes up to 36"W x 105"L x 64"H inside dimensions (i.e., LA036105064) and smaller are suitable for speeds up to 120 mph. Standard sizes larger than 36"W x 105"L x 64"H are suitable for use in areas where the design wind speed is 80 mph or less.
- Hot Box® Enclosures have not been certified to meet the wind-borne debris impact requirements in areas within a few miles of the coast (e.g. Florida Building Code).







### Installation Guide for Sectional Enclosures




- 1. Remove the access panels from the sections and place aside. This will lighten the sections for an easier installation.
- 2. Place the sections as close to their final positions as possible. The order of installation is always "Rear" left to right and then "Front" left to right regardless of the number of sections your enclosure has (4 section shown).
- 3. Each section has a male and a female edge. Lift each section (10"-12") and position over the mating edge and carefully lower the section into position keeping it flush against the opposing section's edge until it seats properly.
- 4. Place the enclosure in its final position. Do not tear the gasket on the enclosure base or around the male/female edges while sliding the sections together or positioning the enclosure.
- 5. The enclosures must be squared and leveled to assure proper fit of the sections. The anchor pads within the enclosure double as levelers. If needed, loosen the bolts attaching the anchor pads to the enclosure. Each pad is slotted for vertical movement. When level, tighten the pad bolts to the enclosure wall.
- 6. Once the enclosure is level and square, set the access panels in place. If the fit is not right or if light may be seen through any seam, the square of the enclosure is incorrect and must be reassessed.
- 7. After all is in place, remove the access panels once more. Install the anchors to secure the enclosure. Anchors and drill bit are included.







### **Installation Guide for Sectional Enclosures**




- 8. Determine if your enclosure has Beam clamp or Cam-locks (see diagram above). Only one type should exist per enclosure.
- 9. For Beam clamp style enclosures: tighten the Beam clamp eyebolts and wing nuts (located at the top seam inside the enclosure).
- 10. For Cam-lock style enclosures: fully engage the Cam-locks (located on the exterior walls along the seams) using the supplied allen wrench tool. Place the plastic plugs in the keyholes for protection.
- 11. Enclosures larger than 72" wide (inside) will be supplied with 2 x 1 support channels. They are attached with the supplied hardware to the underside of the horizontal roof bracing. Use a ratchet and a 1/2" deep socket to attach.
- 12. In some cases the size of the enclosure (typically 4 sections and larger) may cause a slight leaking during inclement weather. To prevent this, Aluminum tape has been provided (for 4 sections and larger). We recommend that the contractor lay a bead of silicon caulking in all seams and tape over the entire seam on the top of the enclosure. This is for situations where the enclosure is to be a "permanent" structure.
- 13. For enclosures with four or more sections, square cap plates have been supplied to cover the areas where the four corners of the sections come together on the top of the enclosure. Place the caps over the intersection and screw into place.
- 14. Hang the heater(s) on the heater plate(s) and plug into the receptacle(s).
- 15. Place the access panels in their respective openings and insert padlocks (not included) through the handles.







### Installation Guide for Standard Dura Fold® Enclosures



In most cases, Dura Fold® Enclosures are shipped assembled. If so, please skip to step 3.

\*Note: The receptacles and the concrete slab should be prepared and fully cured before the enclosure is uncrated.


- Position the "B" Panels around the installed valve maintaining clearance between the enclosure and the installed valve. Do not tear the gasket on the enclosure base while positioning or joining the enclosure panels.
- 2. Secure Panel "A" to Panel "B" using 5/16" wing nuts.
- 3. The enclosure must be squared and leveled. The L-shaped anchor pad brackets supplied with the enclosure double as levelers. If needed, loosen the bolts attaching the anchor pads to the enclosure. Each pad is slotted for vertical movement. When level, tighten the pad bolts to the enclosure wall. If the enclosure is not properly squared and leveled, then the lids may not close properly. Do not force lids closed as this may cause damage.
- 4. To install the concrete anchors in the slab, drill through the anchor pads and drive each concrete anchor into each drilled hole. Place the washer and nut on the top of the anchor and tighten. Concrete anchors and a drill bit are included.
- 5. If applicable, mount the heater to the heater plate using the supplied screws.
- 6. When vents are present, install the winter cover (according to the season).
- 7. Raise hinged front and back panels into place, and latch the internal latches inside.
- 8. Close the lid and hang a padlock on each hasp and staple to secure (padlock not included).







### Installation Guide for Double Dura Fold® Enclosures



In most cases, Dura Fold® Enclosures are shipped assembled. If so, please skip to step 4.

\*Note: The receptacles and the concrete slab should be prepared and fully cured before the enclosure is uncrated.

- Position "L" and "R" panels against the installed valve. Do not tear the gasket on the enclosure base while positioning or joining the enclosure panels.
- 2. Secure Panel "F" to Panel "L" and "R" using 5/16" wing nuts.
- 3. 3. Secure Panel "B" to Panel "L" and "R" using 5/16" wing nuts.
- 4. The enclosure must be squared and leveled. The L-shaped anchor pad brackets supplied with the enclosure double as levelers. If needed, loosen the bolts attaching the anchor pads to the enclosure. Each pad is slotted for vertical movement. When level, tighten the pad bolts to the enclosure wall. If the enclosure is not properly squared and leveled, then the lids may not close properly. Do not force lids closed as this may cause damage.
- 5. To install the concrete anchors in the slab, drill through the anchor pads and drive each concrete anchor into each drilled hole. Place the washer and nut on the top of the anchor and tighten. Concrete anchors and a drill bit are included.
- 6. If applicable, mount the heater to the heater plate using the supplied screws.
- 7. When vents are present, install the winter cover (according to the season).
- 8. Raise hinged front and back panels into place, and latch the internal latches inside.
- 9. Close the lid and hang a padlock on each hasp and staple to secure (padlock not included).










#### **Single and Double Anchor Kit:**

Used on Sectionalized Aluminum, Dura Fold®, Designer Series™ and F/G Flip-Top Enclosures.



Note: Anchor type and quantity will vary depending on the type of the enclosure.

#### **Technical information:**


■ Ultimate strength of wedge anchor: Pull out: 2,300lbs - Shear: 2,400lbs.

#### **Installation:**

- 1. Locate the Anchors. Mark and drill 3/8" diameter holes x 1 3/4" 2" deep with the supplied bit.
- 2. Drive the anchor into the hole, place the anchor pad over the anchor and tighten the washer and nut.

#### **EZ Anchor Kit:**

■ Used on fiberglass EZ Box® & fiberglass Hot Rok® Enclosures.



#### Installation:

- 1. Locate the brackets. Mark and drill 5/32" diameter holes x 3" deep with the supplied bit.
- 2. Attach the brackets with the supplied concrete screws. Screws will be hidden under the flange of the enclosure.










### **Anchor Installation & Specification**

#### **PEZ Anchor Kit:**

■ Used on Poly EZ Box® and PolyRok® Enclosures.




#### Installation:

- 1. Locate the brackets. Mark and drill 5/32" diameter holes x 3" deep with the supplied bit.
- 2. Attach the brackets with the supplied concrete screws. Screws will be hidden under the flange of the enclosure.

#### **Drive Anchor Kit:**

■ Used on Vent Guard® and Valve Cover™ Enclosures.



Note: Anchor quantity is typically four per enclosure.

#### Installation:

- 1. Locate the holes in the flange. Mark and drill 1/4" diameter holes x 2 1/2" deep with the supplied bit.
- 2. Place the anchor through the enclosure flange and into the drilled hole, then hit with a hammer.







### **Standard Convection Heaters**


#### **Benefits and Features:**

- **Better Freeze Protection** Heater is thermostatically controlled to maintain an interior temperature of 40°F (4.4°C) to protect equipment from external temperatures as low as -30°F (-34.4°C) in accordance with ASSE 1060 1.2.2.1.
- Better Performance and Safety Wall-mounted design elevates heater above discharge point.

- Fast and Easy Installation 6' power cord and plug.
- Quiet Operation Factory lubricated 100 cfm fan.

#### **Meets or Exceeds Standards:**

- ETL listed (tested for wet/damp locations).
- Dielectric Voltage Withstand Test (Section 44.0 of the UL 499 Standard & Section 6.4 of the CAN/CSA C22.2, No. 88 standard).
- Grounding Continuity Test (Section 45.1 of the UL 499 Standard & Section 6.5 of the CAN/ CSA C22.2, No. 88 standard).



| MODEL           | WATTAGE   | VOLTAGE | PHASE | BTU/hr    | WEIGHT<br>lb. | RECOMMENDED<br>CIRCUITS | PLUG       |
|-----------------|-----------|---------|-------|-----------|---------------|-------------------------|------------|
| ACI1000-120     | 1000      | 120     | 1     | 3412      | 12            | 20 AMP                  | NEMA 5-20P |
| ACI1500-120     | 1500      | 120     | 1     | 5118      | 12            | 20 AMP                  | NEMA 5-20P |
| ACI2000-120     | 1900      | 120     | 1     | 6824      | 12            | 20 AMP                  | NEMA 5-20P |
| ACI1000-208/240 | 867/1000  | 208-240 | 1     | 2957/3412 | 12            | 20 AMP                  | NEMA 6-20P |
| ACI1500-208/240 | 1300/1500 | 208-240 | 1     | 4436/5118 | 12            | 20 AMP                  | NEMA 6-20P |
| ACI2000-208/240 | 1733/2000 | 208-240 | 1     | 5914/6824 | 12            | 20 AMP                  | NEMA 6-20P |

Contractors other than Hot Box are responsible for the installation of the G.F.I. protected service and receptacles. We recommend that each heater be on separate 20 amp circuits so in the event a circuit fails, all other circuits will remain powered. We recommend that all installations be in accordance with the local and national codes.



NEMA 5-20P (120V)



NEMA 6-20P (240V)











### **Standard Convection Heaters**

#### Installation:

- 1. Contractors other than Hot Box® are responsible for the installation of the G.F.I. protected service and receptacles (ref. UL 943, NEMA 3R). When multiple heaters are required it is recommended that each heater be on a separate 20 amp circuit. Separate circuits help provide redundancy in the event that one circuit fails. All installations to be in accordance with local and national codes.
- 2. Locate the aluminum heater plate(s) inside the enclosure and hang the heater(s) on the provided hangers.
- 3. Plug the heater into the ground fault circuit protected outlet.

**Note:** The heater assembly may be installed on any vertical wall no closer than 2 inches from the adjacent box wall or seam.





#### **Maintenance:**

Perform the following maintenance prior to installation and at least once per season, preferably before energizing the system, or immediately after any work has taken place on the piping system:

- Check to be sure heater power cord is free from mechanical or thermal damage (cuts or nicks in the cable insulation from utility knife, use of metal clamps, solder or overheating).
- To test heaters with adjustable thermostats, the thermostat should be turned clockwise until the heater activates and then reset to the minimum setting (40-45°F) by turning the knob counter-clockwise, after testing is completed.
- To test heaters with older pre-set thermostats, spray CO2 on the thermostat bulb to simulate cold temperature until the heater activates.
- Vacuum occasionally using standard vacuum attachments.

Note: The heaters are intended to keep the equipment from freezing and are not to be used as a climate control device. Running the heaters for extended periods of time above 45°F will shorten heater life.

**Warning!** - A ground fault circuit interrupting device shall be installed in the electrical supply circuit to the heater(s). Failure to do so may result in injury or death. The interior of this enclosure can a damp location.

Warning! - Hazard of severe shock, disconnect all power before servicing.

Warning! - Do not block air flow in any way.

Warning! - Avoid contact. The heater surface is HOT.

For replacement heaters please contact your local Hot Box Representative.







### **Heat Trace Tape**


#### **Benefits and Features:**


- Energy Efficient & Self-Regulating The electrical resistance of the heat trace tape varies with temperature. As the process temperature drops the heat output increases; as the process temperature rises the heat output decreases.
- Fast and Easy Installation Single overlap cable and 3' power cord and plug.
- Freeze Protection Protects equipment from external temperatures as low as -30°F (-34.4°C).
- **Durable -** Commercial grade design suitable for wet environments.

**Note:** Heat trace tape does not respond to a drop in ambient temperature. It responds to abject cooling of surfaces such as the piping risers and backflow prevention device. It does not heat along the entire cable at one time. The tape uses a sensory bulb and is self regulating, heating only those sections of tape that are required to warm the cooled portions of the piping risers and backflow prevention device.

#### **Standards:**

- UL Listed
- CSA Certified for commercial/residential pipe freeze protection applications





NEMA 5-15P (120V)

| MODEL   | WATTAGE | VOLTAGE | PHASE | CABLE<br>LENGTH (ft) | WEIGHT (lbs) | RECOMMENDED<br>CIRCUITS | PLUG       |
|---------|---------|---------|-------|----------------------|--------------|-------------------------|------------|
| C001266 | 30      | 120     | 1     | 6                    | .50          | 15 AMP                  | NEMA 5-15P |
| C001267 | 60      | 120     | 1     | 12                   | 1.00         | 15 AMP                  | NEMA 5-15P |
| C001269 | 90      | 120     | 1     | 18                   | 1.50         | 15 AMP                  | NEMA 5-15P |

Contact Hot Box if you do not see the heat trace tape you are looking for.









### **Heat Trace Tape**

#### Installation:

- 1. Contractors other than Hot Box® are responsible for the installation of the G.F.I. protected service and receptacles (ref. UL 943, NEMA 3R). When multiple heaters are required it is recommended that each heater be on a separate 15 amp circuit. Separate circuits help provide redundancy in the event that one circuit fails. All installations to be in accordance with the local and national codes.
- 2. Wrap heat trace tape in a spiral or straight line (depending on length of the heat tape) about the pipe risers and backflow device. Avoid overlapping the heat tape.
- 3. Secure heat trace tape on 12" centers using only glass cloth tape or plastic cable ties. Restrain the plug end of the cord to provide proper strain relief.
- 4. Pipe insulation is not a requirement. If insulating the pipe, use only a fire resistant thermal insulation, such as fiberglass pipe wrap.
- 5. Plug cable into 120V ground fault circuit protected outlet.

#### Maintenance:

Perform the following maintenance prior to installation and at least once per season, preferably before energizing the system, or immediately after any work has taken place on the piping system:

- Check to be sure heating cable is free from mechanical or thermal damage (cuts or nicks in the cable insulation from utility knife, use of metal clamps, solder or overheating).
- Use Megohmmeter to test each circuit (see below).

#### Megohmmeter Testing Procedure (Use only 2500VDC megohmmeter for this test):

- Check insulation resistance between each lead of the heating cable and the round ground lug on the power cord plug.
- Perform the test by placing one lead of the megohmmeter on the round ground lug and the other on one of the rectangular power lugs. You should read 1000 megohms minimum.
- Perform the test again by checking the opposite rectangular power lug. Again the reading should be 1000 megohms minimum.

**Note:** If you read less than 1000 megohms on either lead, the cable needs to be replaced. Do not attempt to repair the unit. Replace with new product. The megohm readings along with the test date should be recorded.

**Warning!** - A ground fault circuit interrupting device shall be installed in the electrical supply circuit to the heater(s). Failure to do so may result in injury or death. The interior of this enclosure can be a damp location.

Warning! - Hazard of severe shock, disconnect all power before servicing.

**Warning! -** Avoid contact. The heater surface is HOT.

For replacement heaters please contact your local Hot Box Representative.







### **Hot Box Order Form**

#### HOT BOX ORDER FORM

Floor

Inside Height

Inside Length

Inside Width

Top

Floor

Locate penetrations by giving dimensions from the centerline to the floor.

|            | Enclosure Style |   | FDC boot              |
|------------|-----------------|---|-----------------------|
|            | Heat (yes/no)   |   | Penetrations/Size     |
|            | Vented          | 0 | Special Door/location |
|            | Exhaust Fan     |   | Color                 |
|            | Alarm/Style     |   | BFP Model/optional    |
| $\bigcirc$ | Lights          |   |                       |






**(** 



### TYPICAL WINTERIZATION FOR 3"-10" BFP RISERS

(RECOMMENDED COLD WEATHER INSTALLATION)



NOTE: UTILIZATION OF THIS RECOMMENDATION LIES WITH THE PROJECT ENGINEER AND/OR UTILITY. HOW IT IS INSTALLED SHALL BE IN STRICT ACCORDANCE WITH THE ENGINEERING AND/OR UTILITY SPECIFICATION.











### **Typical Installation-Single**

#### SINGLE INSTALLATION




PIPE SIZE: BACKFLOW: VALVE TYPE: HOTBOX P/N:\_




- RECOMMENDED SLAB SIZE IS 12" LARGER THAN THE INTERIOR DIMENSIONS OF THE SPECIFIED ENCLOSURE AND 4" THICK. INSULATED ENCLOSURES ARE INTERNALLY LINED WITH
- POLYISOCYANATE FOAM FOR A MINIMUM R8 VALUE.
- MANUFACTURER RECOMMENDS MANUFACTURER RECOMMENDS
  ENCLOSURES HAVE A UL OR ETL
  LISTED HEAT SOURCE WHEN IT IS
  DETERMINED THAT FREEZE
  PROTECTION IS NEEDED. HEATED
  ENCLOSURES HAVE A "H" PREFIX
  AND UNHEATED ENCLOSURES HAVE
  A "I" PROFESS. A "L" PREFIX.
- IF A STRAINER IS REQUIRED IT IS LOCATED BEFORE THE BFP.

#### SINGLE W/ STRAINER INSTALLATION



PIPE SIZE: BACKFLOW: VALVE TYPE STRAINER: HOTBOX P/N:\_



- RECOMMENDED SLAB SIZE IS 12"
  LARGER THAN THE INTERIOR
  DIMENSIONS OF THE SPECIFIED
  ENCLOSURE AND 4" THICK.
  INSULATED ENCLOSURES ARE
  INTERNALLY LINED WITH
  DI VISCOSYNNITE FORM FOR A
- POLYISOCYANATE FOAM FOR A MINIMUM R8 VALUE.
- MANUFACTURER RECOMMENDS ENCLOSURES HAVE A UL OR ETL LISTED HEAT SOURCE WHEN IT IS DETERMINED THAT FREEZE PROTECTION IS NEEDED. HEATED ENCLOSURES HAVE A "H" PREFIX AND UNHEATED ENCLOSURES HAVE A "L" PREFIX.
- IF A STRAINER IS REQUIRED IT IS LOCATED BEFORE THE BFP.




HUBBELL






### Typical Installation-Single w/ Meter

#### SINGLE W/ METER INSTALLATION



#### SINGLE W/ METER & BYPASS INSTALLATION










#### 

### **Typical Installation-Dual**


#### **DUAL INSTALLATION**



- PIPE SIZE "A": BACKFLOW "A": PIPE SIZE "B": BACKFLOW "B":
- HOTBOX P/N: \_\_
- RECOMMENDED SLAB SIZE IS 12" LARGER THAN THE INTERIOR DIMENSIONS OF THE SPECIFIED ENCLOSURE AND 4" THICK.
- INSULATED ENCLOSURES ARE
  INTERNALLY LINED WITH POLYISOCYANATE FOAM FOR A MINIMUM R8 VALUE.
- MANUFACTURER RECOMMENDS ENCLOSURES HAVE A UL OR ETL LISTED HEAT SOURCE WHEN IT IS DETERMINED THAT FREEZE PROTECTION IS NEEDED. HEATED ENCLOSURES HAVE A "H" PREFIX AND UNHEATED ENCLOSURES HAVE A "L" PREFIX.

  IF A STRAINER IS REQUIRED IT IS LOCATED BEFORE THE BFP.

#### DUAL W/ STRAINER INSTALLATION



- PIPE SIZE "A": \_ BACKFLOW "A": \_ STRAINER "A": \_ PIPE SIZE "B": BACKFLOW "B":\_ STRAINER "B": \_ HOTBOX P/N: \_\_\_\_
  - RECOMMENDED SLAB SIZE IS 12" LARGER THAN THE INTERIOR DIMENSIONS OF THE SPECIFIED ENCLOSURE AND 4"
  - THICK.
    INSULATED ENCLOSURES ARE
    INTERNALLY LINED WITH POLYISOCYANATE
    FOAM FOR A MINIMUM R8 VALUE.
  - MANUFACTURER RECOMMENDS
    ENCLOSURES HAVE A UL OR ETL LISTED
    HEAT SOURCE WHEN IT IS DETERMINED
    THAT FREEZE PROTECTION IS NEEDED. HEATED ENCLOSURES HAVE A "H" PREFIX AND UNHEATED ENCLOSURES HAVE A "L" PREFIX.
  - IF A STRAINER IS REQUIRED IT IS LOCATED BEFORE THE BFP.









#### **(**

### **Typical Installation-Tandem**

#### TANDEM INSTALLATION



#### TANDEM W/ METER INSTALLATION









#### BACKFLOW PREVENTION ASSEMBLY ENCLOSURE SPECIFICATION-DURA FOLD®

#### **GENERAL**

#### 1.1 WORK INCLUDED

A. Provide and install manufactured backflow prevention assembly enclosure.

#### **1.2 QUALITY ASSURANCE**

A. Qualifications: The backflow prevention assembly enclosure manufacturer shall be a company specializing in the manufacture of backflow prevention assembly enclosures with at least 29 years of successful experience designing and selling enclosures to various customers in different climatic regions.

#### 1.3 STORAGE AND HANDLING

A. Store products in shipping containers and maintain in dry place until installation.

#### 1.4 ACCEPTABLE MANUFACTURERS

A. Hot Box® or Engineer approved equal.

#### 1.5 REFERENCES

A. ASTM B209.

B. ASTM B221.

C. ASSE 1060 - Performance Requirements for Outdoor Enclosures for Backflow Prevention assemblies.

#### **PRODUCTS**

#### 2.1 DURA FOLD® ENCLOSURES

A. Dura Fold® Enclosures ship assembled to allow quick installation by securing to the concrete pad with the supplied anchor pads and wedge anchors. The design includes hinged walls, as well as front and top lids, to provide easy access. Also the front wall is easily removed to provide unobstructed access for equipment testing and maintenance after installation.

- B. Drain ports are sized for full port backflow discharge and are designed for a one way operation allowing backflow discharge but not allowing wind, debris and small animals to enter the enclosure.
- C. Standard enclosures shall be designed to support a minimum vertical load of 100 lb/sf.
- D. Standard enclosures shall be designed to support wind speeds up to 80 mph.
- E. Standard enclosures are ASSE 1060 certified.
- F. Custom Dura Fold Enclosures are designed and constructed in the same manner as standard certified enclosures, but have not been lab tested and listed by ASSE.

#### 2.2 MATERIALS OF FABRICATION

A. Aluminum sheeting shall be 3003 aluminum

(.050"/18 gauge), stucco embossed finish and shall meet ASTM B209. Stucco embossed finish reduces the glare and helps hide surface scratches or imperfections received in the field.

- B. Bracing shall be 6063-T52 aluminum and shall meet ASTM B221
- C. No wood or particle board should be used in the construction of the enclosure.
- D. Anchor pads shall be galvanized steel. 3/8-16 unc x 2  $\frac{3}{4}$  long zinc plated wedge anchors are supplied.
- E. Insulation shall be approximately 1.5" unicellular, non-wicking, polyisocyanate foam sprayed in place that forms a monolithic bond between the aluminum bracing and aluminum sheeting.

F. The Insulation shall have the following properties:

• R-Value: 10

• Dimensional Stability: <2% linear change

Compressive Strength: 51 psiFlame point: 325 degrees

Water absorption: .037 psfPorosity: 91%

### 3.1 HEATING EQUIPMENT (ASSE 1060 Class I-Required; ASSE 1060 Class II-Optional)

A. Heating equipment will protect the piping and equipment from exterior temperatures to -30F. ETL listed thermostatically controlled wall mounted air forced heaters or UL listed self regulating cable(s) shall be furnished and designed by the manufacturer of the enclosure to maintain the equipment at +40F, In accordance with ASSE 1060 1.2.2.1.

- B. Heating equipment shall be wall mounted to the supplied heater plates and a minimum 8" above the slab unless it is UL or ETL certified and NEC approved for submersion.
- C. Power source shall be protected with a GFI receptacle, U.L. 943, NEMA 3R. Mounted a minimum of 8" from the bottom of the receptacle to the top of the slab
- D. Separate 20 amp circuits are recommended for each heater, so in the event a circuit fails all other circuits will remain powered. Installations must be in accordance with the local and national codes.
- E. The heaters shall be ETL listed for wet/damp locations.

#### 4.1 RECOMMENDED SLAB SIZE & INSTALLATION

- A. The recommended slab size shall be 12" larger than the interior dimensions of the enclosure and a minimum of 4" thick.
- B. The enclosure shall be assembled per the manufacturer's instructions provided with the enclosure.









#### **BACKFLOW PREVENTION ASSEMBLY ENCLOSURE SPECIFICATION-SECTIONAL ALUMINUM**

#### **GENERAL**

#### 1.1 WORK INCLUDED

A. Provide and install manufactured backflow prevention assembly enclosure.

#### 1.2 QUALITY ASSURANCE

A. Qualifications: The backflow prevention assembly enclosure manufacturer shall be a company specializing in the manufacture of backflow prevention assembly enclosures with at least 29 years of successful experience designing and selling enclosures to various customers in different climatic regions.

#### 1.3 STORAGE AND HANDLING

A. Store products in shipping containers and maintain in dry place until installation.

#### 1.4 ACCEPTABLE MANUFACTURERS

A. Hot Box® or Engineer approved equal.

#### 1.5 REFERENCES

A. ASTM B209.

B. ASTM B221.

C. ASSE 1060 - Performance Requirements for Outdoor Enclosures for Backflow Prevention assemblies.

#### **PRODUCTS**

#### 2.1 SECTIONALIZED ALUMINUM ENCLOSURES

A. Sectionalized enclosures are factory assembled with tongue and grooved sections that slide together and are then secured to the concrete pad with the supplied anchor pads and wedge anchors.

B. Access panels have a four point locking system with pad lockable handle and are completely removable.

C. Drain ports are sized for full port backflow discharge and are designed for a one way operation allowing backflow discharge but not allowing wind, debris and small animals to enter the enclosure.

D. Standard enclosures shall be designed to support a minimum vertical load of 100lb/sf.

E. Standard enclosures up to  $36\text{"W} \times 105\text{"L} \times 64\text{"H}$  shall be designed to support wind speeds up to 120 mph, all larger sizes shall be designed to support wind speeds up to 80 mph.

F. Standard enclosures are ASSE 1060 certified.

G. Custom enclosures are designed and constructed in the same manner as standard certified enclosures, but have not been lab tested and listed by ASSE.

#### 2.2 MATERIALS OF FABRICATION

A. Aluminum sheeting shall be 3003 aluminum (.050/18 gauge), stucco embossed finish and shall

meet ASTM B209. Stucco embossed finish reduces the glare and helps hide any surface scratches or imperfections received in the field.

B. Bracing shall be 6063-T52 aluminum and shall meet ASTM B221.

C. No wood or particle board should be used in the construction of the enclosure.

D. Anchor pads shall be galvanized steel. 3/8-16 unc x 2 3/4 long zinc plated wedge anchors are supplied.

E. Insulation shall be approximately 1.5" unicellular, non-wicking, polyisocyanate foam sprayed in place that forms a monolithic bond between the aluminum bracing and aluminum sheeting.

F. The Insulation shall have the following properties:

• R-Value: 10

• Dimensional Stability: <2% linear change

Compressive Strength: 51 psi

Flame point: 325 degreesWater absorption: .037 psfPorosity: 91%

### 3.1 HEATING EQUIPMENT (ASSE 1060 Class I-Required; ASSE 1060 Class II-Optional)

A. Heating equipment will protect the piping and equipment from exterior temperatures to -30F. ETL listed thermostatically controlled wall mounted air forced heaters shall be furnished and designed by the manufacturer of the enclosure to maintain the equipment at +40F, In accordance with ASSE 1060 1.2.2.1.

B. Heating equipment shall be wall mounted to the supplied heater plates and a minimum of 8" above the slab unless it is UL or ETL certified and NEC approved for submersion.

C. Power source shall be protected with a GFI receptacle, U.L. 943, NEMA 3R. Mounted a minimum of 8" from the bottom of the receptacle to the top of the slab.

D. Separate 20 amp circuits are recommended for each heater, so in the event a circuit fails all other circuits will remain powered. Installations must be in accordance with the local and national codes.

E. The heaters shall be ETL listed for wet/damp locations.

#### 4.1 RECOMMENDED SLAB SIZE & INSTALLATION

A. The recommended slab size shall be 12" larger than the interior dimensions of the enclosure and a minimum of 4" thick.

B. The enclosure shall be assembled per the manufacturer's instructions provided with the enclosure.







#### BACKFLOW PREVENTION ASSEMBLY ENCLOSURE SPECIFICATION-DESIGNER SERIES™

#### **GENERAL**

#### 1.1 WORK INCLUDED

A. Provide and install manufactured backflow prevention assembly enclosure.

#### 1.2 QUALITY ASSURANCE

A. Qualifications: The backflow prevention assembly enclosure manufacturer shall be a company specializing in the manufacture of backflow prevention assembly enclosures with at least 29 years of successful experience designing and selling enclosures to various customers in different climatic regions.

#### 1.3 STORAGE AND HANDLING

A. Store products in shipping containers and maintain in dry place until installation.

#### 1.4 ACCEPTABLE MANUFACTURERS

A. Hot Box® or Engineer approved equal.

#### 1.5 REFERENCES

A. ASSE 1060 - Performance Requirements for Outdoor Enclosures for Backflow Prevention assemblies.

#### **PRODUCTS**

#### 2.1 DESIGNER SERIES™ ENCLOSURES

A. Enclosures shall have front and back hinged doors that are removable for full access to both sides of the equipment for maintenance and testing.

- B. Enclosures shall have a removable hinged top with gas shocks to support and secure the lid in an upright position for full access to the top of the equipment for maintenance and testing.
- C. Doors shall be secured from the interior of the enclosure and shall have no exterior handles or lock exposed to the elements.
- D. The top is lockable to deter unauthorized entry, theft and vandalism.
- E. Anchoring is supplied to secure to the concrete pad.
- F. Drain ports are sized for full port backflow discharge and are designed for a one way operation allowing backflow discharge but not allowing wind, debris and small animals to enter the enclosure.
- G. Standard enclosures shall be designed to support a minimum vertical load of 100 lb/sf.
- H. Standard enclosures shall be designed to support wind speeds up to 120 mph.
- I. Standard enclosures shall be ASSE 1060 certified.

#### 2.2 MATERIALS OF FABRICATION

A. Fiberglass is minimum of 1/8" thick Thixotropic polyester resin reinforced with fiberglass strand. A smooth yacht quality finish, protected with UV inhibited isophthalic polyester gel coat.

- B. No wood or particle board should be used in the construction of the enclosure.
- C. Anchor pads shall be galvanized steel. 3/8-16 unc x 2  $\frac{3}{4}$  long zinc plated wedge anchors and drill bit are supplied.
- D. Insulation shall be 1.5" unicellular, non-wicking, polyisocyanate foam frothed applied to form a monolithic bond to the fiberglass and is not affected by heat or cold. No clips or fasteners shall be used.

E. The Insulation shall have the following properties:

• R-Value: 10

• Dimensional Stability: <2% linear change

Compressive Strength: 51 psi
Flame point: 325 degrees
Water absorption: .037 psf

• Porosity: 91%

### 3.1 HEATING EQUIPMENT (ASSE 1060 Class I-Required; ASSE 1060 Class II-Optional)

A. Heating equipment will protect the piping and equipment from exterior temperatures to -30F. ETL listed thermostatically controlled wall mounted air forced heaters shall be furnished and designed by the manufacturer of the enclosure to maintain the equipment at +40F, In accordance with ASSE 1060 1.2.2.1.

- B. Heating equipment shall be wall mounted to the supplied heater plates and a minimum 8" above the slab unless it is UL or ETL certified and NEC approved for submersion.
- C. Power source shall be protected with a GFI receptacle, U.L. 943, NEMA 3R. Mounted a minimum of 8" from the bottom of the receptacle to the top of the slab
- D. Separate 20 amp circuits are recommended for each heater, so in the event a circuit fails all other circuits will remain powered. Installations must be in accordance with the local and national codes.
- E. The heaters shall be ETL listed for wet/damp locations.

#### 4.1 RECOMMENDED SLAB SIZE & INSTALLATION

- A. The recommended slab size shall be 12" larger than the interior dimensions of the enclosure and a minimum of 4" thick.
- B. The enclosure shall be assembled per the manufacturer's instructions provided with the enclosure.







#### **BACKFLOW PREVENTION ASSEMBLY ENCLOSURE SPECIFICATION-FIBERGLASS**

#### **GENERAL**

#### 1.1 WORK INCLUDED

A. Provide and install manufactured backflow prevention assembly enclosure.

#### 1.2 QUALITY ASSURANCE

A. Qualifications: The backflow prevention assembly enclosure manufacturer shall be a company specializing in the manufacture of backflow prevention assembly enclosures with at least 29 years of successful experience designing and selling enclosures to various customers in different climatic regions.

#### 1.3 STORAGE AND HANDLING

A. Store products in shipping containers and maintain in dry place until installation.

#### 1.4 ACCEPTABLE MANUFACTURERS

A. Hot Box® or Engineer approved equal.

#### 1.5 REFERENCES

A. ASTM B209.

B. ASTM B221.

C. ASSE 1060 - Performance Requirements for Outdoor Enclosures for Backflow Prevention assemblies.

#### **PRODUCTS**

#### 2.1 FIBERGLASS ENCLOSURES

A. Available in Drop over, Flip top, Vent Guard, Valve Cover & Roks.

- B. All fiberglass enclosures are lockable.
- C. Anchoring is supplied to secure to the concrete pad.
- D. Drain ports are sized for full port backflow discharge and are designed for a one way operation allowing backflow discharge but not allowing wind, debris and small animals to enter the enclosure.
- E. Standard enclosures shall be designed to support a minimum vertical load of 100 lb/sf.
- F. Standard enclosures shall be designed to support wind speeds up to 120 mph.
- G. Standard enclosures are ASSE 1060 certified.

#### 2.2 MATERIALS OF FABRICATION

A. Fiberglass is minimum of 1/8" thick Thixotropic polyester resin reinforced with fiberglass strand. A smooth yacht quality finish, protected with UV inhibited isophthalic polyester gel coat.

B. Non molded products will utilize an Industrial exterior texture.

C. No wood or particle board should be used in the construction of the enclosure.

D. Insulation shall be 1"-1.5" unicellular, non-wicking, polyisocyanate foam frothed or sprayed in place.

E. The Insulation shall have the following properties:

• R-Value:

• Dimensional Stability: <2% linear change

• Compressive Strength: 51 psi

Flame point: 325 degreesWater absorption: .037 psf

• Porosity: 91%

# 3.1 HEATING EQUIPMENT (ASSE 1060 Class I-Required; ASSE 1060 Class II-Optional)

A. Heating equipment will protect the piping and equipment from exterior temperatures to -30F. ETL listed thermostatically controlled wall mounted air forced heaters or UL listed self regulating cable(s) shall be furnished and designed by the manufacturer of the enclosure to maintain the equipment at +40F, In accordance with ASSE 1060 1.2.2.1.

B. Heating equipment shall be wall mounted to the supplied heater plates and a minimum 8" above the slab unless it is UL or ETL certified and NEC approved for submersion.

C. Power source shall be protected with a GFI receptacle, U.L. 943, NEMA 3R. Mounted a minimum of 8" from the bottom of the receptacle to the top of the slab.

D. Separate 20 amp circuits are recommended for each heater, so in the event a circuit fails all other circuits will remain powered. Installations must be in accordance with the local and national codes.

E. The heaters shall be ETL listed for wet/damp locations.

#### 4.1 RECOMMENDED SLAB SIZE & INSTALLATION

A. The recommended slab size shall be 12" larger than the interior dimensions of the enclosure and a minimum of 4" thick.

B. The enclosure shall be assembled per the manufacturer's instructions provided with the enclosure.







### **Hot Box® Catalog Numbering System**

| 1<br>Type                               | 2<br>Hot Box Style       | 3, 4, 5<br>Width    | 6, 7, 8<br>Length    | 9, 10, 11<br>Height  | 12<br>Color Options***           | 13<br>Lights      |  |
|-----------------------------------------|--------------------------|---------------------|----------------------|----------------------|----------------------------------|-------------------|--|
| H-Heated<br>(Hotbox)                    | A-Aluminum               | (Interior<br>Width) | (Interior<br>Length) | (Interior<br>Height) | A-Standard                       | A-Standard        |  |
| L-Unheated<br>(Lokbox)                  | C-Valve Cover            |                     |                      |                      | B-Black                          | B-(1) 24" light   |  |
| V-Non-<br>Insulated<br>(Valve<br>Guard) | D-Dura Fold              |                     |                      |                      | C-Grey                           | C-(2) 24" light   |  |
| G-Glass Pad                             | E-EZ Box                 |                     |                      |                      | E-Brown<br>(Roks Only)           | E-(4) 24" light   |  |
|                                         | F-Flip-Top Fiberglass    |                     |                      |                      | G-Dark Green                     | F-(1) Haz light   |  |
|                                         | G-Glass Pad              |                     |                      |                      | L-Smooth Mill<br>Finish Aluminum | G-(2) Haz light   |  |
|                                         | L-Low Profile            |                     |                      |                      | M-Federal Brown                  |                   |  |
|                                         | M-Designer Series        |                     |                      |                      | N-Granite                        |                   |  |
|                                         | N-EZ Box w/ doors        |                     |                      |                      | S-Desert Rose                    |                   |  |
|                                         | P-Poly EZ Box            |                     |                      |                      | T-Beige                          |                   |  |
|                                         | Q-PolyRock               |                     |                      |                      | W-White (Sail)                   |                   |  |
|                                         | R-Hot Rock<br>Fiberglass |                     |                      |                      | Specials "500#" D                | igits 12 13 & 14  |  |
|                                         | V-Vent guard             |                     |                      |                      | Specials 500# D                  | 1910 12, 10, 0 17 |  |
|                                         |                          |                     |                      |                      |                                  |                   |  |
|                                         |                          |                     |                      |                      |                                  |                   |  |
|                                         |                          |                     |                      |                      |                                  |                   |  |

<sup>\*\*\*</sup>Note: When no options are needed, no color code is needed for standard colors. With ordering options, if standard color is acceptable, then use an "A" in the 12th digit. See page 49 for details on color and finish options.










| 14<br>Fans       | 15<br>Alarms                                      |
|------------------|---------------------------------------------------|
| A-Standard       | A-Standard                                        |
| B-7" Fan         | B-PLAHBO audible pwr loss                         |
| C-10" Fan        | C-PLAHBOS strobe<br>pwr loss                      |
| D-12" Fan        | D-PLAHBO-T audible pwr & temp                     |
| E-12" Expl Proof | E-PLAHBOS-T strobe pwr & temp                     |
| F- FDC (4"-9")   | F-PLAHBOT-S aud/<br>strobe pwr loss & low<br>temp |
| G- FDC (9"-16")  |                                                   |
| V-Vents          |                                                   |
|                  |                                                   |
|                  |                                                   |
|                  |                                                   |
|                  |                                                   |
|                  |                                                   |
|                  |                                                   |
|                  |                                                   |
| 1                | 1                                                 |















### HUBBELL LENOIR CITY, INC. TERMS & CONDITIONS OF SALES

Hubbell Lenoir City, Inc. (hereinafter called HLC) hereby gives notice of its exception to any different or additional terms and conditions other than as stated herein. All sales are expressly made conditional on Buyer's assent to the following terms and conditions. Buyer's acceptance of the provisions of HLC's terms and conditions as recited herein shall be conclusively presumed upon Buyer's receipt of the goods, or if no written objection is received by HLC within fifteen (15) days from the date on HLC's order acknowledgment, whichever event shall first occur. These terms and conditions constitute the entire agreement between HLC and Buyer, and supersede other communications between the two parties, whether written or oral.

#### **PRICING**

Refer to appropriate Price Schedule, unless otherwise quoted.

#### TERMS

HLC's payment terms are net 30 days. Invoices will be dated the day of shipment. A service charge of 1-1/2% per month or, if such rate exceeds the maximum lawful rate, the maximum lawful rate shall be assessed on all past due accounts and shall be payable on demand.

#### **QUOTATIONS**

Unless otherwise stated in writing, HLC's quotations are subject to acceptance by the Buyer within thirty (30) days from the date of issue.

#### **SALES AND SIMILAR TAXES**

HLC's prices do not include any sales, use, excise or similar taxes. Consequently, in addition to the price specified herein, the amount of any present or future sales, use, excise or other similar tax applicable to the sale or use of the goods hereunder, shall be paid by the Buyer, or in lieu thereof the Buyer shall provide HLC with a tax exemption certificate acceptable to the taxing authorities.

#### **ACCEPTANCE OF ORDERS**

All orders are subject to acceptance by HLC at its main office at 3621 Industrial Park Drive, Lenoir City, TN, USA, and to "HLC Terms and Conditions of Sales". Any other terms proposed by Buyer are rejected unless expressly accepted in writing. Orders shall be deemed to be executed in the State of Tennessee and shall be construed and performed in accordance with the Laws of that State. Acceptance of any order is subject to availability of product and the ability of HLC to deliver. Orders will be billed at prices in effect at time of shipment unless otherwise agreed. Unless, otherwise stated in writing, HLC reserves the right to ship plus or minus 10% of specified quality for special products that are made to order.

#### **SALES BY AGENTS**

Sales by agents or through overseas representatives shall be at prices, terms and conditions of sale specified by HLC. All invoices will be issued by and payment remitted to HLC.

#### **DELAY**

HLC will use reasonable efforts to meet shipment or delivery dates specified by HLC, but such dates are estimates only. HLC shall in no event be liable for any delay or nondelivery if such delay or nondelivery is caused directly or indirectly by Acts of God, fire, flood, strike or lockout or other labor dispute, accident, civil commotion, riot, war, governmental regulation or order, whether or not it later proves to be invalid, or from any other cause or causes (whether or not similar to any of the foregoing) beyond HLC's control. In no case will HLC be liable for loss of profits or any special or consequential damages on account of any delay in delivery or nondelivery whether or not excused hereunder.

#### SHIPPING DEFERMENT

Buyer requests for shipping deferment must be approved by HLC and are subject to price negotiation.

#### LIMITED WARRANTY AND LIMITATION OF LIABILITY

MATERIAL: HLC warrants all products sold by it to be merchantable (as such term is defined in the Uniform Commercial Code) and to be free from defects in material and workmanship for a period of one (1) year (or as otherwise specified) from the date of original shipment by HLC when stored, installed, operated or maintained in accordance with recommendations of HLC and standard industry practice and when used under proper and normal use. Buyer must notify HLC promptly of any claim under this warranty. NO OTHER WARRANTY, WHETHER EXPRESS OR ARISING BY OPERATION OF THE LAW, COURSE OF DEALING, USAGE OF TRADE OR OTHERWISE IMPLIED, SHALL EXIST IN CONNECTION WITH HLC'S PRODUCTS OR ANY SALE OR USE THEREOF. HLC SHALL IN NO EVENT BE LIABLE FOR ANY LOSS OF PROFITS OR CONSEQUENTIAL OR SPECIAL DAMAGES INCURRED BY BUYER. HLC's warranty shall run only to the first Buyer of a product from HLC, from HLC's Buyer, or from an original goods manufacturer reselling HLC's product, and is non-assignable and non-transferable and shall be of no force and effect if asserted by any person other than such first Buyer. This warranty applies only to the use of the product as intended by HLC and does not cover any modification, misapplication, alteration, repair or misuse of said product by Buyer or others, or for damage caused thereto by negligence, accident, or improper use by Buyer or others. This warranty does not include reimbursement for the expenses of labor, transportation, removal or reinstallation of products. Products may contain certain cosmetic imperfections that do not impact the Product's performance;

Effective August 1, 2015







1

Page 76



these cosmetic imperfections are not considered defects in material or workmanship and shall not be covered by any HLC warranty.

APPLICATION: HLC does not warrant the accuracy of and results from product or system performance recommendations resulting from any engineering analysis or study. This applies regardless of whether a charge is made for the recommendation, or if it is provided free of charge. Responsibility for selection of the proper product of application rests solely with the Buyer. In the event of errors or inaccuracies determined to be caused by HLC, its liability will be limited to the reperformance of any such analysis or study.

BUYER INSPECTIONS: Tests, inspections and acceptance of all material must be made at the factory. Buyer's inspectors are welcome at the factories and are provided with the necessary facilities for carrying out their work. Name and phone number of who should be contacted for inspection should be given to HLC no later than two weeks prior to scheduled shipment date.

LIMITATION OF LIABILITY: IN NO EVENT AND UNDER NO CIRCUMSTANCES, WHETHER AS A RESULT OF BREACH OF CONTRACT OR WARRANTY OR ALLEGED NEGLIGENCE, SHALL HLC BE LIABLE TO BUYER OR ANY OTHER PERSON FOR ANY INDIRECT, SPECIAL OR CONSEQUENTIAL, OR INCIDENTIAL LOSSES OR DAMAGES INCLUDING, WITHOUT LIMITATION DAMAGE TO OR LOSS OF PROFITS OR REVENUE, LOST SALES, LOSS OF USE OF THE GOODS OR ANY ASSOCIATED GOODS, OR DELAY OR FAILURE TO PERFORM THIS WARRANTY OBLIGATION, LOSS OF CAPITAL, COST OF SUBSTITUTE GOODS, FACILITIES OR SERVICES, DOWNTIME COSTS, OR CLAIMS OF THIRD PARTIES OF THE BUYER FOR SUCH DAMAGES ARISING OUT OF OUR IN CONNECTION WITH THE SALE, INSTALLATION, USE OF, INABILITY TO USE, OR THE REPAIR OR REPLACMENT OF, HLC's PRODUCTS. Any warranty claim by Buyer shall be deemed waived by Buyer unless submitted to HLC in writing within thirty (30) days from the date Buyer discovered, or by reasonable inspection should have discovered the alleged breach. Any warranty claim shall be brought within one year of discovery of alleged defect or non-conformity. Upon prompt written notice by the Buyer that a product is defective or non-conformity, HLC's liability shall be limited to repairing or replacing the product, at HLC's option.

<u>DISCLAIMER OF WARRANTY</u>: THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER WRITTEN, ORAL, EXPRESSED OR IMPLIED. THERE IS NO WARRANTY OF FITNESS OF ANY PRODUCT FOR A PARTICULAR PURPOSE.

#### FREIGHT ALLOWANCE and F.O.B. POINT

All shipments are F.O.B. origin. Risk of loss and title of goods shall pass to Buyer upon delivery to the designated carrier. Freight is prepaid and allowed on all shipments of products with a net order value of \$7,500 and above to destinations within the Continental United States and Canada. Shipments to Alaska and Hawaii are F.O.B. Pacific Coast docks, collect beyond. Tool trailers will be F.O.B. HLC's dock – no freight allowed.

HLC reserves the right to route all qualified freight allowed shipments via least expensive surface route within the Continental United States and Canada. Buyer will assume all charges for transportation specified via more expensive means. Acceptance of a specified routing does not constitute a guarantee of ship date, transit time or arrival date. HLC will not be responsible for any cartage or storage charges at destination.

HLC's responsibility for exception-free delivery ceases when the transportation company receives shipment in good condition. Claims for loss or damage must be reported directly to the carrier. HLC's willingness to assist does not indicate liability for claim or replacement.

#### **PARTIAL RELEASE**

If an order has multiple releases specified by the Buyer, each release will be treated as individual orders, relative to freight allowance and minimum billing.

#### **BACK ORDERS**

Back orders that are the responsibility of HLC will be shipped F.O.B. factory or point of shipment with freight prepaid and allowed via the most cost effective method, providing the original order qualified for freight allowance.

#### MINIMUM BILLING

Standard Orders -- \$400 net per order. Minimum waived on hardware only orders. \$40 surcharge for below minimum orders.

#### **ORDER ADD-ON POLICY**

HLC's "Add-On" policy allows you to add items to an existing unshipped order for up to fifteen (15) days from the entry date of the original order.

#### **DELIVERY SCHEDULE**

Shipping dates provided by HLC are estimates only. Based on these estimated shipping dates, HLC makes every reasonable effort to meet Buyer's shipping requirements provided HLC promptly receives all necessary information from Buyer and approved drawings if required by HLC. HLC will not assume liability because of delayed shipment for any reason. HLC's responsibility ceases upon acceptance of shipment by carrier.

Effective August 1, 2015



**HOT BOX** 





#### **CANCELLATIONS**

Cancellation of an order for current stock product requires a minimum of five (5) days' notice prior to actual ship date. Stock item orders shipped after cancellation notice is received, but before expiration of the five-day requirement, will be subject to all standard Returned Goods conditions, noted below.

Cancellation on non-stock items may be made only if no work has been performed or material purchased. If cancellation is requested after work is in progress, there will be a cancellation charge as established by HLC.

Orders may not be cancelled unless HLC gives its written consent, and then only upon agreement as to applicable cancellation charges.

#### **RETURNED GOODS CONDITIONS**

GENERAL CONDITIONS applying to all transactions in which Buyer seeks to return goods to HLC:

- 1. Merchandise is not returnable without the written consent of HLC.
- 2. Request for permission to return merchandise must be made in writing within one year from date of shipment, and Buyer must provide original HLC invoice number with request.
- 3. Material to be returned must be considered standard material by HLC.
- 4. HLC reserves the right to refuse returns of any special or made-to-order material, regardless of condition.
- 5. All returned goods must be in excellent, resaleable condition, and packaged in the original carton. Products will be inspected upon return; and any service or repair needed to place them in first class, saleable condition will be charged and added to the restocking charge.
- 6. A 30% restocking charge will be deducted from all credits issued on authorized returns.
- 7. Return Goods Authorization (RGA) Packing List, supplied by the factory, must accompany the return shipment.
- 8. Return freight must be prepaid. Material must be received by HLC within sixty (60) days of issuance of RGA.
- 9. Net value of the return must not be less than \$250.
- 10. HLC reserves the right to deduct for any damage sustained in transit.
- 11. Unauthorized returns will be refused. Goods returned without proper authorization from HLC will, at the sole option of HLC, be returned to the Buyer freight collect or scrapped immediately with no issuance of credit. Unauthorized material included in a return will not be credited.

#### **BROKEN PACKAGE POLICY**

Shipments will be made in standard package quantities or multiples thereof. HLC Customer Service will notify the Buyer of any orders that do not comply. The Buyer must authorize an adjustment to comply with standard package quantities before the order will be entered.

#### **QUOTATION PRICE PROTECTION**

All prices shown in the price lists are subject to change without notice.

All quotations on special products or modifications to catalog items are binding only if confirmed in writing by the factory for the period shown on the quotation. Price protection will be provided for a period of thirty (30) days from date of quotation from HLC.

#### **ORDERS**

All orders are taken and prices quoted only with the understanding that each order shall be subject to the acceptance of HLC at its principal office upon such terms as we may specify when order is received. Prices to cover amount of any sales or excise tax which now or hereinafter may be imposed by any taxing authority upon this merchandise or the sale or manufacture thereof.

#### PRODUCT SPECIFICATION

HLC reserves the right to discontinue items, modify designs, and change specifications or prices without incurring obligation.

#### **INVOICING**

All invoices are due and payable per the standard terms stated herein. In the case of an apparent discrepancy in a line item charge, Buyer is obligated to advise HLC Customer Service in writing of the nature of the claimed discrepancy within five (5) days of receipt of the invoice. This includes all requests for proof of delivery. A claim of discrepancy does not relieve Buyer of the absolute obligation to pay the remaining balance of the invoice in accordance with the standard terms of payment. HLC, after review, will have sole discretion to resolve the discrepancy; and the Buyer expressly agrees to abide by HLC's decision. HLC will promptly advise Buyer of its decision regarding any disputed items or charges.

#### OSHA

HLC warrants that at time of shipment, the goods will conform to the applicable occupational safety and health standards promulgated pursuant to the Federal Occupational Safety and Health Act of 1970, which are in effect on the date that HLC enters its acknowledgment of Buyer's order. The Buyer's exclusive remedy and HLC's liability for breach of this warranty is limited to replacement of the nonconforming goods.

#### FAIR LABOR STANDARDS ACT AS AMENDED

HLC represents that any goods to be delivered hereunder will be produced in compliance with the requirements of the Fair Labor Standards Act of 1938, as amended.

**NOTE** - These Terms and Conditions supersede all those published and issued previously by Hubbell Lenoir City, Inc., Quazite, CDR Systems, CDR, PenCell, Pen-Cell Plastics, Inc., Polycast, Electrimold, Custom Composites, Western Power Products, Comcore, Hot Box, Windbreaker, and Jandec.

Effective August 1, 2015







| $\sim$ | Ь. |
|--------|----|
| /4     |    |
| 1      | 7  |
| _ \ 7  | г. |

| NOTES: |  |
|--------|--|
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |
|        |  |











Hubbell Enclosures
Hubbell Lenoir City, Inc
3621 Industrial Park Drive • Lenoir City, Tennessee 37771
Phone: 800.346.3062 or 865.986.9726 • Fax: 865.986.0585
hotboxsales@hubbell.com
www.hot-box.com

HB-9

