


Manual Supplement

Manual Title:	1587 FC/1587/1577 Calibration	Supplement Issue:	3
Print Date:	September 2005	Issue Date:	10/21
Revision/Date:	2, 12/15	Page Count:	1

This supplement contains information necessary to ensure the accuracy of the above manual.

Change #1, 65441, 134

On page 4, add the following to the **Symbols** table:

	WARNING. Do not apply greater than 660 Volts
---	--

Change #2, 367

On page 24, Table 4, replace steps 4 and 6 with:

4	1000 V	60.0 MΩ	1 MΩ	0.5	1.5
6	1000 V	2.0 GΩ	1.7 GΩ	1.2	2.2

Change #3, 225

On page 38, Table 9, replace item 41 with:

41*	5211830	1	MP51	15x7, Soft Case, Molded
-----	---------	---	------	-------------------------