

Instrument Security Procedures

Models:

Fluke 117, Fluke 116, Fluke 115, Fluke 114, Fluke 113, Fluke 110,
and Fluke 110 PLUS

Product Name:

True-rms Multimeters

Instrument Description:

Fluke 117 Electrician's Multimeter with Non-Contact Voltage

Fluke 116 HVAC Multimeter with Temperature and Microamps

Fluke 115 Multimeter

Fluke 114 Electrical Multimeter

Fluke 113 Electrical Multimeter

Fluke 110 True-rms Multimeter

Fluke 110 PLUS True-rms Multimeter

Memory Description:

Fluke 117, 116, 115, 114, 113, 110, and 110 PLUS have one memory device:
U2, micro controller, TI MSP430F448, 48kB Flash, 2048B RAM, contains
operating code for the product and calibration constants.

Memory Cleaning Instructions:

The user-controlled storage operation other than calibration constants is the
storage of Min Max and Average. Min, Max and Average is cleared when the
function switch is changed or the unit is powered off.