line starters and enclosures

600 VAC maximum

EMN manual

Cl. I, Div. 1 & 2, Groups C, D Cl. II, Div. 1, Groups E, F, G Cl. II, Div. 2, Groups F, G CI. III NEMA 3, 7CD, 9EFG, 12

Suffix

Explosionproof **Dust-ignitionproof** Raintight Wet Locations

2C

Applications:

EMN manual line starters and enclosures are used:

- For manual across-the-line starting of single and polyphase AC motors
- To provide motor running protection and manual starting and stopping
- In locations made hazardous due to the presence of flammable vapors, gases or highly combustible dusts
- For installation in petroleum refineries, chemical and petrochemical plants and other process industry facilities
- In damp, wet or corrosive locations

Features:

- Compact, rectangular enclosure makes optimum use of internal space
- Operating handle may be padlocked in either ON or OFF position
- Compact design allows installation in area where space is limited
- Furnished with drilled and tapped conduit
- · Polyphase manual starters are furnished with third overload relay as standard

Certifications and compliances:

NEC/CEC:

- Class I, Divisions 1 & 2, Groups C, D
- · Class II, Division 1, Groups E, F, G
- · Class II, Division 2, Groups F, G
- Class III

UL standard:

• UL1203

CSA standard:

C22.2 No. 14

Environmental ratings:

• NEMA/EEMAC 3, 7CD, 9EFG, 12

Standard materials:

- Bodies, covers and toggle operator copper-free aluminum
- · Operating shaft stainless steel
- · Internal operating bail sheet steel or aluminum

Standard finishes:

- Copper-free aluminum natural
- Stainless steel natural
- · Sheet steel electrogalvanized with chromate finish

Electrical ratings:

Starter sizes 0, 1

Options:

Description

Standard breather (Class I, Groups C, D; Class II, Groups E, F, G;

- Standard drain (Class I, Groups C, D; Class II, Groups E, F, G; Class III) S198
- Standard breather and drain (Class I, Groups C, D; Class II, Groups E, F, G; Class III) \$198V
- Universal breather/drain (Class I, Groups C, D; Class II, Groups F, G)... S454
- Two universal breather/drains (Class I, Groups C, D; Class II,

Ordering information:

Select the complete catalog number below and specify horsepower, voltage, frequency, number of phases, RPM, type and full load ampere rating of motor - or specify ampere rating of heaters. Two-pole starters require one heater; three-pole starters have three heaters.

Enclosure only can be ordered. See listing below.



Enclos	


	Poles (phase)	Maximum horsepower ratings		Cat. #	Cat. #	
NEMA size		115 VAC	208 / 240 VAC	480 / 600 VAC	Without starter	With starter
M-0	2 (1-phase)	1	2		EMN24	EMN24 W20
M-1	2 (1-phase)	2	3		EMN24	EMN24 W21
M-0	3 (3-phase)	2	3	5	EMN24	ENANIO A MAZO
N A 1	3 (1-phase)	2	3		EMN24	EMN24 W30
M-1	3 (3-phase)	3	7.5	10	EMN24	EMN24 W31

Motor starters

Motor starter

Manufacturer	Symbol
Cutler-Hammer	W

Dimensionse (in inches):



- ♠ Enclosures are furnished with two 1¼" drilled and tapped openings with 1¼" to 1" reducers.
- BDimensions are approximate, not for construction purposes.

