

Twist-Lock Instructions

For use with Ring Terminals

General Information

1. CAUTION: RISK OF ELECTRIC SHOCK. Disconnect power before installing. For installation by a qualified electrician in accordance with national and local electrical codes. Never wire energized electrical components
2. Use Copper Wire Only.
3. Check that the device's type and rating are suitable for the application.
4. Select conductor size from National Electrical Code® Table 400-5 or Canadian Electrical Code Table 12.
5. Terminal capacity: #14 to 8 AWG.

Installation

Note: For use with UL Listed Ring Terminals Only.

1. Crimp proper wire to ring terminal per manufacturers instructions.
 2. Insert ring terminal between terminal screw and terminal.
- Tighten terminal screw 10-14 lb.in (1.1-1.6 Nm).

Wiring Device-Kellems
Hubbell Incorporated (Delaware)
185 Plains Road
Milford, CT 06460-8897
(203) 882-4800

PD1970 Page 1

PRINTED IN USA 9/03



Twist-Lock Instructions

For use with Ring Terminals

General Information

1. CAUTION: RISK OF ELECTRIC SHOCK. Disconnect power before installing. For installation by a qualified electrician in accordance with national and local electrical codes. Never wire energized electrical components
2. Use Copper Wire Only.
3. Check that the device's type and rating are suitable for the application.
4. Select conductor size from National Electrical Code® Table 400-5 or Canadian Electrical Code Table 12.
5. Terminal capacity: #14 to 8 AWG.

Installation

Note: For use with UL Listed Ring Terminals Only.

1. Crimp proper wire to ring terminal per manufacturers instructions.
 2. Insert ring terminal between terminal screw and terminal.
- Tighten terminal screw 10-14 lb.in (1.1-1.6 Nm).

Wiring Device-Kellems
Hubbell Incorporated (Delaware)
185 Plains Road
Milford, CT 06460-8897
(203) 882-4800

PD1970 Page 1

PRINTED IN USA 9/03

