



**CMBPR\*\*Y, CMBPB\*\*Y**  
(R = Red colored ring)  
(B = Black colored ring)

### Installation Options for Front of Module




#### Option 1

- Strip off about 1/2" to 3/4" of outer jacket from the speaker wire. Twist conductor strands together.
- Remove termination cap from front side of module by rotating counter-clockwise.
- Insert the exposed portion of the speaker wire into the side hole in the binding post shaft.
- Re-install termination cap by rotating clock-wise until wire is secure.



#### Option 2


- Strip off about 1/2" to 3/4" of outer jacket from the speaker wire. Twist conductor strands together.
- Remove termination cap from front side of module by rotating counter-clockwise.
- Curve exposed wire slightly. Wrap wire around the shaft.
- Re-install termination cap by rotating clock-wise until wire is secure.



#### Option 3


- Insert banana plug straight into the shaft on the front side of module.

### Installation Options for Rear of Module



#### Option 1

- Remove set screw from rear shaft.
- Insert banana plug straight into the shaft on the rear side of module.
- Discard set screw.



#### Option 2

- Remove set screw from rear shaft.
- Strip off about 1/2" to 3/4" of outer jacket from the speaker wire. Twist conductor strands together.
- Insert exposed wires into shaft on the rear side of module.
- Replace screw and tighten until wire is secure.