# The Compact Soft Starter with Integrated Bypass

#### Altistart<sup>™</sup> 22

Soft start/soft stop motor control for commercial and light-duty industrial applications







## Altistart 22 soft start/ soft stop unit

The Altistart 22 soft start/soft stop unit uses both voltage and torque control to provide a soft start and soft stop for three-phase asynchronous motors between 17 A and 590 A.



Innovative, economical and safe



#### **Customer values:**

- Reduce your wiring cost and installation time
- Save your valuable mounting space
- Decrease your operating cost
- Improve your machine performance


## Your benefits with an integrated bypass contactor



### Installation couldn't be simpler

- Integrated bypass reduces the number of external components: power wiring, contactor and control wiring for coil
- Wiring 6 terminals instead of 12 saves time and cost
- Fewer components and wiring points reduces heat dissipation allowing for a smaller enclosure
- Fewer components improves the reliability of the installation and decreases maintenance cost

#### Integrated bypass contactor



50% reduction in wiring time

### Bypass the stress


#### Decrease your operating cost


The Altistart 22 soft start/soft stop unit controls motor current in-rush, reducing your electrical demand cost. Conformal coated printed circuit boards provide enhanced resistance to harsh environments, increasing the service life of your installation and reducing maintenance cost.

### Improve your machine performance

- The Altistart 22 soft start/soft stop unit incorporates true three-phase control with other protection functions to monitor and protect your machine to sustain up-time
- The soft start and soft stop reduces mechanical stress on your machine increasing productivity while protecting your delicate goods







# Programming and communication made simple

#### Altistart 22 communicates easily

- The integrated keypad display provides access to configuration menus and provides real-time visual feedback
- The easy start menu guides you through the basic parameters to get you up and running quickly
- The multi-function integrated Modbus® port allows connection to either:
  - » A remote-mount keypad to allow access outside of the enclosure
  - » Connection to a Modbus network for remote communication
  - » SoMove™ PC software for configuration and diagnostics



## Integrated functions to optimize your machine

#### Centrifugal pump

- Soft slowdown and stopping reduces water hammer
- Protection against underloads and reversed rotation

#### Piston pump

- Monitors pump priming and direction of rotation
- Voltage boost on start up

#### Fan

- Underload parameter for broken belt detection
- Brakes torque on stopping

#### **Turbine blowers**

Thermal monitoring of the motor with an electrically-isolated PTC probe

#### Refrigerant compressor

- Monitors starting characteristics
- Manages number and time lapse of starts

### Screw compressor and centrifugal compressor

- Protection against reversed rotation
- Contact for automatic draining on stopping

#### Conveyor

- Overcurrent threshold and time delay parameter for load monitoring
- Second set of motor parameters based on the load carried

#### Screw conveyor

• Input to monitor external state or condition

#### Agitator, mixer

- Displays the current indicating the density of the material
- Automatic cooling fan control





## Altistart product family

Model	Altistart 01	Altistart 22	Altistart 48
Voltage range	110 Vac to 480 Vac single-phase 110 Vac to 480 Vac three-phase	208 Vac to 575 Vac three-phase	230 Vac to 415 Vac three-phase 208 Vac to 690 Vac three-phase
Current range (ICL)	3 A to 12 A, single-phase 6 A to 32 A, three-phase	17 A to 590 A	17 A to 1200 A
Control power options	24 Vdc, 24 Vac or 120 Vac	_	-
Horse power range	1/4 HP to 2 HP, single-phase 1/2 HP to 20 HP, three-phase	3 HP to 500 HP	3 HP to 1200 HP
Communication	_	Embedded Modbus	Embedded Modbus Available options: Web-based Ethernet, FIPIO®, Modbus Plus, Devicenet
Software	_	SoMove	PowerSuite/SoMove
IP	IP20	IP00, IP20	IP00, IP20
Starts per hour	Minimum of 10	6 standard-duty only	10 standard-duty, 5 severe-duty
Motor start/stop	Reduced voltage starting;	Current limit on starting,	Exclusive torque control system
control method	torque limiting on start-up	acceleration and	(TSC) for linear starting and
		deceleration time settings for voltage ramp	stopping, or by current limit adjustment up to 5 times the device rating
Analog inputs	none	1 PTC probe	1 PTC probe
logic inputs	none	3	4
Analog outputs	none	none	1
Logic outputs	none	none	2
Relay outputs	none	2 (N.C./N.O.)	3
Human interface	Adjustment dials and two indicator LEDs	4 LED (Ready, Communication, Run and Trip), 4 seven segment display	3 seven-segment display

Due to possible changes in standards and equipment, the features described in this document in the form of text and images are subject to confirmation by Schneider Electric.

#### Schneider Electric USA, Inc.

Automation and Control Center of Excellence 8001 Knightdale Blvd. Knightdale, NC 27545 Tel: 919-266-3671 www.schneider-electric.us

#### Schneider Electric Canada, Inc.

19 Waterman Avenue Toronto, ON M4B 1Y2 Tel: 1-800-565-6699

