

Enerlin'X IFE/EIFE Ethernet Interface

Firmware Release Notes

DOCA0147EN-14
07/2023



Legal Information

The information provided in this document contains general descriptions, technical characteristics and/or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.

Table of Contents

Safety Information.....	5
About the Book.....	6
Introduction	9
IFE Ethernet Interface for One Circuit Breaker	9
EIFE Embedded Ethernet Interface for One MasterPact MTZ Drawout Circuit Breaker	9
Firmware Release History	10
Firmware Update Policy	10
Firmware Update with EcoStruxure Power Commission Software	10
Firmware Versions	12
Firmware Version 004.011.000	12
Firmware Version 004.010.000	12
Firmware Version 004.009.000	13
Firmware Version 004.008.000	13
Firmware Version 004.007.000	14
Firmware Version 003.016.000	14
Firmware Version 004.005.000	15
Firmware Version 003.015.000	15
Firmware Version 004.004.001	16
Firmware Version 003.014.000	16
Firmware Version 004.003.000	17
Firmware Version 003.013.003	17
Firmware Version 004.002.000	18
Firmware Version 003.012.002	18
Firmware Version 004.001.000	19
User Management Reconfiguration after Firmware Update	19
Firmware Version 003.011.003	20
Firmware Version 003.010.005	21
Firmware Version 003.009.010	21
Firmware Version 003.007.024	22
Firmware Version 003.006.011	23
Firmware Version 003.005.003	23

Safety Information

Important Information

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a "Danger" or "Warning" safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

Please Note

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

About the Book

Document Scope

This document provides the firmware version history of IFE Ethernet interface for one circuit breaker (or IFE interface) and EIFE Embedded Ethernet interface for one MasterPact MTZ drawout circuit breaker (or EIFE interface).

Validity Note

This document is valid for IFE and EIFE interface.

Online Information

The technical characteristics of the devices described in this guide also appear online. To access the information online, go to the Schneider Electric home page at www.se.com.

The information contained in this guide is likely to be updated at any time. Schneider Electric strongly recommends that you have the most recent and up-to-date version available on www.se.com/ww/en/download.

Related Documents for IEC Devices

The following table lists the documents valid for IEC devices that are compatible with an IFE/EIFE interface with the latest firmware version:

Title of documentation	Publication date	Reference number
<i>Enerlin'X IFE – Ethernet Switchboard Server/ Ethernet Interface for One Circuit Breaker – Instruction Sheet</i>	03/2018	QGH13473–02
<i>Enerlin'X IFE – Ethernet Interface for One IEC Circuit Breaker – User Guide</i>	06/2023	DOCA0142EN-08 DOCA0142ES-08 DOCA0142FR-08 DOCA0142ZH-08
<i>Enerlin'X EIFE – Embedded Ethernet Interface for One MasterPact MTZ Drawout Circuit Breaker – Instruction Sheet</i>	09/2017	NVE23550–03
<i>Enerlin'X EIFE – Embedded Ethernet Interface for One MasterPact MTZ Drawout Circuit Breaker – User Guide</i>	06/2023	DOCA0106EN-12 DOCA0106ES-12 DOCA0106FR-12 DOCA0106ZH-12
<i>ULP System (IEC Standard) - User Guide</i>	03/2019	DOCA0093EN-04 DOCA0093ES-04 DOCA0093FR-04 DOCA0093ZH-04
<i>ComPacT NSX - Modbus Communication Guide</i>	07/2022	DOCA0213EN-01 DOCA0213ES-01 DOCA0213FR-01 DOCA0213ZH-01
<i>ComPact NSX - Modbus Communication Guide</i>	07/2022	DOCA0091EN-09 DOCA0091ES-09 DOCA0091FR-09

Title of documentation	Publication date	Reference number
		DOCA0091ZH-09
<i>ComPacT NS - Modbus Communication Guide</i>	07/2022	DOCA0220EN-01 DOCA0220ES-01 DOCA0220FR-01 DOCA0220ZH-01
<i>MasterPact NT/NW, ComPact NS - Modbus Communication Guide</i>	07/2022	DOCA0054EN-10 DOCA0054ES-10 DOCA0054FR-10 DOCA0054ZH-10
<i>MasterPact MTZ – Modbus Communication Guide</i>	07/2022	DOCA0105EN-09 DOCA0105ES-09 DOCA0105FR-09 DOCA0105ZH-09

You can download these technical publications and other technical information from our website at <https://www.se.com/en/download>.

Related Documents for UL/ANSI Devices

The following table lists the documents valid for UL/ANSI devices that are compatible with an IFE/EIFE interface with the latest firmware version:

Title of documentation	Publication date	Reference number
<i>Enerlin'X IFE – Ethernet Switchboard Server/ Ethernet Interface for One Circuit Breaker – Instruction Sheet</i>	03/2018	QGH13473-02
<i>Enerlin'X IFE – Ethernet Interface for One UL Circuit Breaker – User Guide</i>	06/2023	0602IB1801EN-08 0602IB1801ES-08 0602IB1801FR-08 0602IB1801ZH-08
<i>Enerlin'X EIFE – Embedded Ethernet Interface for One MasterPact MTZ Drawout Circuit Breaker – Instruction Sheet</i>	09/2017	NVE23550-03
<i>Enerlin'X EIFE – Embedded Ethernet Interface for One MasterPact MTZ Drawout Circuit Breaker – User Guide</i>	06/2023	DOCA0106EN-12 DOCA0106ES-12 DOCA0106FR-12 DOCA0106ZH-12
<i>ULP System (UL Standard) – User Guide</i>	03/2019	0602IB1503-02 (EN) 0602IB1504-02 (ES) 0602IB1505-02 (FR) 0602IB1506-02 (ZH)
<i>PowerPact H-, J-, and L-Frame Circuit Breakers – Modbus Communication Guide</i>	07/2022	0611IB1302-08 (EN) 0611IB1303-08 (ES) 0611IB1304-08 (FR) 0611IB1305-08 (ZH)

Title of documentation	Publication date	Reference number
<i>MasterPact NT/NW and PowerPact P- and R-Frame – Modbus Communication Guide</i>	07/2022	0613IB1313-10 (EN) 0613IB1314-10 (ES) 0613IB1315-10 (FR) 0613IB1316-10 (ZH)
<i>MasterPact MTZ – Modbus Communication Guide</i>	07/2022	DOCA0105EN-09 DOCA0105ES-09 DOCA0105FR-09 DOCA0105ZH-09

You can download these technical publications and other technical information from the website at <https://www.se.com/en/download>.

Introduction

IFE Ethernet Interface for One Circuit Breaker

When an intelligent modular unit (IMU) contains a circuit breaker equipped with a communicating MicroLogic trip unit, the IFE Ethernet interface for one circuit breaker enables the IMU to be connected to an Ethernet network. Each circuit breaker has its own IFE interface and a corresponding IP address.

The IFE interface with part number LV434001 or LV434010 is an Ethernet interface for the circuit breaker in the IMU.

NOTE: The IFE interface with part number LV434001 completely replaces the IFE interface with part number LV434010. The part number LV434001 comes with the real time clock (RTC) feature and allows ULP connections up to 20 m (65.6 ft) with the MasterPact MTZ circuit breakers (LV434010 had a theoretical limitation of 5 m (16.4 ft) over the life of the IFE interface).

The IFE interface is compatible with the following ranges of circuit breakers:

- MasterPact MTZ circuit breakers
- MasterPact NT/NW circuit breakers
- ComPacT NS circuit breakers
- ComPacT NSX circuit breakers
- PowerPacT P- and R-frame circuit breakers
- PowerPacT H-, J-, and L-frame circuit breakers

NOTE:

- The information related to the new generation of ComPacT NSX and PowerPacT H-, J-, and L-frame circuit breakers in this document applies to ComPacT NSX and PowerPacT H-, J-, and L-frame circuit breakers also. The exceptions are mentioned wherever applicable.
- The information related to the new generation of ComPacT NS and PowerPacT P- and R-frame circuit breakers in this document applies to ComPacT NS and PowerPacT P- and R-frame circuit breakers also. The exceptions are mentioned wherever applicable.

EIFE Embedded Ethernet Interface for One MasterPact MTZ Drawout Circuit Breaker

The EIFE Embedded Ethernet interface for one MasterPact MTZ drawout circuit breaker enables one MasterPact MTZ drawout circuit breaker to be connected to an Ethernet network.

It provides:

- Digital access to all the data that is delivered by the MicroLogic X control unit of the MasterPact MTZ circuit breaker.
- Information about the intelligent modular unit (IMU) system

It also monitors the three positions of the circuit breaker in the cradle:

- Cradle connected
- Cradle disconnected
- Cradle test position

Firmware Release History

The following table indicates the availability of each firmware version for IFE/EIFE interface:

Date	Firmware version	Availability
July 2023	004.011.000	Digital release in EcoStruxure Power Commission (EPC) software (LV434001 and LV851001)
May 2023	004.010.000	Obsolete
February 2023	004.009.000	Obsolete
November 2022	004.008.000	Obsolete
July 2022	004.007.000	Obsolete
	003.016.000	Digital release in EcoStruxure Power Commission (EPC) software (LV434010)
February 2022	004.005.000	Obsolete
	003.015.000	Obsolete
July 2021	004.004.001	Obsolete
	003.014.000	Obsolete
April 2021	004.003.000	Obsolete
	003.013.003	Obsolete
January 2021	004.002.000	Release for manufacturing (LV434001 and LV851001)
	003.012.002	Release for manufacturing (LV434010)
October 2020	004.001.000	Obsolete
	003.011.003	Obsolete
December 2019	003.010.005	Obsolete
March 2019	003.009.010	Obsolete
April 2018	003.007.024	Obsolete
July 2017	003.006.011	Obsolete
December 2016	003.005.003	Obsolete

Firmware Update Policy

Firmware update is recommended to benefit from the latest features and potential bug fixes. Do not update the firmware to the latest version, if the latest features are not required for your application and no bug fixes are provided.

Use this release note to confirm if an update to the latest version of the firmware is relevant for your application.

NOTE: You can upgrade the firmware version from 003.xxx.xxx to 004.xxx.xxx but vice-versa is not possible.

For more information on the firmware update policy and the firmware compatibility between devices, refer to [DOCA0155EN MicroLogic Trip and Control Units - Firmware History](#).

Firmware Update with EcoStruxure Power Commission Software

Use the latest version of EcoStruxure Power Commission software to update the device with the latest firmware version available.

The latest version of EcoStruxure Power Commission software is available on www.se.com.

For more information on the use of EcoStruxure Power Commission software, refer to *EcoStruxure Power Commission Online Help*.

Firmware Versions

Firmware Version 004.011.000

New Features

Added the following list of events with email notification:

- Events from the IDMTG ground-fault protection.
- Events indicating the change of passwords.

Firmware Version 004.010.000

Security Updates

Enhanced cybersecurity features.

New Features

- Added Device Specific Settings (DSS) feature that enables the IFE/EIFE interface configurations to be tailored for each individual device.
- Added signature verification feature to validate the security configuration files received from CAE software.

Firmware Version 004.009.000

Security Updates

Restored compatibility with EcoStruxure Cybersecurity Admin Expert software version 2.4.3 and later.

New Features

Added Role Base Access Control (RBAC) for ComPacT NSX with MicroLogic 5, 6, and 7 trip units.

Bugs Fixed

IFE/EIFE webpage did not load on certain versions of Google Chrome.

NOTE: The above bug was observed in Google Chrome version 107.0.5304.63 (official build) (64-bit).

Firmware Version 004.008.000

Security Updates

Enhanced cybersecurity features.

Firmware Version 004.007.000

Security Updates

Enhanced cybersecurity features.

New Features

- Added the Syslog logging service feature.
- Added the Machine-to-Machine (M2M) communication for Modbus communication.
- Added Role Base Access Control (RBAC) for MasterPact MTZ with MicroLogic X control unit.

Known Issues

Diagnostics page for RSTP goes blank when the RSTP service is disabled.

Firmware Version 003.016.000

New Features

Freshness timeout for ULP communication is configurable.

Firmware Version 004.005.000

Security Updates

Enhanced cybersecurity features.

New Features

Enhanced firmware upgrade feature for ComPacT NSX and PowerPacT H-, J-, and L-frame circuit breakers.

Known Issues

Lost compatibility with EcoStruxure Cybersecurity Admin Expert software.

Firmware Version 003.015.000

New Features

Enhanced firmware upgrade feature for ComPacT NSX and PowerPacT H-, J-, and L-frame circuit breakers.

Firmware Version 004.004.001

Security Updates

- Enhanced cybersecurity features.
- Included the patch for IPv6 vulnerabilities.

New Features

Added ComPacT NS and PowerPacT P- and R-frame circuit breakers. These new ranges are the evolution of existing ComPact NS and PowerPact P- and R-frame range of circuit breakers.

Bugs Fixed

The measurement values were inconsistent with the real time values after the IMU system recovered from critical discrepancy.

Firmware Version 003.014.000

Security Updates

Included the patch for IPv6 vulnerabilities.

Firmware Version 004.003.000

New Features

Added ComPacT NSX and PowerPacT H-, J-, and L- frame circuit breakers. These new ranges are the evolution of existing ComPact NSX and PowerPact H-, J-, and L-frame range of circuit breakers.

Bugs Fixed

- Language and phone number was not updated while creating a user account.
- Location field was removed from the user account pages.
- After the firmware was upgraded from 003.xxx.xxx to 004.002.000, the HTTPS protocol was not enabled by default.
- After the firmware was upgraded from 003.xxx.xxx to 004.002.000, the FTP protocol was disabled.
- The register 12395 for freshness timeout setting was not always accessible without the installation of the Modbus Legacy Dataset Digital Module.

Firmware Version 003.013.003

New Features

Added ComPacT NSX and PowerPacT H-, J-, and L- frame circuit breakers. These new ranges are the evolution of existing ComPact NSX and PowerPact H-, J-, and L-frame range of circuit breakers.

Bugs Fixed

New administrators were able to perform the control operations without the acceptance of the disclaimer message.

Firmware Version 004.002.000

New Features

- Added MicroLogic Xi control units. A MicroLogic Xi is a control unit without Bluetooth Low Energy (BLE) communication.
- Enhanced the following cybersecurity features:
 - Enabled the FTPS mode for file import.
 - Enabled automatic export of datalog file.

Firmware Version 003.012.002

New Features

Added MicroLogic Xi control units. A MicroLogic Xi is a control unit without Bluetooth Low Energy (BLE) communication.

Bugs Fixed

Time synchronization of IFM interface with IFE/EIFE interface did not happen when the IFE/EIFE interface was in Daylight Saving mode.

Firmware Version 004.001.000

New Features

- Improved design for the webpages interface.
- Added the IEC 61850 communication protocol, which is compatible with CET850 configuration software.
- Added the Rapid Spanning Tree Protocol (RSTP).
- Enhanced the Simple Network Time Protocol (SNTP) with the Network Time Protocol (NTP).
- Enhanced the following Cybersecurity features:
 - Revised the user management configuration rules according to the Role Base Access Control (RBAC) strategy (Refer to [User Management Reconfiguration after Firmware Update](#), page 19).
 - Strengthened the policies of password security.
 - Enabled the HTTPS mode for the web interface.
 - Harmonized the users list of FTP server with the webpage.
 - Enabled compatibility with EcoStruxure Cybersecurity Admin Expert software.
- Added the events for internal Current Power Supply (CPS) sensors, available with a MicroLogic X control unit with firmware version 004.105.000 or higher.

User Management Reconfiguration after Firmware Update

⚠ WARNING

POTENTIAL COMPROMISE OF SYSTEM AVAILABILITY, INTEGRITY, AND CONFIDENTIALITY

Change default passwords at first use to help prevent unauthorized access to device settings, controls, and information.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

NOTICE

LOSS OF DATA

- Ensure that you take backup of the data log files before updating the firmware. The data log entries of the IFE/EIFE interface may be lost when the firmware is updated.
- Ensure that you take backup of data present in User Accounts and Email Events sections of IFE/EIFE webpages.
- Ensure that after firmware upgrade, you restore the User Accounts and Email Events configuration on IFE/EIFE webpages.

Failure to follow these instructions can result in permanent loss of data.

To take advantage of new security features, the reconfiguration of the IFE/EIFE-webpage users is required when an IFE/EIFE interface firmware is updated from a version 003.010.005 or lower to 004.001.000 or higher.

The management of the users of the IFE/EIFE webpages for firmware version 004.001.000 or higher is based on Role Base Access Control (RBAC). It is not compatible with the user management of the IFE/EIFE webpages for firmware version 003.010.005 or lower.

After the firmware update of an IFE/EIFE interface from a version 003.010.005 or lower to 004.001.000 or higher:

- the Guest account is removed
- the Administrator account is removed and replaced by a SecurityAdmin user:
 - with the default password: **AAAAAAAA**
 - with the email address of the Administrator account
- the first 11 configurable user accounts are maintained:
 - with the same user names. If a user name was shorter than 4 characters, then **0** are added to complete it to 4 characters.
 - with the same email addresses
 - with the default password: **Admin@123**
 - with **Viewer** role
- the last 3 configurable accounts are removed
- the export of logging data by email is disabled
- the notification of email events is reset to default values
- the email addresses for notifications are removed

Once the IFE/EIFE interface firmware is updated from a version 003.010.005 or lower to 004.001.000 or higher, the Security Administrator must edit and review the user accounts configuration on the **USER MANAGEMENT** webpage.

Firmware Version 003.011.003

New Features

- Added the events for internal Current Power Supply (CPS) sensors, available with the MicroLogic X control unit for firmware version 004.105.000 or higher.

Bugs Fixed

- Treck TCP/IP Vulnerabilities (Ripple20)
For more information, refer to [SEVD-2020-175-01](#) *Schneider Electric Security Notification*.

Firmware Version 003.010.005

New Features

- Added access through Modbus registers to the following data for MasterPact MTZ circuit breakers:
 - IDMTL protection trip
 - Over/Under frequency trip
 - Directional overcurrent trip
 - Discrepancy between display and MicroLogic

Bugs Fixed

- When IP Filtering was enabled as Read only, the Modbus function *Scattered read* was blocked.

Firmware Version 003.009.010

New Features

- Added the following maintenance features, available with a MicroLogic X control unit with firmware version 003.011.000 or higher:
 - New events for contact wear ratio
 - New events for type of preventive maintenance to be performed
- Added access through Modbus registers to the following data for MasterPact MTZ circuit breakers:
 - Average peak current demand
 - Minimum and maximum values of real-time measurements
 - Energy per phase values
 - Main settings of the active setting group of current protection functions

NOTE: The configuration of the connection to EcoStruxure Facility Expert is not available now. You can use Enerlin'X COM'X energy servers to configure the connection to EcoStruxure Facility Expert.

Bugs Fixed

- IFE/EIFE interface lost its clock master status when SNTP server did not answer.
- IFE/EIFE interface restarted when discovery packet from Satchwell Sigma BMS platform was received.

Firmware Version 003.007.024

New Features

New features in this firmware version for IFE/EIFE interface:

Added the following features, available with a MicroLogic X control unit with firmware version 002.000.003 or higher:

- Monitoring of current and power demand values
- Reset of peak demand values
- New events for notification by email:
 - Presence of 24 Vdc power supply
 - Ground-fault alarm/ Earth-leakage alarm (available when Ground-fault Digital Module is installed on MicroLogic X control unit)
- Update of standard dataset with current and power demand values
- Availability of legacy dataset when Modbus Legacy Dataset Digital Module is installed on the MicroLogic X control unit
- Availability of individual harmonics and currents up to rank 40 when Individual Harmonics Analysis Digital Module is installed on the MicroLogic X control unit
- Introduction of new mechanism for activating Digital Modules across Enerlin'X devices
- Modification to management of multiple requests through command interface: reception of new command aborts previous command still in progress.

New features in this firmware version for IFE interface:

- Added ComPacT NSX circuit breaker with MicroLogic 7 trip unit as discoverable device that can be connected to ULP port of IFE interface.

Bugs Fixed

Bugs fixed in this firmware version for IFE interface:

- LV434001: ULP LED was blinking green instead of yellow when IFE interface was in Boot mode.

Firmware Version 003.006.011

New Features

New features in this firmware version for IFE/EIFE interface:

- Added access through Modbus registers to the trip cause data for MasterPact MTZ circuit breakers
- Added support of alpha-numeric passwords for IFE webpages

New features in this firmware version for IFE interface:

- Added support for the internal battery that maintains the date and time settings of the real-time clock (RTC) during a power loss (reference LV434001)
- Added compatibility with ULP cables up to 20 m (65 ft) in length
- Added alarm support for the MicroLogic P and H advanced protection settings, allowing an alarm email to be sent
- Added discovery from IFE webpages of devices equipped with non-communicating trip units, through BCM or BSCM module (e.g. NSX non-communicating MicroLogic with BSCM module), for device status display only
- Added compatibility with new MicroLogic 7 trip units for ComPacT NSX circuit breakers

Bugs Fixed

Bugs fixed in this firmware version for IFE/EIFE interface:

- FTP server could not be enabled in Italian language

Bugs fixed in this firmware version for IFE interface:

- BCM firmware update was not performed when IFE device closed connection in DHCP mode.

Firmware Version 003.005.003

New Features

- Added the MasterPact MTZ circuit breakers as discoverable devices.
- Added the integration of secure email.

Bugs Fixed

- IFE time and date were not well synchronized with the SNTP server.
- Refresh of data on IFE device stopped after a few hours of use.
- IP filtering was disabled after a firmware update of IFE devices.
- IFE device and IO module ULP communication did not share the correct cradle status when powered up with a device in disconnected position.

Schneider Electric
35 rue Joseph Monier
92500 Rueil Malmaison
France

+ 33 (0) 1 41 29 70 00

www.se.com

As standards, specifications, and design change from time to time,
please ask for confirmation of the information given in this publication.

© 2023 Schneider Electric. All rights reserved.

DOCA0147EN-14